


GOT-A900 Series Operating Manual

(GT Works2 Version2/GT Designer2 Version2 Compatible
Extended·Option Functions Manual)



Graphic Operation Terminal
900
series



● SAFETY PRECAUTIONS ●

(Always read these instructions before using this equipment.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly.

The instructions given in this manual are concerned with this product. For the safety instructions of the programmable controller system, please read the CPU module user's manual.

In this manual, the safety instructions are ranked as "DANGER" and "CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Note that the  CAUTION level may lead to a serious consequence according to the circumstances. Always follow the instructions of both levels because they are important to personal safety.

Please save this manual to make it accessible when required and always forward it to the end user.

[PRECAUTION WHEN PERFORMING THE TEST OPERATION]

CAUTION

- Read the manual carefully and fully understand the operation before the test operation (ON/OFF) of bit devices, modifying current value of a word device, modifying timer/counter setting, modifying the current value, or modifying the current value of a buffer memory) of system monitor, special function module monitor, and ladder monitor.

In addition, never modify data in a test operation to a device which performs a crucial operation to the system.

It may cause an accident by a false output or malfunction.

REVISIONS

* The manual number is given on the bottom left of the back cover.

Print Date	* Manual Number	Revision
Oct., 2004	SH (NA)-080523ENG-A	First edition
Mar., 2005	SH (NA)-080523ENG-B	Partial correction Section 12.23, Section 12.28, Section 12.29, Section 12.31, Section 12.32
Jan., 2006	SH (NA)-080523ENG-C	Partial correction Section 2.2, Section 9.1.2, Section 31.2.1, Section 31.2.2 → Section 31.2.3, Section 31.3 Partial addition Section 3.9.3, Section 4.5, Section 6.3.2 Addition Section 1.1.11, Section 3.10, Section 31.2.2, Chapter 32
Jun., 2006	SH (NA)-080523ENG-D	Partial correction Section 6.3.3, Section 6.3.4 → Section 6.3.5, Section 6.3.5 → Section 6.3.6 Addition Section 6.3.4
Nov., 2006	SH(NA)-080523ENG-E	Addition Section 3.2.4
Nov., 2006	SH(NA)-080523ENG-F	Partial correction Layouts were revised. Titles of chapters and sections were revised.

Japanese Manual Version SH-080516-G

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2004 MITSUBISHI ELECTRIC CORPORATION

INTRODUCTION

Thank you for choosing the Mitsubishi Graphic Operation Terminal.
Please read this manual carefully so that equipment is used to its optimum.

CONTENTS

SAFETY PRECAUTIONS	A - 1
REVISIONS.....	A - 2
INTRODUCTION.....	A - 3
CONTENTS	A - 3
ABOUT MANUALS	A - 12
ABBREVIATIONS AND GENERIC TERMS IN THIS MANUAL.....	A - 13

1 OVERVIEW 1 - 1 to 1 - 17

1.1 Features	1 - 1
1.1.1 Features of the utility function.....	1 - 1
1.1.2 Features of the ladder monitor function	1 - 3
1.1.3 Features of the system monitor function	1 - 5
1.1.4 Features of the special module monitor function	1 - 7
1.1.5 Features of the network monitor function	1 - 9
1.1.6 Features of the List editor function	1 - 11
1.1.7 Features of the motion monitor function	1 - 12
1.1.8 Features of the servo amplifier monitor functions.....	1 - 14
1.1.9 Features of the CNC monitor functions	1 - 16
1.1.10 Features of the font change function	1 - 17
1.1.11 Features of the system dialog language switching function	1 - 17

2 BEFORE BEGINNING OPERATION 2 - 1 to 2 - 15

2.1 Before getting started with various functions	2 - 1
2.2 Precautions before use	2 - 1

3 SPECIFICATIONS 3 - 1 to 3 - 29

3.1 Ladder monitor function specifications	3 - 1
3.1.1 PLC CPUs to be monitored	3 - 1
3.1.2 Access ranges to be monitored	3 - 1
3.1.3 Precautions when using the ladder monitor function.....	3 - 1
3.2 System monitor function specifications	3 - 2
3.2.1 PLC CPUs to be monitored	3 - 2
3.2.2 Access ranges to be monitored	3 - 2
3.2.3 Names of devices to be monitored	3 - 2
3.2.4 Precautions when using the system monitor function	3 - 2
3.3 Special module monitor function specifications	3 - 3
3.3.1 Access ranges to be monitored	3 - 4
3.3.2 Special function modules to be monitored.....	3 - 4
3.3.3 Memory capacity	3 - 5
3.3.4 Precautions when using the special module monitor function	3 - 6

3.4	Network monitor function specifications	3 - 9
3.4.1	Network information to be monitored	3 - 9
3.4.2	Access ranges to be monitored	3 - 10
3.4.3	Precautions when using the network monitor function	3 - 10
3.5	List editor function specifications	3 - 11
3.5.1	PLC CPU that allows for list edit	3 - 11
3.5.2	Access range that allows for list edit	3 - 11
3.5.3	Precautions for List editor function	3 - 11
3.5.4	List of key arrangement and key functions	3 - 12
3.5.5	Display format on the display	3 - 15
3.5.6	List of List editor function	3 - 18
3.6	Specifications of the motion monitor function	3 - 20
3.6.1	PLC CPUs that can be monitored	3 - 20
3.6.2	Access ranges that can be monitored	3 - 20
3.6.3	Precautions for use of the motion monitor function	3 - 20
3.6.4	Memory space necessary to use the motion monitor function	3 - 20
3.7	Specifications of the Servo Amplifier Monitor Functions	3 - 21
3.7.1	List of servo amplifier models that can be monitored and functions	3 - 21
3.7.2	Access range that can be monitored	3 - 21
3.7.3	Precautions for use of the servo amplifier monitor functions	3 - 22
3.7.4	System configuration for servo amplifier connection	3 - 22
3.7.5	Screens and memory capacity	3 - 23
3.8	CNC monitor function specifications	3 - 26
3.8.1	CNC models that can be monitored	3 - 26
3.8.2	CNC functions that can be monitored	3 - 26
3.8.3	Access ranges to be monitored	3 - 26
3.8.4	Precautions when using the CNC monitor function	3 - 26
3.9	Font change function specifications	3 - 27
3.9.1	Available fonts	3 - 27
3.9.2	Applicable range for each font	3 - 27
3.9.3	Precautions when using the font change function	3 - 28
3.10	System dialog language switching function specifications	3 - 29
3.10.1	Switchable languages	3 - 29
3.10.2	Precautions when using the system dialog language switching function	3 - 29

4 OPERATING THE UTILITY FUNCTION **4 - 1 to 4 - 22**

4.1	Utility function table	4 - 1
4.2	Selecting the utility function	4 - 2
4.3	Utility Menu Screen	4 - 3
4.4	Screen & OS Copy	4 - 5
4.5	Setup	4 - 7
4.6	Self-Test	4 - 15
4.7	Memory Information	4 - 16
4.8	Clock	4 - 17
4.9	Screen Cleanup	4 - 18
4.10	Security Password	4 - 19

4.11 Password	4 - 20
4.12 Brightness/Contrast Adjustment	4 - 21

LADDER MONITOR FUNCTION

5 OPERATING LADDER MONITOR 5 - 1 to 5 - 2

5.1 Operation procedures before starting ladder monitoring	5 - 1
5.2 Operation procedures from display of user-created monitor screen to start of ladder monitoring	5 - 2

6 OPERATING THE VARIOUS LADDER MONITOR SCREENS 6 - 1 to 6 - 30

6.1 Display screens	6 - 1
6.2 Screen operation and screen changes when monitoring	6 - 3
6.2.1 Reading data from the PLC	6 - 3
6.2.2 Ladder read operation	6 - 9
6.2.3 Using the defect search	6 - 12
6.2.4 Touch search operation	6 - 16
6.2.5 Changing from one screen to another	6 - 18
6.3 Ladder monitor	6 - 19
6.3.1 Ladder monitor screen display and key functions	6 - 19
6.3.2 Precaution during ladder monitoring	6 - 22
6.3.3 Switching displays	6 - 24
6.3.4 Language switching (MELSEC-Q ladder monitor)	6 - 26
6.3.5 Changing the device value	6 - 29
6.3.6 About Hardcopy Output	6 - 30

7 ERROR MESSAGES FOR LADDER MONITOR 7 - 1 to 7 - 2

SYSTEM MONITOR FUNCTION

8 OPERATING SYSTEM MONITOR 8 - 1 to 8 - 2

8.1 Operation procedures before starting system monitoring	8 - 1
8.2 Operation procedures from user-created monitor screen display to start of system monitoring	8 - 2

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS 9 - 1 to 9 - 22

9.1 Screen configuration, common operations and changing screens when monitoring	9 - 1
9.1.1 Basic screen configuration and key functions (menu)	9 - 1
9.1.2 Switching displays	9 - 2
9.1.3 Specifying the monitor station and device (SET)	9 - 4
9.1.4 Changing screens	9 - 6
9.2 Entry monitor	9 - 7
9.2.1 Basic operation	9 - 7
9.2.2 Entry monitor screen display and key functions	9 - 8
9.2.3 Deleting a registered device	9 - 9
9.3 Batch monitor	9 - 10
9.3.1 Basic operation	9 - 10
9.3.2 Batch monitor screen display and key functions	9 - 11

9.4	TC Monitor (monitor of timer and counter)	9 - 12
9.4.1	Basic operation	9 - 12
9.4.2	TC Monitor screen display and key functions	9 - 13
9.5	BM Monitor (monitor of buffer memory)	9 - 14
9.5.1	Basic operation	9 - 14
9.5.2	BM Monitor screen display and key functions	9 - 15
9.6	Test	9 - 16
9.6.1	Basic operation	9 - 17
9.6.2	Quick test function	9 - 20

10 ERROR MESSAGES FOR SYSTEM MONITOR 10 - 1 to 10 - 2

SPECIAL MODULE MONITOR FUNCTION

11 OPERATING SPECIAL MODULE MONITOR 11 - 1 to 11 - 2

11.1	Operation procedures before starting special module monitoring	11 - 1
11.2	Operation procedures from user-created monitor screen display to start of special module monitor	11 - 2

12 OPERATING SPECIAL MODULE MONITOR SCREEN 12 - 1 to 12 - 82

12.1	Screen configuration, common operation and changing screens when monitoring	12 - 1
12.1.1	Composition of system configuration screen and key functions	12 - 1
12.1.2	Setting method for remote station monitoring	12 - 4
12.1.3	Composition of PC Information screen and key functions (only when QCPU(Q mode) is used)	12 - 5
12.1.4	Composition of Unit Detail info screen and key functions (only when QCPU(Q mode) is used)	12 - 6
12.1.5	Monitor screen configuration and key functions	12 - 7
12.1.6	Specifying monitor module and selecting monitor menu	12 - 8
12.1.7	Test for special function module	12 - 9
12.1.8	Changing the screen	12 - 11
12.2	A61LS Module Monitor	12 - 12
12.3	AD61 Module Monitor	12 - 13
12.4	A1SD61 Module Monitor	12 - 14
12.5	A62DA-S1 Module Monitor	12 - 15
12.6	A1S62DA Module Monitor	12 - 16
12.7	A62LS Module Monitor	12 - 17
12.8	A1S62RD Module Monitor	12 - 18
12.9	A1S63ADA Module Monitor	12 - 19
12.10	A1S64AD Module Monitor	12 - 20
12.11	A68AD Module Monitor	12 - 21
12.12	A1S68AD Module Monitor	12 - 22
12.13	A68ADN Module Monitor	12 - 23
12.14	A68RD Module Monitor	12 - 24

12.15	A1S68DAI,A1S68DAV Module Monitor	12 - 25
12.16	A616AD Module Monitor	12 - 26
12.17	A616DAI,A616DAV Module Monitor	12 - 28
12.18	A616TD Module Monitor	12 - 29
12.19	AD70,A1SD70 Module Monitor	12 - 32
12.20	AD70D Module Monitor	12 - 34
12.21	AD71 Module Monitor	12 - 37
12.22	AD72,A1SD71 Module Monitor	12 - 40
12.23	AD75, A1SD75 Module Monitor	12 - 43
12.24	AJ71PT32-S3, A1SJ71PT32-S3 Module Monitor	12 - 49
12.25	AJ71ID1(ID2) -R4, A1SJ71ID1(ID2) -R4 Module Monitor	12 - 51
12.26	A84AD Module Monitor	12 - 52
12.27	A1S64TCTT(BW)-S1, A1S64TCRT(BW)-S1 Module Monitor	12 - 53
12.28	Q64AD,Q68ADV,Q68ADI Module Monitor	12 - 55
12.29	Q62DA,Q64DA Module Monitor	12 - 56
12.30	QD62,QD62D Module Monitor	12 - 57
12.31	QD75P,QD75D Module Monitor	12 - 58
12.32	QD75M Module Monitor	12 - 69

13 OPERATING I/O MODULE MONITOR SCREENS 13 - 1 to 13 - 2

13.1	Specifying the module to be monitored	13 - 1
13.2	Monitor screen configuration and key functions	13 - 2

14 ERROR MESSAGES FOR SPECIAL MODULE MONITOR 14 - 1 to 14 - 2

NETWORK MONITOR FUNCTION

15 OPERATING NETWORK MONITOR 15 - 1 to 15 - 2

15.1	Steps in getting started with the network monitor function	15 - 1
15.2	Steps in starting the network monitor function from the user-created monitor screen	15 - 2

16 SWITCHING THE NETWORK MONITOR SCREENS 16 - 1 to 16 - 2

17 USING THE NETWORK MONITOR SCREENS 17 - 1 to 17 - 18

17.1	Own station monitor	17 - 1
17.1.1	Display contents and keys functions: own station monitor	17 - 1
17.2	Detailed own station monitor	17 - 4
17.2.1	MELSECNET/B, MELSECNET (II) master station	17 - 4
17.2.2	MELSECNET/B, MELSECNET (II) local station	17 - 5
17.2.3	MELSECNET/10 Control station/ordinary Station	17 - 6
17.2.4	MELSECNET/10, MELSECNET/H remote master station	17 - 9

17.3	Other station monitor	17 - 12
17.3.1	Other station monitor menu	17 - 12
17.3.2	Other station communication status monitor	17 - 13
17.3.3	Other station data link status monitor	17 - 14
17.3.4	Other station parameter status monitor	17 - 15
17.3.5	Other station CPU action status monitor	17 - 16
17.3.6	Other station CPU RUN status monitor	17 - 17
17.3.7	Other station loop status monitor	17 - 18

18 ERROR MESSAGES FOR NETWORK MONITOR 18 - 1 to 18 - 2

LIST EDITOR FUNCTION

19 OPERATING LIST EDITOR 19 - 1 to 19 - 5

19.1	Operation procedures before starting the list edit	19 - 1
19.2	Operation procedures from user-created monitor screen display to starting list editing	19 - 2
19.2.1	Operation of keyword input.....	19 - 3
19.2.2	Selection and operation of mode	19 - 5

20 OPERATION OF EDITING SCREEN FOR EACH LIST 20 - 1 to 20 - 17

20.1	Basic operation of key input	20 - 1
20.1.1	Switching of valid key (function indicated at the upper/lower part of the key)	20 - 1
20.1.2	Command input procedures	20 - 2
20.1.3	Action if an incorrect key is input	20 - 6
20.2	Basic operation of list edit	20 - 7
20.2.1	Reading sequence program	20 - 7
20.2.2	Changing (overwriting) command.....	20 - 8
20.2.3	Adding (inserting) command.....	20 - 9
20.2.4	Deleting command.....	20 - 10
20.2.5	Using Help function.....	20 - 11
20.3	Operation procedure list of list edit	20 - 13
20.3.1	Common operation	20 - 13
20.3.2	Operation in Write mode (W).....	20 - 13
20.3.3	Operation in Read mode (R).....	20 - 14
20.3.4	Operation in Insert mode (I).....	20 - 14
20.3.5	Operation in Delete (D) mode.....	20 - 14
20.3.6	Operation in Parameter mode (P).....	20 - 15
20.3.7	Operation in Other modes (O)	20 - 16

21 ERROR MESSAGES FOR LIST EDITOR 21 - 1 to 21 - 6

21.1	Error detected with the list editor function	21 - 1
21.2	Error of PLC CPU	21 - 4
21.3	Error using list editor function on the link system	21 - 5

MOTION MONITOR FUNCTION

22 OPERATING MOTION MONITOR	22 - 1 to 22 - 4
22.1 Operation procedures before starting motion monitoring	22 - 1
22.2 Operation procedures from user-created monitor screen display to start of motion monitor	22 - 2
22.2.1 Password entry operation procedure.....	22 - 4
23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS	23 - 1 to 23 - 17
23.1 Screen layout, common operations and screen changes for monitoring	23 - 1
23.1.1 System configuration screen layout and key functions.....	23 - 1
23.2 Changing the screen	23 - 3
23.3 Motion monitor	23 - 4
23.3.1 Display data and key functions of present value monitor screen	23 - 5
23.3.2 Display data and key functions of SFC error history screen.....	23 - 6
23.3.3 Display data and key functions of error list screen	23 - 7
23.3.4 Display data and key functions of error list designated-axis screen.....	23 - 8
23.3.5 Display data and key functions of positioning monitor screen.....	23 - 10
23.3.6 Display data and key functions of servo monitor screen	23 - 12
23.3.7 Display data and key functions of present value history monitor screen.....	23 - 13
23.4 Parameter setting	23 - 15
23.4.1 Display data and key functions of parameter setting screen.....	23 - 15
23.4.2 Parameter setting operation	23 - 16
23.5 About Hardcopy Output	23 - 17
24 ERROR MESSAGES FOR MOTION MONITOR	24 - 1 to 24 - 2

SERVO AMPLIFIER MONITOR FUNCTION

25 OPERATING SERVO AMPLIFIER MONITOR	25 - 1 to 25 - 2
25.1 Operation procedures before starting motion monitoring	25 - 1
25.2 Operation procedures from user-created monitor screen display to start of motion monitor	25 - 2
26 OPERATIONS OF SERVO AMPLIFIER MONITOR SCREENS	26 - 1 to 26 - 36
26.1 Screen Transition	26 - 1
26.2 About the Servo Amplifier Monitor Functions	26 - 2
26.3 Setup	26 - 3
26.3.1 Setup screen	26 - 3
26.4 Monitor Functions	26 - 5
26.4.1 Monitor screen.....	26 - 5
26.5 Alarm Function	26 - 7
26.5.1 Alarm display screen	26 - 8
26.5.2 Alarm history screen.....	26 - 9
26.6 Diagnostics Function	26 - 10
26.6.1 DI/DO display screen.....	26 - 13

26.6.2	Function device display screen.....	26 - 14
26.6.3	Amplifier information display screen.....	26 - 15
26.6.4	ABS data display screen.....	26 - 16
26.6.5	Unit composition list display screen.....	26 - 17
26.7	Parameter Setting	26 - 18
26.7.1	Password entry operation procedure.....	26 - 19
26.7.2	Parameter setting screen.....	26 - 20
26.7.3	Parameter setting operation	26 - 22
26.8	Test Operations	26 - 24
26.8.1	Precautions for test operations.....	26 - 27
26.8.2	Preparations for test operations.....	26 - 28
26.8.3	JOG operation screen.....	26 - 29
26.8.4	Positioning operation screen	26 - 30
26.8.5	Motorless operation screen	26 - 32
26.8.6	DO forced output screen.....	26 - 33
26.9	About Hardcopy Output	26 - 34

27 ERROR MESSAGES FOR SERVO AMPLIFIER MONITOR 27 - 1 to 27 - 2

CNC MONITOR FUNCTION

28 OPERATING CNC MONITOR 28 - 1 to 28 - 2

28.1	Operation procedures before starting CNC monitoring	28 - 1
------	---	--------

29 OPERATING THE CNC MONITOR FUNCTION SCREEN 29 - 1 to 29 - 3

29.1	Changing screens	29 - 1
29.2	About the CNC Monitor Functions	29 - 2

30 ERROR MESSAGES FOR CNC MONITOR 30 - 1 to 30 - 2

OTHER EXTENDED/OPTION FUNCTIONS

31 FONT CHANGE FUNCTION 31 - 1 to 31 - 10

31.1	Preparation to use the font change function	31 - 1
31.1.1	Checking the required devices	31 - 1
31.1.2	Checking the ROM_BIOS version	31 - 1
31.1.3	Checking the OS.....	31 - 2
31.2	Operation of the font change function	31 - 3
31.2.1	Setting the font change device	31 - 3
31.2.2	Displaying Chinese (simplified characters) fonts with Preview of GT Designer2	31 - 4
31.2.3	Installing font data.....	31 - 8
31.3	Troubleshooting when font cannot be changed.	31 - 10

32 SYSTEM DIALOG LANGUAGE SWITCHING 32 - 1 to 32 - 4

32.1	Preparation to use the system dialog language switching function	32 - 1
32.1.1	Checking the required devices	32 - 1

32.1.2	Checking the ROM_BIOS version	32 - 1
32.1.3	Checking the OS	32 - 1
32.2	Operation of the system dialog language switching function	32 - 2
32.2.1	Setting the system dialog language switching device	32 - 2
32.3	Example of system dialog language display	32 - 3

ABOUT MANUALS

The following manuals related to this product are available. Obtain the manuals as required the according to this table.

• Related manual

Manual name	Manual number (type code)
GT Designer2 Version2 Operating Manual (Startup ▫ Introductory Manual) Describes methods of installing GT Designer2 and introductory drawing methods. (Sold separately)	SH-080520ENG (1DM215)
GT Designer2 Version2 Operating Manual Describes methods of operating GT Designer2 and transmitting data to GOT. (Sold separately)	SH-080521ENG (1DM216)
GT Designer2 Version2 Reference Manual Describes the specifications and settings of each object function used in GT Designer2. (Sold separately)	SH-080522ENG (1DM217)
GOT-A900 Series Operating Manual (GT Designer2 Version2 compatible Gateway Functions Manual) Describes the gateway function specifications, system configuration and methods of setting GOT-A900 series. (Sold separately)	SH-080525ENG (1DM220)
A985GOT/A975GOT/A970GOT/A960GOT User's Manual Provides performance specification, setting method, and communication board/communication module installation method of each GOT. (Sold separately)	SH-4005 (1DM099)
A950GOT/A951GOT/A953GOT/A956GOT User's Manual Provides performance specification, setting method, and communication board/communication module installation method of each GOT. (Sold separately)	SH-080018 (1DM103)
GOT-A900 Series User's Manual (GT Designer2 Version2 compatible Connection System Manual) Describes the system configuration of which connection method is compatible with GOT-A900 series as well as processing cables. (Sold separately)	SH-080524ENG (1DM219)
GT SoftGOT2 Version1 Operating Manual Describes the system configuration, screen makeup and usage of GT SoftGOT2. (Sold separately)	SH-080400E (1DM210)

ABBREVIATIONS AND GENERIC TERMS IN THIS MANUAL

Abbreviations, generic terms and special terms used in this manual are described as follows:

Abbreviations, generic terms and special terms	Description	
GOT	A985GOT-V	Generic term of A985GOT-TBA-V and A985GOT-TBD-V
	A985GOT	Generic term of A985GOT-TBA, A985GOT-TBD and A985GOT-TBA-EU
	A975GOT	Generic term of A975GOT-TBA-B, A975GOT-TBD-B, A975GOT-TBA, A975GOT-TBD and A975GOT-TBA-EU
	A970GOT	Generic term of A970GOT-TBA-B A970GOT-TBD-B, A970GOT-TBA, A970GOT-TBD, A970GOT-SBA, A970GOT-SBD, A970GOT-LBA, A970GOT-LBD, A970GOT-TBA-EU and A970GOT-SBA-EU
	A97*GOT	Generic term of A975GOT and A970GOT
	A960GOT	Generic term of A960GOT-EBA, A960GOT-EBD and A960GOT-EBA-EU
	A956WGOT	Generic term of A956WGOT-TBD
	A956GOT	Generic term of A956GOT-TBD, A956GOT-SBD, A956GOT-LBD, A956GOT-TBD-M3, A956GOT-SBD-M3, A956GOT-LBD-M3, A956GOT-SBD-B and A956GOT-SBD-M3-B
	A953GOT	Generic term of A953GOT-TBD, A953GOT-SBD, A953GOT-LBD, A953GOT-TBD-M3, A953GOT-SBD-M3, A953GOT-LBD-M3, A953GOT-SBD-B and A953GOT-SBD-M3-B
	A951GOT	Generic term of A951GOT-TBD, A951GOT-SBD, A951GOT-LBD, A951GOT-TBD-M3, A951GOT-SBD-M3, A951GOT-LBD-M3, A951GOT-SBD-B and A951GOT-SBD-M3-B
	A951GOT-Q	Generic term of A951GOT-QTBD, A951GOT-QSBD, A951GOT-QLBD, A951GOT-QTBD-M3, A951GOT-QSBD-M3, A951GOT-QLBD-M3, A951GOT-QSBD-B and A951GOT-QSBD-M3-B
	A950GOT	Generic term of A950GOT-TBD, A950GOT-SBD, A950GOT-LBD, A950GOT-TBD-M3, A950GOT-SBD-M3, A950GOT-LBD-M3, A950GOT-SBD-B and A950GOT-SBD-M3-B
	A950 handy GOT	Generic term of A953GOT-SBD-M3-H, A953GOT-LBD-M3-H, A950GOT-SBD-M3-H and A950GOT-LBD-M3-H
	A95*GOT	Generic term of A956GOT, A953GOT, A951GOT, A951GOT-Q, A950GOT and A950 handy GOT
Communication board	Bus connection board	Generic term of A9GT-QBUSS, A9GT-QBUS2S, A9GT-BUSS and A9GT-BUS2S
	Serial communication board	Generic term of A9GT-RS4, A9GT-RS2 and A9GT-RS2T
Communication unit	Bus connection unit	Generic term of A9GT-QBUS2SU, A9GT-BUS2SU, A9GT-BUS2SU, A7GT-BUSS and A7GT-BUS2S
	Data link unit	Generic term of A9GT-QJ71LP23, A9G1-QJ71BR13, A7GT-J71AP23, A7GT-J71AR23 and A7GT-J71AT23B
	Network unit	Generic term of A9GT-QJ71LP23, A9GT-QJ71BR13, A7GT-J71LP23 and A7GT-J71BR13
	CC-Link communication unit	Generic term of A8GT-J61BT13 and A8GT-J61BT15
	Ethernet unit	Generic term of A9GT-J71E71-T
Option	Protection sheet	Abbreviation of A9GT-80PSC, A9GT-70PSC, A9GT-60PSC and A9GT-50PSC type transparent protection sheets
	Backlight	Abbreviation of A9GT-80LTT, A9GT-70LTTB, A9GT-70LTT, A9GT-70LTS, A9GT-70LTTBW and A9GT-50LT type backlights
	Debug stand	Abbreviation of A9GT-80STAND, A9GT-70STAND and A9GT-50STAND type debug stand
	Memory card	Flash PC card/Commercially available flash PC card/SRAM type PC card
	Flash PC card	Generic term of A9GTMEM-10MF, A9GTMEM-20MF and A9GTMEM-40MF
	Compact flash PC card	Commercially available flash PC card
	Memory board	Abbreviation of A9GT-FNB, A9GT-FNB1M, A9GT-FNB2M, A9GT-FNB4M, A9GT-FNB8M, A9GT-QFNB, A9GT-QFNB4M, A9GT-QFNB8M type option function memory board
	Attachment	Generic term of A77GT-96ATT/A85GT-95ATT/A87GT-96ATT/A87GT-97ATT attachments
	Ten-key Panel	Abbreviation of A8GT-TK ten-key Panel
	A7GT-CNB	Abbreviation of A7GT-CNB bus connector conversion box
A9GT-QCNB	Abbreviation of A9GT-QCNB bus connector conversion box	
Option unit	External I/O module	Abbreviation of A9GT-70KBF and A8GT-50KBF type external I/O interface module
	Printer interface module	Abbreviation of A9GT-50PRF type printer interface module
	Memory card interface module	Abbreviation of A1SD59J-MIF memory card interface module
	Video/RGB mixed input interface module	Abbreviation of A9GT-80V4R1 type Video/RGB mixed input interface module
	Video input interface module	Abbreviation of A9GT-80V4 type Video input interface module
	RGB input interface module	Abbreviation of A9GT-80R1 type RGB input interface module
Software	GT Designer2 Version2	Generic term of SW2D5C-GTD2-E software
	GT Designer	Abbreviation of image creation software GT Designer for GOT900
	GT Converter2	Abbreviation of data conversion software GT Converter for GOT900
	GT SoftGOT2	Abbreviation of GT SoftGOT2 monitoring software
	GX Developer	Generic term of SW□D5C-GPPW-E/SW□D5F-GPPW-E software packages
	GX Simulator	Generic term of SW□D5C-LLT-E ladder logic test tool function software packages (SW5D5C-LLT-E or later)

Abbreviations, generic terms and special terms		Description
CPU	QCPU (Q Mode)	Generic term of Q00JCPU, Q00CPU, Q01CPU, Q02CPU, Q02HCPU, Q06HCPU, Q12HCPU, Q25HCPU, Q12PHCPU, Q25PHCPU, Q12PRHCPU and Q25PRHCPU CPU
	QCPU (A Mode)	Generic term of Q02CPU-A, Q02HCPU-A and Q06HCPU-A CPU
	Remote I/O station	Network module for MELSECNET/H network system remote I/O station (QJ72LP25-25, QJ72LP25G, QJ72BR15)
	QCPU	Generic term of QCPU (Q Mode), QCPU (A Mode) and Remote I/O station
	QnACPU Type	Generic term of Q2ACPU, Q2ACPU-S1, Q2AHCPU, Q2AHCPU-S1, Q3ACPU, Q4ACPU and Q4ARCPU CPU
	QnASCPU Type	Generic term of Q2ASCPU, Q2ASCPU-S1, Q2ASHCPU and Q2ASHCPU-S1 CPU
	QnACPU	Generic term of QnACPU Type and QnASCPU Type
	AnUCPU	Generic term of A2UCPU, A2UCPU-S1, A3UCPU and A4UCPU CPU
	AnACPU	Generic term of A2ACPU, A2ACPU-S1 and A3ACPU CPU
	AnNCPU	Generic term of A1NCPU, A2NCPU, A2NCPU-S1 and A3NCPU CPU
	AnCPU Type	Generic term of AnUCPU, AnACPU and AnNCPU CPU
	AnUS(H)CPU	Generic term of A2USCPU, A2USCPU-S1 and A2USHCPU-S1 CPU
	AnS(H)CPU	Generic term of A1SCPU, A1SCPUC24-R2, A2SCPU, A2SCPU-S1, A1SHCPU, A2SHCPU and A2SHCPU-S1 CPU
	A1SJ(H)CPU	Generic term of A1SJCPU, A1SJCPU-S3 and A1SJHCPU CPU
	AnSCPU Type	Generic term of A2US(H)CPU, AnS(H)CPU and A1SJ(H)CPU CPU
	ACPU	Generic term of AnCPU Type, AnSCPU Type, A1FXCPU, A0J2HCPU, A2CCPU, A2CCPU24 and A2CJCPU CPU
	FXCPU	Generic term of FX ₀ series, FX _{0N} series, FX _{0S} series, FX ₁ series, FX _{1N} series, FX _{1S} series, FX ₂ series, FX _{2C} series, FX _{2N} series, FX _{1NC} series and FX _{2NC} series CPU
Motion controller CPU	Generic term of A273UCPU, A273UHCPU, A273UHCPU-S3, A373UCPU, A373UCPU-S3, A171SCPU, A171SCPU-S3, A171SCPU-S3N, A171SHCPU, A171SHCPUN, A172SHCPU, A172SHCPUN, A173UHCPU, A173UHCPU-S1, Q172CPUN, Q173CPUN, Q172CPUN and Q173CPUN CPU	
FA controller	Generic term of LM610, LM7600, LM8000 CPU	
Peripheral connection module	G4	Abbreviation of AJ65BT-G4-S3
Ethernet module	E71	Generic of AJ71E71-S3, AJ71E71N-B2, AJ71E71N-B5, AJ71E71N-T, AJ71E71N-B5T, A1SJ71E71-B2-S3, A1SJ71E71-B5-S3, A1SJ71E71N-B2, A1SJ71E71N-B5, A1SJ71E71N-T and A1SJ71E71N-B5T
	QE71	Generic of AJ71QE71, AJ71QE71-B5, AJ71QE71N-B2, AJ71QE71N-B5, AJ71QE71N-T, AJ71QE71N-B5T, A1SJ71QE71-B2, A1SJ71QE71-B5, A1SJ71QE71N-B2, A1SJ71QE71N-B5, A1SJ71QE71N-T and A1SJ71QE71N-B5T
	Q series-compatible E71	Generic of QJ71E71, QJ71E71-B2, QJ71E71-B5 and QJ71E71-100
Other PLC	Omron PLC	Generic term of C200HS, C200H, C200H α series(C200HX, C200HG, C200HE), CQM1, C1000H, C2000H, CV500, CV1000, CV2000, CVM1-CPU11, CVM1-CPU21, CS1, CS1D, CJ1M, CPM1, CPM1A, CPM2A, CPM2C CPU, CQM1H
	Yasukawa PLC	Generic term of GL60S, GL60H, GL70H, GL120, GL130, CP-9200SH, CP-9300MS, MP-920, MP-930, MP-940, CP-9200(H) and PROGIC-8 CPU
	SLC500 Series	Generic term of SLC500-20, SLC500-30, SLC500-40, SLC5/01 SLC5/02, SLC5/03, SLC5/04 SLC5/05
	MicroLogix1000 Series	Generic term of 1761-L10BWA, 1761-L10BWB, 1761-L16AWA, 1761-L16BWA, 1761-L16BWB, 1761-L16BBB, 1761-L32AWA, 1761-L32BWA, 1761-L32BWB, 1761-L32BBB, 1761-L32AAA, 1761-L20AWA-5A, 1761-L20BWA-5A, 1761-L20BWB-5A
	MicroLogix1500 Series	Abbreviation of 1764-LSP
	Allen-Bradley PLC	Generic term of SLC 500 Series, MicroLogix1000 Series, MicroLogix1500 Series
	Sharp PLC	Generic term of JW-21CU, JW-22CU, JW-31CUH, JW-32CUH, JW-33CUH, JW-50CUH, JW-70CUH, JW-100CUH, JW-100CU, Z-512J CPU
	PROSEC T Series	Generic term of T2(PU224 type), T2E, T2N, T3, T3H CPU
	PROSEC V Series	Abbreviation of Model3000(S3) CPU
	Toshiba PLC	Generic term of PROSEC T Series and PROSEC V Series
	SIEMENS PLC	Generic term of SIMATIC S7-300 Series and SIMATIC S7-400 Series CPU
	Large type H series	Generic term of H-302(CPU2-03H), H-702(CPU2-07H), H-1002(CPU2-10H), H-2002(CPU2-20H), H-4010(CPU3-40H), J-300(C0PU-03Ha), H-700(CPU-07Ha), H-2000(CPU-20Ha)
	H200 to 252 Series	Generic term of H-200(CPU-02H, CPE-02H), H-250(CPU21-02H), H-252(CPU22-02H), H-252B(CPU22-02HB), H-252C(CPU22-02HC, CPE22-02HC)
	H Series board type	Generic term of H-20DR, H-28DR, H-40DR, H-64DR, H-20DT, H-28DT, H-40DT, H-64DT, HL-40DR, HL-64DR
	EH-150 Series	Generic term of EH-CPU104, EH-CPU208, EH-CPU308, EH-CPU316
	HITACHI PLC (HIDIC H Series)	Generic term of large type H series, H-200 to 252 Series H Series board type, EH-150 Series
	Matsushita Electric Works PLC	Generic term of FP0-C16CT, FP0-C32CT, FP1-C24C, FP1-C40C, FP2, FP2SH, FP3, FP5, FP10(S), FP10SH, FP-M(C20TC) and FP-M(C32TC)
Others	Memory	abbreviation of memory (flash memory) in the GOT
	OS	Abbreviation of GOT system software
	Object	Setting data for dynamic image
	Personal Computer	Personal computer where the corresponding software package is installed
	Servo amplifier	Generic term of the MR-J2S-□A, MR-J2S-□CP and MR-J2M A series
MELDAS C6/C64	Generic term of the FCA C6, FCA C64	

* In this manual, the following products are called by new names.

Old Name	New Name	Remarks
GPPW	GX Developer	Generic term of SW□D5C-GPPW-E/SW□D5F-GPPW-E software packages

1 OVERVIEW

This manual that can be used on a GOT with an operating system installed. These functions include the utility function, ladder monitor function, system monitor function, special module monitor function, network monitor function, list editor function, motion monitor function, servo amplifier monitor function and CNC monitor function.



Note that some functions cannot be performed depending on the used GOT and the target CPU/connection form.

Refer to Chapter 2 for more information on the functions available for each GOT and the restrictions on the functions per target CPU and connection form.

1.1 Features

The monitor functions described in this manual are intended to improve the efficiency of trouble-shooting and maintenance operations for the PLC system.

The features of each monitor function are explained in the following sections.


1.1.1 Features of the utility function

The utility function enables you to use GOT setup and self-tests. To use the utility function, you need to install an operating system for the utility function on the GOT built-in internal memory by using GT Designer2. The features of the utility function are shown below.




Some of the utility functions cannot be used with GT SoftGOT2. Refer to the GT SoftGOT2 Version1 Operating Manual for the utility functions available for GT SoftGOT2.

- (1) The brightness of a monitor screen can be adjusted (see Section 4.3 for details).




- (2) The screen and OS data can be copied between the internal memory and memory card (see Section 4.4 for details).



The data monitored can be copied to and from the GOT built-in internal memory or a memory card installed on the GOT.


The OS data can only be copied from the GOT to the memory card.

- (3) Setting a use environment of the GOT (see Section 4.5 for details).



You can set the operating environment of the GOT such as the beep sound, message display language and screen saver's idle time. When using the A985GOT, you can also make settings on the Human sensor.

- (4) Running diagnostic checks on GOT hardware (see Section 4.6).




You can run diagnostic checks on the GOT hardware, including the image check, font check, memory card check and so on.

- (5) Other functions (see Section 4.7 for details)
- Displaying data on available space in the GOT internal memory.
 - Adjusting the clock of the PLC CPU.
 - Displaying the display area cleanup screen.
 - Changing security levels.
 - Limiting access to the Utility Menu screen.

1.1.2 Features of the ladder monitor function

Installing the ladder monitor function operating system into the GOT built-in memory using the GT Designer2 enables ladder monitoring of the PLC CPU program as shown in a ladder diagram. The features of the ladder monitor function are shown below.

- (1) Monitoring based on ladder symbols (see Section 6.3 for details)
(Sample display) Ladder monitor screen



Remark

The **Print Screen** and **Cancel Print** buttons are not displayed on the A956WGOT or the GOT whose display screen type is the EL.

1) Ladder monitor screen


A maximum of 8 lines (max. 11 contact points per line; with 12 contact points or more, the line returns) of a sequence program are displayed on one screen. Also, for the current values and other settings of word devices, a maximum of 8 devices are displayed (With 9 devices or more, use the arrow keys to switch displays.).

Remark

Depending on the GOT model, a display is provided on the MELSEC-Q ladder monitor screen as indicated below.

- A985GOT(-V): Max. 15 lines displayed (1 line: Max. 11 contacts)
- A956WGOT: Max. 5 lines displayed (1 line: Max. 7 contacts)

(2) The display format can be changed to show comments for devices (see Section 6.2.2 for details).
(Sample display) Ladder monitor screen



1) Switching the display format

The current values monitor of the word devices at the bottom of the screen are executed in decimal or hexadecimal format.

2) Displaying device comments

Comments of for the device used in the PLC program (comments that are written into the PLC CPU) are displayed.

(3) Monitoring other stations

Other stations in data link systems, network system or CC-Link system, including the GOT (or stations connected to the GOT), can be monitored.

1.1.3 Features of the system monitor function

Installing the screen monitor function operating system into the GOT built-in memory using the GT Designer2 enables monitoring and testing of the buffer memory for the PLC CPU program and the special functions module. The features of the system monitor function are shown below.

- (1) Any desired device can be monitored, using 4 dedicated screens
The system monitor function provides an entry monitor, a batch monitor, and a buffer memory monitor, enabling monitoring of any device, for complete flexibility in any application.

Entry monitor

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No. [0]	STATION[FF]			
D 15	-2147483648	DW		
D 10	-32767			
X 001	●			
M 25	○			
Y 70	●			
W 200	43			
R 50	68378428	DW		
D 300	30000			

- Up to 8 points for a PLC CPU device registered by the user can be monitored in one window (see Section 9.2).

Batch monitor

BATCH MONITOR	TEST	MENU	FORM	SET
NETWK No. [0]	STATION[FF]			
D 10	32767	D 18	-500	
D 11	0	D 19	3234	
D 12	0	D 20	0	
D 13	-1	D 21	0	
D 14	0	D 22	0	
D 15	3	D 23	-32768	
D 16	0	D 24	0	
D 17	0	D 25	0	

- Up to 16 points subsequent to a PLC CPU device specified by the user can be monitored in one window (see Section 9.3).

T/C monitor

TC MONITOR	TEST	MENU	FORM	SET
NETWK No. [0]	STATION[FF]			
T 0 PV	0 SV	0	○	△
[Production line A]				
T 1 PV	0 SV	0	○	
[Production line B]				
T 2 PV	150 SV	150	■ ●	
[Production line C]				
T 3 PV	0 SV	0	○	▽
[Production line D]				


- Up to 8 points, including the current value, set value, contact point, and coil can be monitored in a window subsequent to a PLC CPU timer (T)/counter (C) specified by the user (see Section 9.4).

Buffer memory monitor

BM MONITOR	TEST	MENU	FORM	SET
NETWK No. [0]	STATION[FF]			
I/O NO[1]				
BM 1110	-32767	BM 1118	0	
BM 1111	64	BM 1119	0	
BM 1112	149	BM 1120	150	
BM 1113	-1111	BM 1121	131	
BM 1114	126	BM 1122	-32768	
BM 1115	160	BM 1123	555	
BM 1116	255	BM 1124	2368	
BM 1117	1200	BM 1125	11000	

- Up to 16 points subsequent to the buffer memory of a special function module specified by the user can be monitored in one window (see Section 9.5).

- With the GOT, the full screen can be divided into four windows and separate monitoring carried out in all four windows simultaneously.





(2) Data can be changed by test operation (see Section 9.6 for details).

(Test sample)

When M0 is on

When changing D0 present value





- 1) Test for bit device
Device specified by user is turned on or off.
- 2) Test for word device
Writes designated value into device specified by user.
- 3) Test for timer/counter
Writes in designated value as current value or set values of device specified by user.
- 4) Test for buffer memory
Writes designated value into buffer memory specified by user.

(3) Display format can be changed and device comments can be displayed (see Section 9.1.2 for details).

(Sample display)

For entry monitor
(comment display)

For batch monitor
(hexadecimal display)



- 1) Changing display format
The word device values for the entry monitor, batch monitor, T/C monitor, and the buffer memory monitor are monitored in decimal or hexadecimal format.
- 2) Device comment display
When the PLC CPU device is monitored, the comments written into the PLC CPU are displayed.

(4) Other stations can be monitored.
Other stations in data link systems, network systems or CC-Link systems, including the GOT (or stations connected to the GOT), can be monitored.


1.1.4 Features of the special module monitor function

Installing (or downloading) the special module monitor function operating system and special module monitor data into the GOT built-in memory using the GT Designer2 enables monitoring and changing of data in the special function module buffer memory, using dedicated screens. Signal statuses of I/O modules can also be monitored. The features of the special module monitor function are shown below.

- (1) Monitoring can be done with dedicated screens (see Section 12.2 for details). Monitoring is carried out using dedicated screens provided by the manufacturer for the special function module and I/O module. It is not necessary for the user to create monitor screens.


(Sample display 1: for special function module)

Menu screen after module selection




Monitor screen after menu selection

Menu selection



(Sample display 2: for I/O module)

Monitor screen



1) Menu screen

The menu is displayed classified into monitor items for the special function module only. The object monitor screen is displayed by selecting the item from the menu.

2) Monitor screen

With the special function module, the buffer memory contents and the status of the PLC CPU I/O signals are monitored using text, numbers, and graphs.


With the I/O module, the status of I/O signals to and from an external module is monitored.

(2) Data can be changed by writing (see Section 12.1.5 for details).

(Writing example)

Monitor screen

When changing channel that can be changed



- 1) The designated values are written into the user-specified buffer memory by writing the values from the monitor.
- 2) When changing the buffer memory data, input the numeric value using the auto display key window and write it into the buffer memory.

(3) Special module monitor data can be allocated as user monitor screen data.

The special module monitor data installed in the computer can be allocated to serve as user monitor screen data. To do this, the steps below are required.

- 1) Using the Copy function, allocate special module monitor data from another project as user monitor screen data.
- 2) Correct the data to match the system used for the BM initial buffer memory number of the Object function which has been set.


1.1.5 Features of the network monitor function

To use the network monitor function, you first must install an operating system (OS) for the network monitor function on your GOT by using GT Designer2. This enables you to monitor the status of the MELSECNET/B, MELSECNET (II), and MELSECNET/10 networks. The following describes the features of the network monitor function.

- (1) Network monitor screens are selectable on the own station monitor screen to monitor the own station and other stations on a network.

The own station monitor screen enables you to monitor the status of all the network lines connected to the own station.

A touch of the screen will guide you through various monitor screens to monitor the status of the own station and other stations on a network.




- (2) Network information can be obtained from the own station monitor screen.

Dedicated monitor screens are available for each category of station classification, depending on the role that is played by the own station.


Network category: MELSECNET/B, MELSECNET (II) master station
MELSECNET/B, MELSECNET (II) local station
MELSECNET/10, MELSECNET/H control station/ordinary station
MELSECNET/10, MELSECNET/H remote master station

(Sample display) MELSECNET/B, MELSECNET (II) master station




- (3) The status of other stations can be monitored on the other-station monitor screen. The other-station monitor screen provides the following type of information on the status of other stations connected on a network:
- Communications status of each station
 - Data link status of each station
 - Parameters status of each station
 - CPU action status of each station
 - CPU RUN status of each station
 - Loop status of each station

(Sample display) Other station monitor menu screen



Other station's communications status monitor screen



1.1.6 Features of the List editor function

Installation of the List editor function OS into the memory with the GT Designer2 allows for list edit of the sequence program in the ACPU.


The following shows features of the List editor function.

- (1) Easy parameters and sequence program maintenance
Simple key operations allow checks, partial modifications, changes and additions of the parameters and the sequence program in the PLC CPU.
Without peripheral equipment other than the GOT, the sequence program can be simply edited.

Example of command change in the sequence program

```
LD X0      Change → LD X0
OUT Y20    → MOV D0 D1
LD X1      LD X1
```

- (2) Interlock with the ladder monitor function (only when A985/97*/960GOT is used)
The list edit window can be started from the ladder monitor screen with a single touch. The list can be edited while viewing the ladder.
The list can also be displayed from the step line displayed on the ladder monitor.



- (3) The list edit screen can be recorded.
The hard copy function allows recording the edit screen of the list program.
- (4) Access to other station is available.
The sequence program of the PLC CPU in other station can be list edited.
- (5) Useful help functions
Help functions for read, write, insert and delete are available on the interactive menu selection system. Simple operation is facilitated.
- (6) Comment for each device can be displayed.
Comment of the device at the cursor position can be displayed.

```
W 9 OUT M50
^ 10 MOV
10▶ D1
   Current value
```

← Comment of D1 is displayed.

1.1.7 Features of the motion monitor function

Installation of the motion monitor function OS or downloading of motion monitor data into the built-in memory of the GOT using GT Designer2 enables the servo monitoring and parameter setting of the motion controller CPU (Q172CPU, Q173CPU).

The following are the features of the motion monitor function.

- (1) Various servo monitor data can be displayed on multiple monitor screens (refer to Section 23.3 for details)

The motion monitor function has multiple monitor screens, on which you can monitor servo data in a variety of patterns.

(Display examples)

Present Value Monitor

- Monitors and displays the feed current values and actual current values of all running axes. (Refer to Section 23.3.3)

Error List

M/ H:	D:	Ax	SV P. No.	Err Code	Error Definition	Set Data
7/24				SV P		
10:50			103	906	The unused axis was started.	906
7/24				Maj.	At a start, sv.ampl is OFF, initial processing, the ampl is not yet installed, a sv.err occurred, or the cable is faulty.	
10:50		5	20	1004		
7/24				SV P		
10:50			21	4	Command speed outside the range.	4
7/24				SV P		
10:50			22	906	The unused axis was started.	906
7/24				SV P		
10:50			103	906	The unused axis was started.	906
7/24				Maj.	At a start, sv.ampl is OFF, initial processing, the ampl is not yet installed, a sv.err occurred, or the cable is faulty.	
10:51		5	20	1004		
7/24				SV P		
10:51			21	4	Command speed outside the range.	4
7/24				SV P		
10:51			22	906	The unused axis was started.	906

- Displays the history of errors that occurred on and after the leading edge of PLC ready (M2000). (Refer to Section 23.3.3)

Positioning Monitor

Data Item	1Ax	MON Val	Status	CMD Signal
Feed PV		359054	PLS	POS Start/Completion
Actual PV		358127	PLS	POS Completion
Dvt.Counter		927	PLS	In-Position
EXE_Prog No.		4		Command In-Position
Min/Major SV ERR	0	0	0	Speed Controlling
M Code T Limit	0	300		Speed/POS CHG Latch

- Monitors the details of the positioning data set to any axis. (Refer to Section 23.3.5)


Error List Designated-Axis

1Ax	Err Code	Error Definition
Min.ERR	204	PC ready/M2000 turned from OFF to ON again during deceleration made by PC ready/M2000 OFF.
Maj.ERR	0	
SV ERR	0	
Program No. [0]	0	
R/V CHG ERR Info(H)	0000	
PC Link COM ERR	0	
Motion CPU WDT ERR	0	
MAN-PLS Axis ERR	Each 1-Pulse IM Error	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32
	MAN-PLS Ax ERR	1 2 3
	Each MAN-PLS SM ERR	1 2 3
Test REQ ERR	Op. Axis No. By Test Mode Req.	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32


- Displays the latest errors that occurred on the specified axis. (Refer to Section 23.3.4)

- (2) Servo parameters can be set by write operation (refer to Section 23.4 for details)
 (Write example: Making the auto tuning function invalid)

Parameter setting screen




Parameter setting window appears



Change auto tuning from "1" to "2"
 (No Auto).

Parameter setting screen



Parameter setting is
 changed.

- 1) By performing write operation from the parameter setting screen, write the servo parameter setting (basic parameters/adjustment parameters) to the motion controller CPU.
- 2) When changing any servo parameter setting, enter the necessary numeral or option number from the automatically displayed key window to change the servo parameter setting, and write it to the motion controller CPU.

1.1.8 Features of the servo amplifier monitor functions

You can perform various monitor functions, parameter setting changes, test operations and others for the servo amplifier connected to the GOT.

The features of the servo amplifier monitor functions are described below.

- (1) Servo amplifier status is displayed in real time
(detailed description: Section 26.4, Section 26.5)

The status and alarm definition of the servo amplifier connected to the GOT can be listed in real time.

(Display example: A975GOT)

Monitor

MR-J2S-A 9600 bps Servo amp.Monitor [0St]		Menu	End
Cumulative feedback pulses	0 pulse	Peak load ratio	0 %
Servo motor speed	0 r/min	Instantaneous torque	0 %
Droop pulses	0 pulse	Within one-revolution position	37812 pulse
Cumulative command pulses	0 pulse	ABS counter	20493 rev
Command pulse frequency	0 kpps	Load inertia moment ratio	3.3 times
Analog speed command voltage	0.00 V	Bus voltage	270 V
Analog torque command voltage	0.06 V		
Regenerative load ratio	0 %		
Effective load ratio	0 %		
Clear			
Print Screen		Cancel Print	

- Lists the monitor data of the servo amplifier.
(Refer to Section 26.4.1.)

Alarm display

MR-J2S-A 9600 bps Servo amp.Monitor [0St]		Menu	End
Alarm Number	No alarm		
Alarm Name			
Time of Alarm			
Cause of Alarm			
Reset			
AlarmHist			
Print Screen		Cancel Print	

- Displays the definition (number, name, occurrence time, occurrence factor) of the alarm currently occurring in the servo amplifier. It also allows the alarm to be reset. (Refer to Section 26.4.2.)

- (2) Various diagnostics can be run on the servo amplifier
(detailed description: Section 26.4.1)

There are multiple diagnostic functions to run various diagnostics on the connected servo amplifier.
(Display example)

DI/DO display

MR-J2M-A 19200bps Servo amp. Monitor [00Station]		Menu	End
:ON :OFF			
Input Signal		Output Signal	
CN1A-4	CN1A-36 CN1B-32 CN5-7 CN5-19	CN1A-3	CN1A-27 CN1A-23
CN1A-5	CN1A-37 CN1B-34 CN5-10 CN5-20	CN1A-6	CN1B-27 CN1A-22
CN1A-7	CN1B-4 CN1B-36 CN5-11	CN1A-8	CN1A-25 CN1B-25
CN1A-9	CN1B-5 CN1B-37 CN5-12	CN1A-11	CN1A-24 CN1B-24
CN1A-10	CN1B-7 CN5-1 CN5-13	CN1A-28	CN1B-8 CN1B-23
CN1A-12	CN1B-9 CN5-2 CN5-14	CN1A-30	CN1B-11 CN1B-22
CN1A-29	CN1B-10 CN5-3 CN5-15	CN1A-33	CN1B-28
CN1A-31	CN1B-12 CN5-4 CN5-16	CN1A-35	CN1B-30
CN1A-32	CN1B-29 CN5-5 CN5-17	CN1B-3	CN1B-33
CN1A-34	CN1B-31 CN5-6 CN5-18	CN1B-6	CN1B-35
DO1			
Func.Dev		ABSdata UnitCompo	
Print Screen		Cancel Print	


- Lists the ON/OFF states of the external I/O signals of the servo amplifier. (Refer to Section 26.6.1.)

Amplifier information display

MR-J2S-A 9600 bps Servo amp.Monitor [0St]		Menu	End
Amplifier Firmware Version	BCD-B26W000 B0		
Motor model	HC-PQ053/MF(S)053		
Motor ID	02F05300		
Encoder resolution	131072 pulse/rev		
DI/DO ABSdata			
Print Screen		Cancel Print	


- Displays the software number of the servo amplifier and the information (model, ID, encoder resolution) of the servo motor. (Refer to Section 26.6.3.)

- (3) Servo parameters can be written (detailed description: Section 26.7)
The parameter values of the servo amplifier can be read, changed and written to the servo amplifier.




- (4) Various test operations can be performed (detailed description: Section 26.8)
Various test operations can be performed for the connected servo amplifier.
(Display example)

JOG operation



- While the Forward/Reverse key is touched, the servo amplifier runs. (Refer to Section 26.8.3.)

Motorless operation




- Simulates the operation of the servo motor in the servo amplifier if the servo motor is not connected. (Refer to Section 26.8.5.)

1.1.9 Features of the CNC monitor functions

Functions equivalent to the MELDAS dedicated display are available for the MELDAS connected with the GOT, such as Position Display Monitor, Alarm Diagnosis Monitor, Tool Offset/Param, Program Monitor and F0 function.
(detailed description: Section 29.2)


Position Display Monitor




Alarm Diagnosis Monitor



Tool Offset/Param



Program Monitor



F0 function



1.1.10 Features of the font change function

This function changes the font displayed on the GOT monitor screen, utility and extended function. (Details: Chapter 31)

Standard font



Chinese (simplified characters) font



1.1.11 Features of the system dialog language switching function

This function switches the language for a system dialog displayed on the GOT monitor screen. (Details: Chapter 32)

For the system dialog language switching function, extended function OS is not required to be installed in the GOT.



- (1) The language switching is available for the following system dialogs.
 - 1) System dialog displayed when using a monitor function
 - 2) System dialog displayed when starting an extended function and the required extended function OS is not installed

- (2) When using Chinese (simplified characters) as system dialog language, it is recommended to set Chinese (simplified characters) font for the character font with the font change function.

2 BEFORE BEGINNING OPERATION

The required equipment for using the monitor functions in this manual is described in this section.

2.1 Before getting started with various functions

When using functions described in this manual, install the OS for each function into the GOT using GT Designer2.

To install an OS for your desired function on your GOT, see GT Designer2 Version2 Operating Manual.

2.2 Precautions before use

- (1) The usable functions change depending on the GOT.

Some functions require the memory board or compatible GOT depending on the model.

The following table indicates the functions available for the GOTs and whether or not the memory board or compatible GOT is required.

○ : Required, ---: Not required, × : No function

Model	A985GOT(-V)	A97*GOT	A960GOT	A956WGOT	A95*GOT	GT SoftGOT2
Required device	Memory board				--- M3 type GOT (A95*GOT-*BD-M3)	None
Utility function	---	---	---	---	---	---
System monitor function	---	---	---	---	---	× *4
Ladder monitor function	○	○	○	○ *2	×	×
Special module monitor function	○	○	○	×	×	×
Network monitor function	○	○	○	○	○	×
List editor function	○	○	○	○	○	×
Motion monitor function	○	○	○	○	○ *3	×
Servo amplifier monitor function	○	○	○	○	○	×
CNC monitor function	○	×	×	×	×	×
Font change function	○ *5	○ *5	○ *5	○ *5	×	×
System dialog language switching function	---	---	---	---	---	×

*1 The table below shows the models of memory boards available for using the option functions.

To use the ladder monitor function requires the memory board compatible with the PLC CPU to be monitored.

Name	Model	Contents
Memory board for option functions	A9GT-FNB	For option function (applicable for MELSEC-A/FX ladder monitor)
	A9GT-QFNB	For option function (applicable for MELSEC-Q/QnA/A/FX ladder monitor)
Expanded memory board for option functions	A9GT-FNB1M	Option function (applicable for MELSEC-A/FX ladder monitor) + internal memory extension 1MB
	A9GT-FNB2M	Option function (applicable for MELSEC-A/FX ladder monitor) + internal memory extension 2MB
	A9GT-FNB4M	Option function (applicable for MELSEC-A/FX ladder monitor) + internal memory extension 4MB
	A9GT-FNB8M	Option function (applicable for MELSEC-A/FX ladder monitor) + internal memory extension 8MB
	A9GT-QFNB4M	Option function (applicable for MELSEC-Q/QnA/A/FX ladder monitor) + internal memory extension 4MB
	A9GT-QFNB8M	Option function (applicable for MELSEC-Q/QnA/A/FX ladder monitor) + internal memory extension 8MB

*2 Only MELSEC-Q ladder monitor may be used.

*3 Unusable for Present Value History Monitor.

*4 Use of the dedicated software allows the equivalent function to be performed.

*5 Use the A9GT-QFNB(□M). (The A9GT-FNB(□M) does not support the font change function.)

*6 When using the font change function, a memory card (4M bytes or more) is required.

(2) Note that some functions are unavailable depending on the connection target CPU and connection form. There are the following restrictions on each function depending on the connection target CPU and connection form.

Refer to Chapter 2 of the GOT-A900 Series User's Manual (Connection System Manual) for the connectable CPU names and the access range for monitoring per connection form.

(a) Connection with QCPU (Q mode)

BT13 : Indicates that the A8GT-J61BT13 is used (intelligent device station).

BT15 : Indicates that the A8GT-J61BT15 is used (remote device station).

G4 : Indicates that the A9GT-RS4 or A9GT-50WRS4 is used (via G4).

○ : Usable △ : Partly restricted × : Unusable

Functions	Ref. Section	QCPU(Q Mode)												
		Bus connection	CPU direct connection	Computer link connection	Ether-net connection	MELSEC NET connection			CC-Link connection					
						H	10	B, II	BT13	BT15	G4			
Utility function	Ch. 4		○		○	×	△ ^{*1}	×	○	△ ^{*2}	○			
Ladder monitor function	Ladder monitor	Sequence program monitoring using ladder signals	Section 6.3.1		○		○	×	△ ^{*10}	×	△ ^{*6}	×	○	
	Display switching	Decimal and hexadecimal display of word device values Device comment display	Section 6.3.3		○		○	×	△ ^{*10}	×	△ ^{*6}	×	○	
	Device changing	Changing of device values	Section 6.3.5		○		○	×	△ ^{*10}	×	△ ^{*6}	×	○	
	Print out	Printing of ladder	Section 6.3.6		○		○	×	△ ^{*10}	×	△ ^{*6}	×	○	
System monitor function	Entry monitor	Monitoring of current values by pre-registering monitor devices	Section 9.2		○		○	×	△ ^{*10}	×	○	△ ^{*3}	○	
	Batch monitor	Monitoring of n points of current values subsequent to specified device	Section 9.3		○		○	×	△ ^{*10}	×	○	△ ^{*3}	○	
	T/C monitor	Monitoring of m points of current values, set values, contact points, and coils subsequent to specified device	Section 9.4		△ ^{*9}		○	×	△ ^{*10}	×	△ ^{*4}	×	○	
	BM monitor	Monitoring of x points of current values subsequent to specified buffer memory of specified special module	Section 9.5		△ ^{*9}		○	×	△ ^{*10}	×	○	×	○	
	Data editing using test operation	Setting/resetting of bit device		Section 9.6		○		○	×	△ ^{*10}	×	○	×	○
		Changing of current value for buffer memory of word device				○	△ ^{*5}	○	×	△ ^{*10}	×	○	×	○
		Changing of current value for T/C (can be used while monitoring T/C)				○		○	×	△ ^{*10}	×	○	×	○
		Changing of set value for T/C (can be used while monitoring T/C)				○		○	×	△ ^{*10}	×	△ ^{*6}	×	○
Quick test	Changing of device values using quick test	Section 9.6.2		○		○	×	△ ^{*10}	×		○			
Display switching	Device comment display		Section 9.1.2		○		○	×	△ ^{*10}	×	△ ^{*6}	×	○	
	Decimal and hexadecimal display of word device values and buffer memory values				○		○	×	△ ^{*10}	×		○		
Special module monitor function	Monitoring of buffer memory of special module on special screen		Ch. 11		○		△ ^{*11}	×	△ ^{*10*11}	×	△ ^{*11}	×	△ ^{*11}	
Network monitor function	Monitoring of network status of MELSECNET/B, (II) or /10		Ch. 15		○		○	×	△ ^{*11}	×	○	×	○	
List editor function	Sequence program in the ACPU is list edited		Ch. 19					×						
Motion monitor function	Servo monitor	Monitoring of servo-related items, such as current values and positioning errors, on various monitor screens	Ch. 22		△ ^{*8}					×				
	Parameter setting	Changing of servo parameter values												
Servo amplifier monitor function	Servo amplifier monitor, servo parameter setting change, test operation		Ch. 25	Can be used independently of the connection form since the RS-232C interface of the GOT is used. (Refer to Section 3.7.3 for the precautions on the servo amplifier monitor function.)										
CNC monitor function	Monitor and parameter change of MELDAS C6/C64		Ch. 28	×										
Font change function	Changing the font displayed on GOT		Ch. 31	Can be used independently of the connection form.										
System dialog language switching function	Changing the language displayed on GOT system dialogs		Ch. 32	Can be used independently of the connection form.										

*1 Clock setting cannot be used when the A7GT-J71LP23 or A7GT-J71BR13 is used, and the GOT is connected to the Q00JCPU, Q00CPU or Q01CPU.

*2 Clock setting cannot be used when the A8GT-J61BT15 is used (remote device station).

*3 When the A8GT-J61BT15 is used (in the remote device station), only the link devices assigned to the GOT can be monitored.

*4 The T/C set values cannot be monitored if the software version of the A8GT-J61BT13 used is version W or earlier.

*5 Cannot change V or Z current values.

- *6 Cannot be monitored if the software version of the A8GT-J61BT13 used is version W or earlier.
- *7 If you modified the set value for T/C using the ladder monitor test function, you need to repeat the PC readout procedure to enable the display of the modification.
- *8 The target CPUs of the motion monitor function are only the Q172CPU and Q173CPU.
- *9 Cannot be monitored when the Q172CPU or Q173CPU is monitored.
- *10 The following conditions must be satisfied to perform monitoring when connected to MELSECNET/10.
 - (1) GOT
 - Communication unit: A9GT-QJ71LP23, A9GT-QJ71BR13
 - Communication driver: MNET/10 (A/QnA/Q)
 - (2) QCPU or network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, QJ71LP21G, QJ71BR11) to be monitored
 - The function version should be version B or later.
- *11 Q12PRHCPU and Q25PRHCPU cannot be monitored.

(b) Connection with QnACPU

BT13 : Indicates that the A8GT-J61BT13 is used (intelligent device station)

BT15 : Indicates that the A8GT-J61BT15 is used (remote device station).

G4 : Indicates that the A9GT-RS4 or A9GT-50WRS4 is used (via G4).

○ : Usable △ : Partly restricted × : Unusable

Functions			Ref. Section	QnACPU									
				Bus connection	CPU direct connection	Computer link connection	Ethernet connection	MELSEC NET connection			CC-Link connection		
								H	10	B, II	BT13	BT15	G4
Utility function			Ch. 4	○						△ *1	○		
Ladder monitor function	Ladder monitor	Sequence program monitoring using ladder signals	Section 6.3.1										
	Display switching	Decimal and hexadecimal display of word device values	Section 6.3.3	○		○	×	△ *6	×	○	×	○	
		Device comment display											
	Device changing	Changing of device values	Section 6.3.5	○		○	×	△ *6	×	○	×	○	
Print out	Printing of ladder	Section 6.3.6											
System monitor function	Entry monitor	Monitoring of current values by pre-registering monitor devices	Section 9.2	○		○	×	△ *6	×	○	△ *2	○	
	Batch monitor	Monitoring of n points of current values subsequent to specified device	Section 9.3	○		○	×	△ *6	×	○	△ *2	○	
	T/C monitor	Monitoring of m points of current values, set values, contact points, and coils subsequent to specified device	Section 9.4							○		○	
	BM monitor	Monitoring of x points of current values subsequent to specified buffer memory of specified special module	Section 9.5	○		○	×	△ *6	×	○	×	○	
		Setting/resetting of bit device	Section 9.6							○		○	
	Data editing using test operation	Changing of current value for buffer memory of word device		○		△ *4	○	×	△ *6	×	○	×	○
		Changing of current value for T/C (can be used while monitoring T/C)		○		○	×	△ *6	×	○	×	○	
		Changing of set value for T/C (can be used while monitoring T/C)		○		○	×	△ *6	×	○	×	○	
	Quick test	Changing of device values using quick test	Section 9.6.2	○		○	×	△ *6	×	○	○	○	
	Display switching	Device comment display	Section 9.1.2	○		○	×	△ *6	×	○	×	○	
Decimal and hexadecimal display of word device values and buffer memory values		○			○	×	△ *6	×	○	○	○		
Special module monitor function	Monitoring of buffer memory of special module on special screen	Ch. 11	○		○	×	△ *6	×	○	×	○		
Network monitor function	Monitoring of network status of MELSECNET/B, (II) or /10	Ch. 15	○		○	×	△ *6	×	○	×	○		
List editor function	Sequence program in the ACPUCPU is list edited	Ch. 19	×										
Motion monitor function	Servo monitor	Monitoring of servo-related items, such as current values and positioning errors, on various monitor screens	Ch. 22	×									
	Parameter setting	Changing of servo parameter values											
Servo amplifier monitor function	Servo amplifier monitor, servo parameter setting change, test operation	Ch. 25	Can be used independently of the connection form since the RS-232C interface of the GOT is used. (Refer to Section 3.7.3 for the precautions on the servo amplifier monitor function.)										
CNC monitor function	Monitor and parameter change of MELDAS C6/C64	Ch. 28	×										
Font change function	Changing the font displayed on GOT	Ch. 31	Can be used independently of the connection form.										
System dialog language switching function	Changing the language displayed on GOT system dialogs	Ch. 32	Can be used independently of the connection form.										

*1 Clock setting cannot be used when the A8GT-J61BT15 is used (remote device station).

*2 When the A8GT-J61BT15 is used (in the remote device station), only the link devices assigned to the GOT can be monitored.

*3 Cannot monitor T/C set values.

*4 Cannot change V or Z current values.

*5 If you modified the set value for T/C using the ladder monitor test function, you need to repeat the PC readout procedure to enable the display of the modification.

*6 The following conditions must be satisfied to perform monitoring when connected to MELSECNET/10.

(1) GOT

Communication unit: A9GT-QJ71LP23, A9GT-QJ71BR13

Communication driver: MNET/10 (A/QnA/Q)

(2) QCPU or network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, QJ71LP21G, QJ71BR11) to be monitored

The function version should be version B or later.

(c) Connection with ACPUCPU/QCPU (A mode)

BT13 : Indicates that the A8GT-J61BT13 is used (intelligent device station).

BT15 : Indicates that the A8GT-J61BT15 is used (remote device station).

G4 : Indicates that the A9GT-RS4 or A9GT-50WRS4 is used (via G4).

○ : Usable △ : Partly restricted × : Unusable

Functions		Ref. Section	ACPU/QCPU (A mode)										
			Bus connection	CPU direct connection	Computer link connection	Ethernet connection	MELSEC NET connection			CC-Link connection			
							H	10	B, II	BT13	BT15	G4	
Utility function		Ch. 4		○		○	×		○		△ ^{*2}	○	
Ladder monitor function	Ladder monitor	Sequence program monitoring using ladder signals	Section 6.3.1										
	Display switching	Decimal and hexadecimal display of word device values	Section 6.3.3	○		△ ^{*1}	○	×	○	○	×	○	
		Device comment display											
	Device changing	Changing of device values	Section 6.3.5				○	×	○	○	×	○	
Print out	Printing of ladder	Section 6.3.6		○		○	×	○	○	×	○		
System monitor function	Entry monitor	Monitoring of current values by pre-registering monitor devices	Section 9.2		○		○	×	○	○	△ ^{*3}	○	
	Batch monitor	Monitoring of n points of current values subsequent to specified device	Section 9.3		○		○	×	○	○	△ ^{*3}	○	
	T/C monitor	Monitoring of m points of current values, set values, contact points, and coils subsequent to specified device	Section 9.4		○		○	×	○	○	×	○	
	BM monitor	Monitoring of x points of current values subsequent to specified buffer memory of specified special module	Section 9.5		○		○	×	○	○	×	○	
	Data editing using test operation	Setting/resetting of bit device	Section 9.6		○		△ ^{*5}	○	×	○	○	×	○
		Changing of current value for buffer memory of word device					○	×	×	○	×	○	
		Changing of current value for T/C (can be used while monitoring T/C)			○		×	○	×	○	○	×	○
		Changing of set value for T/C (can be used while monitoring T/C)			○		×	○	×	○	○	×	○
	Quick test	Changing of device values using quick test	Section 9.6.2		○		○	×	○	○	○	○	
	Display switching	Device comment display	Section 9.1.2		○		○	×	○	○	○	×	○
Decimal and hexadecimal display of word device values and buffer memory values							○	×	○	○	○	○	
Special module monitor function	Monitoring of buffer memory of special module on special screen	Ch. 11		○		×	○	×	○	○	×	○	
Network monitor function	Monitoring of network status of MELSECNET/B, (II) or /10	Ch. 15		○		△ ^{*7}	○	×	○	○	×	○	
List editor function	Sequence program in the ACPUCPU is list edited	Ch. 19	△ ^{*8}	○		×	○	×	○	○	×	○	
Motion monitor function	Servo monitor	Monitoring of servo-related items, such as current values and positioning errors, on various monitor screens	Ch. 22										
	Parameter setting	Changing of servo parameter values											
Servo amplifier monitor function	Servo amplifier monitor, servo parameter setting change, test operation	Ch. 25	Can be used independently of the connection form since the RS-232C interface of the GOT is used. (Refer to Section 3.7.3 for the precautions on the servo amplifier monitor function.)										
CNC monitor function	Monitor and parameter change of MELDAS C6/C64	Ch. 28							×				
Font change function	Changing the font displayed on GOT	Ch. 31	Can be used independently of the connection form.										
System dialog language switching function	Changing the language displayed on GOT system dialogs	Ch. 32	Can be used independently of the connection form.										

*1 Subprograms 2, 3 of the A4UCPU (for computer link connection) cannot be monitored.

*2 Can be monitored only when the A8GT-J61BT15 is used (in the remote device station).

*3 When the A8GT-J61BT15 is used (in the remote device station), only the link devices assigned to the GOT can be monitored.

*4 Cannot monitor T/C set values.

*5 Cannot change V or Z current values.

*6 If you modified the set value for T/C using the ladder monitor test function, you need to repeat the PC readout procedure to enable the display of the modification.

*7 Monitor is disabled when the connection target CPU is the AnU type (MELSECNET/10 network card is fitted).

*8 If ACPU is performing E²PROM operation when connected to the GOT, program write is disabled.

(d) Connection with FXCPU, third party PLC or microcomputer

○ : Usable △ : Partly restricted × : Unusable

Functions		Ref. Section	FXCPU *5	Other PLC connection	Microcomputer connection	
			CPU direct connection			
Utility function		Ch. 4	△ *1	△ *2	△ *3	
Ladder monitor function	Ladder monitor	Sequence program monitoring using ladder signals	Section 6.3.1			
	Display switching	Decimal and hexadecimal display of word device values	Section 6.3.3	○	×	×
		Device comment display				
	Device changing	Changing of device values	Section 6.3.5			
Print out	Printing of ladder	Section 6.3.6				
System monitor function	Entry monitor	Monitoring of current values by pre-registering monitor devices	Section 9.2	○	×	×
	Batch monitor	Monitoring of n points of current values subsequent to specified device	Section 9.3			
	T/C monitor	Monitoring of m points of current values, set values, contact points, and coils subsequent to specified device	Section 9.4	△ *4	×	×
	BM monitor	Monitoring of x points of current values subsequent to specified buffer memory of specified special module	Section 9.5	×	×	×
	Data editing using test operation	Setting/resetting of bit device	Section 9.6	○	×	×
		Changing of current value for buffer memory of word device				
		Changing of current value for T/C (can be used while monitoring T/C)				
		Changing of set value for T/C (can be used while monitoring T/C)		×	×	×
	Quick test	Changing of device values using quick test	Section 9.6.2	○	×	×
	Display switching	Device comment display	Section 9.1.2	×	×	×
Decimal and hexadecimal display of word device values and buffer memory values		○		×	×	
Special module monitor function	Monitoring of buffer memory of special module on special screen	Ch. 11	×	×	×	
Network monitor function	Monitoring of network status of MELSECNET/B, (II) or /10	Ch. 15	×	×	×	
List editor function	Sequence program in the ACPU is list edited	Ch. 19	×	×	×	
Motion monitor function	Servo monitor	Monitoring of servo-related items, such as current values and positioning errors, on various monitor screens	Ch. 22	×	×	×
	Parameter setting	Changing of servo parameter values				
Servo amplifier monitor function	Servo amplifier monitor, servo parameter setting change, test operation	Ch. 25	Can be used independently of the connection form since the RS-232C interface of the GOT is used. (Refer to Section 3.7.3 for the precautions on the servo amplifier monitor function.)			
CNC monitor function	Monitor and parameter change of MELDAS C6/C64	Ch. 28		×		
Font change function	Changing the font displayed on GOT	Ch. 31	Can be used independently of the connection form.			
System dialog language switching function	Changing the language displayed on GOT system dialogs	Ch. 32	Can be used independently of the connection form.			

*1 Clock setting cannot be made when the GOT is connected with the PLC CPU that does not have the clock function (FX0, FX0N, FX1, FX2NC, FX0S).

The FX2 and FX2C allow clock setting to be made only when the cassette for real-time clock is used.

*2 Clock setting cannot be made when the GOT is connected with the PLC CPU that does not have the clock function.

*3 You can set the clock function only when you are using A9GT-RS2T, which includes a clock element.

*4 T/C set values and coils cannot be monitored.

*5 The FX3UC series can be monitored only in the device range of FX2N series.

(e) Connection with MELDAS C6/C64

BT13 : Indicates that the A8GT-J61BT13 is used (intelligent device station).

BT15 : Indicates that the A8GT-J61BT15 is used (remote device station).

G4 : Indicates that the A9GT-RS4 or A9GT-50WRS4 is used (via G4).

○ : Usable △ : Partly restricted × : Unusable

Functions			Ref. Section	QCPU(Q Mode)									
				Bus connection	CPU direct connection	Computer link connection	Ethernet connection	MELSEC NET connection			CC-Link connection		
								H	10	B, II	BT13	BT15	G4
Utility function			Ch. 4	×	○	×	○	×	×	○	△ ^{*1}	×	
Ladder monitor function	Ladder monitor	Sequence program monitoring using ladder signals	Section 6.3.1	×	○	×	○	×	×	○	×	×	
	Display switching	Decimal and hexadecimal display of word device values	Section 6.3.3	×	○	×	○	×	×	○	×	×	
		Device comment display		×									
	Device changing	Changing of device values	Section 6.3.5	×	○	×	○	×	×	○	×	×	
	Print out	Printing of ladder	Section 6.3.6	×	○	×	○	×	×	○	×	×	
System monitor function	Entry monitor	Monitoring of current values by pre-registering monitor devices	Section 9.2	×	○	×	○	×	×	○	△ ^{*2}	×	
	Batch monitor	Monitoring of n points of current values subsequent to specified device	Section 9.3	×	○	×	○	×	×	○	△ ^{*2}	×	
	T/C monitor	Monitoring of m points of current values, set values, contact points, and coils subsequent to specified device	Section 9.4	×									
	BM monitor	Monitoring of x points of current values subsequent to specified buffer memory of specified special module	Section 9.5	×	○	×	○	×	×	○	×	×	
	Data editing using test operation	Setting/resetting of bit device	Section 9.6	×	○	×	○	×	×	○	×	×	
		Changing of current value for buffer memory of word device		×	○	×	○	×	×	○	×	×	
		Changing of current value for T/C (can be used while monitoring T/C)		×	○	×	○	×	×	○	×	×	
		Changing of set value for T/C (can be used while monitoring T/C)		×									
	Quick test	Changing of device values using quick test	Section 9.6.2	×	○	×	○	×	×	○	○	×	
	Display switching	Device comment display	Section 9.1.2	×	○	×	○	×	×	○	×	×	
Decimal and hexadecimal display of word device values and buffer memory values		×		○	×	○	×	×	○	○	×		
Special module monitor function	Monitoring of buffer memory of special module on special screen	Ch. 11	×										
Network monitor function	Monitoring of network status of MELSECNET/B, (II) or /10	Ch. 15	×										
List editor function	Sequence program in the ACPU is list edited	Ch. 19	×										
Motion monitor function	Servo monitor	Monitoring of servo-related items, such as current values and positioning errors, on various monitor screens	Ch. 22	×									
	Parameter setting	Changing of servo parameter values											
Servo amplifier monitor function	Servo amplifier monitor, servo parameter setting change, test operation	Ch. 25	Can be used independently of the connection form since the RS-232C interface of the GOT is used. (Refer to Section 3.7.3 for the precautions on the servo amplifier monitor function.)										
CNC monitor function	Monitor and parameter change of MELDAS C6/C64	Ch. 28		×		×	△ ^{*3}	×	×		○		
Font change function	Changing the font displayed on GOT	Ch. 31	Can be used independently of the connection form.										
System dialog language switching function	Changing the language displayed on GOT system dialogs	Ch. 32	Can be used independently of the connection form.										

1 OVERVIEW
 2 BEFORE BEGINNING OPERATION
 3 SPECIFICATIONS
 4 OPERATING THE UTILITY FUNCTION
 5 OPERATING LADDER MONITOR
 6 OPERATING THE VARIOUS LADDER MONITOR SCREENS
 7 ERROR MESSAGES FOR LADDER MONITOR
 8 OPERATING SYSTEM MONITOR

*1 Clock setting cannot be used.

*2 Only the link devices assigned to the GOT can be monitored.

*3 The following conditions must be satisfied to perform monitoring when connected to MELSECNET/10.

(1) GOT

Communication unit: A9GT-QJ71LP23, A9GT-QJ71BR13

Communication driver: MNET/10 (A/QnA/Q)

(2) QCPU or network module (QJ71LP21, QJ71LP21-25, QJ71LP21S-25, QJ71LP21G, QJ71BR11) to be monitored

The function version should be version B or later.

(f) Connection with MELSECNET/H system remote I/O station

BT13 : Indicates that the A8GT-J61BT13 is used (intelligent device station).

BT15 : Indicates that the A8GT-J61BT15 is used (remote device station).

G4 : Indicates that the A9GT-RS4 or A9GT-50WRS4 is used (via G4).

○ : Usable △ : Partly restricted × : Unusable

Functions			Ref. Section	MELSECNET/H system remote I/O station												
				Bus connection	CPU direct connection	Computer link connection	Ethernet connection	MELSEC NET connection			CC-Link connection					
								H	10	B, II	BT13	BT15	G4			
Utility function			Ch. 4	×	△ ^{*1}	△ ^{*1}	×	×	×	×	×	×	×	×	×	
Ladder monitor function	Ladder monitor	Sequence program monitoring using ladder signals	Section 6.3.1					×								
	Display switching	Decimal and hexadecimal display of word device values	Section 6.3.3					×								
		Device comment display						×								
	Device changing	Changing of device values	Section 6.3.5					×								
Print out	Printing of ladder	Section 6.3.6					×									
System monitor function	Entry monitor	Monitoring of current values by pre-registering monitor devices	Section 9.2	×	○	○	×	×	×	×	×	×	×	×	×	
	Batch monitor	Monitoring of n points of current values subsequent to specified device	Section 9.3	×	○	○	×	×	×	×	×	×	×	×	×	
	T/C monitor	Monitoring of m points of current values, set values, contact points, and coils subsequent to specified device	Section 9.4	×	○	○	×	×	×	×	×	×	×	×	×	
	BM monitor	Monitoring of x points of current values subsequent to specified buffer memory of specified special module	Section 9.5	×	○	○	×	×	×	×	×	×	×	×	×	
	Data editing using test operation	Setting/resetting of bit device		Section 9.6	×	○	○	×	×	×	×	×	×	×	×	×
		Changing of current value for buffer memory of word device			×	○	△ ^{*2}	×	×	×	×	×	×	×	×	×
		Changing of current value for T/C (can be used while monitoring T/C)			×	○	○	×	×	×	×	×	×	×	×	×
		Changing of set value for T/C (can be used while monitoring T/C)			×	○	○	×	×	×	×	×	×	×	×	×
	Quick test	Changing of device values using quick test	Section 9.6.2	×	○	○	×	×	×	×	×	×	×	×	×	
	Display switching	Device comment display		Section 9.1.2	×	○	○	×	×	×	×	×	×	×	×	×
Decimal and hexadecimal display of word device values and buffer memory values		×	○		○	×	×	×	×	×	×	×	×	×		
Special module monitor function	Monitoring of buffer memory of special module on special screen		Ch. 11					×								
Network monitor function	Monitoring of network status of MELSECNET/B, (II) or /10		Ch. 15					×								
List editor function	Sequence program in the ACPU is list edited		Ch. 19					×								
Motion monitor function	Servo monitor	Monitoring of servo-related items, such as current values and positioning errors, on various monitor screens	Ch. 22					×								
	Parameter setting	Changing of servo parameter values														
Servo amplifier monitor function	Servo amplifier monitor, servo parameter setting change, test operation		Ch. 25	Can be used independently of the connection form since the RS-232C interface of the GOT is used. (Refer to Section 3.7.3 for the precautions on the servo amplifier monitor function.)												
CNC monitor function	Monitor and parameter change of MELDAS C6/C64		Ch. 28					×								
Font change function	Changing the font displayed on GOT		Ch. 31	Can be used independently of the connection form.												
System dialog language switching function	Changing the language displayed on GOT system dialogs		Ch. 32	Can be used independently of the connection form.												

- *1 The clock setting screen is displayed, but the date and time cannot be set. To set the date and time on PLC CPU master station, set the clock using GX Developer.
- *2 Cannot change V or Z current value.

- (3) If a system program (OS) for the expanded or option functions has been installed, the following space is required in the GOT built-in internal memory to store user-created monitor screen data. Hence, add the memory board as required.
- Hence, installing the extended function OS into the GOT decreases the memory space (for monitor screen data storage) available for the user.
- If the free space is insufficient, fit the extension memory board to increase the memory space.

(a) List of extended function and option function OSs installed

Expanded Function OS Name		Space Necessary for Installation in Terms of Memory Count	Remarks
System monitor		1	---
Ladder monitor	MELSEC-A ladder monitor	1	Only one may be installed.
	MELSEC-QnA ladder monitor *1	2	
	MELSEC-Q ladder monitor *1	2	
	MELSEC-FX ladder monitor	1	
Motion monitor *1		2	Only one may be installed
CNC monitor *1		2	
Special module, recipe, sound		1	---
Network monitor		1	---
List editor (MELSEC-A) *1		2	---
Gateway *1		2	---
Servo amplifier Monitor *1		2	---
Others	ESC printer, bar code, report, CSV file, external key input	1	Only one may be installed.
	PCL printer, bar code, report, CSV file, external key input	1	
	ESC printer, bar code, report, CSV file, proximity I/O	1	
	PCL printer, bar code, report, CSV file, proximity I/O	1	
	ESC printer, bar code, report, CSV file, video/RGB input	1	
	PCL printer, bar code, report, CSV file, video/RGB input	1	
	Chinese (Big 5) printer, bar code, report, CSV file, external key input	1	
	Chinese (Big 5) printer, bar code, report, CSV file, proximity I/O	1	
	Chinese (Big 5) printer, bar code, report, CSV file, video/RGB input	1	
	Chinese (GB) printer, bar code, report, CSV file, external key input	1	
	Chinese (GB) printer, bar code, report, CSV file, proximity I/O	1	
	Chinese (GB) printer, bar code, report, CSV file, video/RGB input	1	

*1 When installed into the GOT, this OS uses the memory space twice larger than that of the other extended function OS.

*2 Install the "Other" extended function OSs when using the following functions.

- Report function ▪ Operation panel function ▪ Printer function
- Barcode function ▪ Video display function ▪ RGB display
- External I/O function ▪ When object function is used to create CSV format files

For this extended function OS, refer to the following 1) and 2) and select the OS that meets the language to be output to the printer or CSV file and the optional device used.

1) Language to be output to the printer connected to the GOT or the CSV file (alarm history display function, recipe function)

- ESC printer : Output in Japanese
- PCL printer : Output in English
- Chinese (Big 5) printer : Output in Chinese (traditional language)
- Chinese (GB) printer : Output in Chinese (simplified language)

2) Used optional device

- External key input : Operation panel, ten-key panel (operation panel function)
- Proximity I/O : External I/O device (external I/O function)
- Video/RGB input : Video camera (video display function), personal computer (RGB display function)

(b) Number of extended function OSs installed and free space of GOT's built-in memory

Number of Extended functions OSs	Memory Space Used [k bytes]	Free Space (User area) [k bytes] ^{*1}
0	0	1152
1	256	896
2	384	768
3	640	512
4	768	384
5	1024	128
6	1152	0

*1 Since the A95*GOT-*BD-M3 has the built-in memory of 3200k bytes, the free space is the above value plus 2048k bytes.



Using the special module monitor/motion monitor/servo amplifier monitor function requires the built-in memory to have enough memory space to store the special module monitoring data/motion monitor, servo amplifier monitor screens. (Refer to Section 3.3.3, 3.6.4 and 3.7.5.)

3 SPECIFICATIONS

In this chapter, the specifications of the ladder monitor function, system monitor function, special module monitor function, list editor function, motion monitor function, servo amplifier monitor and CNC monitor are explained separately.

3.1 Ladder monitor function specifications



Refer to Section 2.2 for restrictions on the ladder monitor function.

3.1.1 PLC CPUs to be monitored

The PLC CPUs that allow ladder monitoring are the QCPU, QnACPU, ACPU, FXCPU, motion controller CPU (Except Q172CPU and Q173CPU) and MELDAS C6/C64. For details, refer to Section 2.2 (2).

3.1.2 Access ranges to be monitored

For access range for the ladder monitor function, see GOT-A900 Series User's manual (Connection system manual).



- When the capacity of parameter, PLC program, TC setting value, comment and extension comment is 144 k bytes or more, the comment will not be properly displayed.
- The local device cannot be monitored on the QCPU(Q mode), QnACPU.

3.1.3 Precautions when using the ladder monitor function

- (1) When using the ladder monitor function during monitor of the MELDAS C6/C64, install the MELSEC-QnA ladder monitoring OS into the GOT.
- (2) Changing to the Chinese (simplified characters) font makes the MELSEC-Q/QnA ladder monitor function unusable.
For specifications of the font change function, refer to Section 3.9.

3.2 System monitor function specifications



Refer to Section 2.2 for restrictions on the system monitor function.

3.2.1 PLC CPUs to be monitored

The PLC CPUs that allow system monitoring are the QCPU, QnACPU, ACPUCPU, FXCPU, motion controller CPU and MELDAS C6/C64. For details, refer to Section 2.2 (2).

3.2.2 Access ranges to be monitored

For access range for the system monitor function, see GOT-A900 Series User's manual (Connection System Manual).

3.2.3 Names of devices to be monitored

For the names of devices that can be monitored with the system monitor function, see GT Designer2 Version1 Reference Manual.

3.2.4 Precautions when using the system monitor function

The precautions to follow when using the system monitor function are shown below.

(1) Monitor and test of real number data

Real number data cannot be monitored or tested.


Monitoring of word devices that save real number data is all done by integer data (binary data).

(2) Monitoring in 32-bit modules

When monitoring word devices (such as T, C, D, W) in 32-bit (2-word) modules, monitor up to the point where 32 bits remain in the monitor processing. A location where 16 bits (1 word) remain cannot be monitored.


This situation occurs when an odd number has been specified as the initial number in the monitor device.

Example: When monitoring the A2NCPUCPU data register in 32-bit modules beginning with an odd number (D1, D3...)



- (3) The "Date" column of a Rated Plate shows the date manufactured and function version number. If it reads "9707 B" or a later notation, timer/counter settings can be changed and device comments can be displayed when using any of the large-scale QnACPU or small-scale QnACPU. When changing the timer/counter setup value and performing the device comment display, use the CPU that is described above.

<Viewing the Rated Plate>



- (4) Only the main program may be used to change the timer/counter set values on the AnNCPU, AnACPU and AnUCPU.
- (5) When executing multiple programs with the QCPU (Q mode) and QnACPU, setting values of timer/counter can be changed only to the program (scan execution type program set at the lowest number among them in parameter settings of GX Developer) whose file name is displayed on the TC Monitor screen.
Note that a file to be displayed cannot be changed on the GOT.
Refer to Section 9.4.2 for details.

3.3 Special module monitor function specifications



Refer to Section 2.2 for restrictions on the special unit monitor.

3.3.1 Access ranges to be monitored

- (1) When using bus connection/CPU direct connection/computer link connection
- The special function modules on the bases of the connected station and other stations can be monitored.
 - Special module monitoring for computer link connection is enabled for the systems of the following combinations.

PLC CPU used	Computer link/serial communication module used
QCPU (Q mode) (Except redundant system)	QJ71C24
QCPU (A mode)	A1SJ71UC24
QnACPU	AJ71QC24, A1SJ71QC24
ACPU	AJ71UC24, A1SJ71UC24

*1 For details of module name, refer to GOT-A900 series user's manual (Connection System Manual)

- (2) When using MELSECNET(II) connection/MELSECNET/B connection
- The special function module on the base of the master station can be monitored.(Cannot be monitored when the master station is the QnACPU.)
 - The special function modules on the bases of local stations/remote I/O station cannot be monitored.

- (3) When using MELSECNET/10 connection
- The special function modules on the bases of the control station and normal stations can be monitored.
- When the QCPU (Q mode)/QnACPU is used for the control/normal station, it cannot be monitored depending on the communication unit.

Communication unit	Applicable CPU of the control/normal station
A7GT-J71LP23, A7GT-J71BR13	ACPU, QCPU (A mode)
A9GT-QJ71LP23, A9GT-QJ71BR13	ACPU, QCPU (A mode), QnACPU, QCPU (Q mode)

- The special function module cannot be monitored when it is mounted on the base of remote I/O station.
- (4) When using CC-Link connection (remote device station)
- The special function modules cannot be monitored.
- (5) When using CC-Link connection (intelligent device station / via G4)
- The special function modules on the bases of the master and local stations can be monitored.
 - The special function module cannot be monitored when it is mounted on the base of remote I/O station.
- (6) When using Ethernet connection
- The special function module on the base of the PLC CPU assigned the IP address can be monitored.
(The station assigned in the Ethernet setting of GT Designer2 can be monitored.)

3.3.2 Special function modules to be monitored

The modules for which special function monitoring can be done are only those types shown in Section 3.3.3. Monitoring of special function modules other than those can be done with the system monitor function "BM Monitor".

3.3.3 Memory capacity

The following table indicates memory spaces for special module monitor data. The memory spaces required for storing data into the internal memory of the GOT is the same as the memory spaces required for storing data into the hard disk of a personal computer.

For QCPU(A mode), QnACPU, ACPU		For QCPU(Q mode)	
Stored data	Memory space [k bytes]	Stored data	Memory space [k bytes]
Special module monitor data common information	13.4	Special module monitor data common information	13.4
A61LS	14.5	Q64AD	18.2
AD61	8.14	Q68ADV	
A62DA-S1	6.91	Q68ADI	
A62LS	69.8	Q62DA	12.9
A68AD(S2)	9.97	Q64DA	
A68ADN	15	QD62	16.2
A68RD3	17.8	QD62E	
A68RD4			
A616AD	123	QD62D	313.5
A616DAI	33.5 *3	QD75P	
A616DAV			
A616TD	230	QD75D	473.8
AD70	20.5	QD75M	
AD70D	29.3	Input module	0.0
AD71(S1/S2/S7)	546	Output module	0.0
AD72	562	---	---
A1SD71-S2(S7)			
AD75P1(P2/P3) *1	520 *3	---	---
A1SD75P1(P2/P3) *2			
AJ71PT32-S3	43.5	---	---
AJ71ID1(ID2)-R4	40.5	---	---
A1SJ71ID1(ID2)-R4			
A84AD	20.2	---	---
A1SD61	36.9	---	---
A1S62DA	5.12	---	---
A1S62RD	12.5	---	---
A1S63ADA	16.4	---	---
A1S64AD	12.3	---	---
A1S68AD	9.75	---	---
A1S68DAI	25.8*3	---	---
A1S68DAV			
A1SD70	21.1	---	---
A1SJ71JP132-S3	43.2	---	---
A1S64TCTT/RT-S1	45.7	---	---
Input module	0.0	---	---
Output module	0.0	---	---

*1: The AD75M1(M2/M3) can be monitored within the range of the AD75P1(P2/P3).

*2: The A1SD75M1(M2/M3) can be monitored within the range of the A1SD75P1(P2/P3).

*3: Downloading either data enables both special function modules to be monitored.

3.3.4 Precautions when using the special module monitor function

The precautions to follow when using the special module monitor function are discussed below.

- (1) Special function modules that cannot be monitored
Modules displayed as "special" on the system configuration screen cannot be monitored using the special module monitor function.
To monitor these modules, use the system monitor function "BM Monitor".
- (2) Display when connecting the small building-block type PLC CPU
This precaution pertains to a situation where an expansion base unit for a large building block type of setup is connected to a small building-block type CPU (such as the A1SCPU) in a station connected to the GOT.
In such a case, the special function module on the large expansion base unit is displayed on the system configuration screen with the same model name as that of the small building-block type special function module.
If there is no small building-block type special function module, "special" is displayed and the object module cannot be monitored.

(Example)

[Module Model]	[Model Name Displayed]
AD72	A1SD71
AJ71ID	A1SJ71ID
AJ71PT32-S3	A1SJ71PT32-S3
AD75P	A1SD75P
A68AND [CH1 to CH8]	A1S64AD [CH1 to CH4]
A68RD [CH1 to CH8]	A1S62RD [CH1 to CH4]

- (3) Monitoring restricted special function modules
 - (a) When monitoring the AD71 (S1, S2, S7)
When the slot on front of the AD71 module is an empty slot, monitoring is done in the following way.
 - 1) The AD71 is treated as the AD72, and "AD72" is displayed on the system configuration screen.
In this case, when monitoring the AD71, select the AD72 in the object display position.
 - 2) The monitor screen that is displayed by 1) above is for the AD72.
The number obtained by subtracting 10H from the I/O signal number on the display is the number to be used when installing the AD71 in the 0 slot.
* If you do not want the AD1 to be treated as the AD72, execute "Shift the installation position of AD71 forward" or "In the I/O assignments, assign the empty slot in front of AD71 to the 16 X-Y points."

- (b) When monitoring the A68AD, A68ADN or A68RD used with a small building block type PLC CPU

A special function module installed in a large building block type extension base unit connected to a small building block type PLC CPU (e.g. A1SCPU) is recognized and monitor-processed by the GOT as a small building block type special function module. Hence, there are the following instructions for use of the A68AD, A68ADN and A68RD.

Special function module	Instruction
A68AD	The A68AD cannot be displayed correctly because of the buffer memory map differences between the A68AD and A1S68AD.
A68ADN	Among CH1 to CH8 of the A68ADN, CH5 to CH8 cannot be displayed since the A1S64AD has only CH1 to CH4.
A68RD	Among CH1 to CH8 of the A68RD, CH3 to CH8 cannot be displayed since the A1S62RD has only CH1 and CH2.

The above special function modules can be monitored properly if they are installed in a base unit connected to a large building block type PLC CPU (e.g. AnUCPU)

- (c) When monitoring the A1SD75M, AD75M
 The A1SD75M/AD75M is displayed as A1SD75P/AD75P.
 The A1SD75M/AD75M can be monitored within the monitoring range of the A1SD75P/AD75P.

- (d) When monitoring the A81CPU
 The A81CPU is monitored in the following way.

Item	64 points in first half	64 points in last half
Treatment of A81CPU	Change to module that cannot be monitored.	Change to input module.
System configuration screen	Display "Special X, Y []"	Display "Input 64 X []"
Possibility of monitoring	Not possible	Can be monitored as input.


- (e) When monitoring an I/O composite module
 1) With an I/O composite module for which "Output []" is displayed on the system configuration screen, only the output signal can be monitored.
 For the input signal, monitor X of the PLC CPU device with the system monitor function.

- (4) Editing and allocating of special module monitor data
 Data displayed on a special module monitor screen cannot be edited by modifying or adding an object, except that the data can be used on a user-created monitor screen.

(5) Precaution for I/O allocation setting

- (a) When the QnACPU is connected, the head XY numbers are displayed in due order on the special module monitoring system configuration screen if the I/O allocation setting is random as shown below.

When performing special module monitoring, always perform the I/O allocation in order from slot 0.



- (b) If the slot assigned to Output in I/O allocation is not fitted with a module, the GOT displays Input. (Common to ACPU and QnACPU)

(6) Display provided when the QA1S6□ extension base unit is used with the QCPU(Q mode)

The following instruction is given for the case where the QA1S6□ extension base unit is connected to the QCPU(Q mode) which is a GOT-connected station.

In this case, any of the following special function modules is displayed as the abbreviated formats on the system configuration screen.

You can use the Unit detail information to confirm the formal format of the module which was displayed as the abbreviated format.

Unsupported special function modules are displayed as "Special" and the corresponding modules cannot be monitored.

Loaded module	Displayed format
A1S63ADA	63ADA
A1SJ71PT32-S3	J71PT32-
A1SJ71ID1-R4	J71ID
A1SJ71ID2-R4-S1	
A1S64TCTT(BW)-S1	64TCTT/R
A1S64TCRT(BW)-S1	

3.4 Network monitor function specifications



Refer to Section 2.2 for restrictions on the network monitor function.

3.4.1 Network information to be monitored

The following table shows the types of network information that can be monitored.

Table 3.1 Network Information To be Monitored

Function	Network Information	MELSECNET (II)/B Master Station	MELSECNET (II)/B Local Station	MELSECNET /10, MELSECNET/H Control Station	MELSECNET /10, MELSECNET/H Ordinary Station	MELSECNET /10, MELSECNET/H Remote Master Station	
Own station monitor	Network category display	○	○	○	○	○	
	Network No. display	×	×	○	○	○	
	Station No. display	○	○	○	○	○	
	Own station operation mode	○	○	○	○	○	
	Own station loop line status	○	○	○	○	○	
	Loop back execution status	○	○	○	○	○	
	Link scan time display	○	×	○	○	○	
	Data link system loop status	○	×	○	○	○	
	Own station communications status	×	○*1	×	×	×	
Detailed own station monitor	Own station information	Own station's station No.	○	○	○	○	○
		Own station	○	○	×	×	×
		Network No.	×	×	○	○	○
		Group No.	×	×	○	○	×
	Control-station information	Specified control station	×	×	○	○	×
		Current control station	×	×	○	○	×
		Communications information	×	×	○	○	×
		Sub-control-station link	×	×	○	○	×
	Data link information	Remote-I/O-master-station station No.	×	×	○	○	×
		Total of linked stations	○	○	○	○	○
		Largest connected station	×	×	○	○	○
		Largest data-linked station	×	×	○	○	○
		Communications status	×	○	○	○	○
	Causes of interrupted communications	Causes of interrupted communications	×	×	○	○	○
		Causes of data link stoppage	×	×	○	○	○
	Constant link scan	Constant link scan	×	×	○	○	○
	BWY receive	BWY from the master station	×	○	×	×	×
	BW receive	BW from the master station in the higher loop	×	○	×	×	×
	Loopback	F-loop status	○	○	○*2	○*2	○*2
		R-loop status	○	○	○*2	○*2	○*2
		F-loopback station	○	×	○*2	○*2	○*2
		R-loopback station	○	×	○*2	○*2	○*2
		Loop switching frequency	○	×	○*2	○*2	○*2
	Own station status	Parameter settings	×	×	○	○	×
Designation of reserved stations		×	×	○	○	○	
Communications mode		×	×	○	○	○	
Designation of transmission		×	×	○*2	○*2	○*2	
Other station monitor	Transmission status	×	×	○*2	○*2	○*2	
	Communications status of each station	○	×	○	○	○	
	Data link status of each station	○	×	○	○	○	
	Parameter status of each station	○	×	○	○	○	
	CPU action status of each station	○	○	○	○	×	
	CPU RUN status of each station	○	○	○	○	×	
Loop status of each station	○	×	○*2	○*2	○*2		

*1 Accessible only when connected to a MELSECNET(II) local station.

*2 Accessible only in a MELSECNET/10 or MELSECNET/H loop system.

○ : Accessible × : Not accessible

3.4.2 Access ranges to be monitored

For access range for monitoring, see Chapter 2 of the GOT-A900 Series User's manual (Connection System Manual).

3.4.3 Precautions when using the network monitor function

The following describes precautions that should be followed when using the network monitor function.

- (1) When the GOT is connected to an AnNCPU or AnACPU, a screen display shows a screen of the MELSECNET II network even when you are connected to the MELSECNET/10 network (the monitor screen shows the display contents of the MELSECNET II).
- (2) There may be a possibility that the network monitor function cannot be used, depending on which CPU to connect and which connection method to use.

CPU to Be Connected	Connection Method	Network Monitor Function		
		Own Station Monitor	Detailed Own Station Monitor	Other Station Monitor
QCPU, QnACPU, ACPU, Motion controller cpu *3	Bus connection	○	○	○
	Direct CPU connection			
	MELSECNET connection *1			
	Computer link connection *2			
	CC-Link connection			
	Ethernet connection			
FXCPU	CPU direct connection	×	×	×
Other manufacture's PLC				

*1 Monitoring cannot be done when connected to MELSECNET/B or MELSECNET(II) and the master station is the Q/QnACPU.

Monitoring may not be done depending on the applied conditions, when connected to the MELSECNET/10 and the control station is the Q/QnACPU.

Applicable CPU of the control/normal station	Communication unit	GOT communication driver	Hardware version of the CPU or network module to be monitored
ACPU, QCPU (A mode)	A7GT-J71LP23, A7GT-J71BR13	MNET10(A)	---
ACPU, QCPU (A mode), QnACPU, QCPU (Q mode)	A9GT-QJ71LP23, A9GT-QJ71BR13	MNET10(A/QuA/Q)	Version B or later

*2 Monitoring cannot be done when the target CPU is the AnUCPU and the MELSECNET/10 network module is used.

*3 When the target CPU is the Q172CPU or Q173CPU, monitoring cannot be done.

- (3) When connected to a QnACPU and the master station of the MELSECNET(II), monitoring cannot be done with the keyword being defined.
- (4) If the MELSECNET/H network module is being monitored, a MELSECNET/10 display is provided in either of the following cases:
The normal station has been started due to a communication error (cable disconnection, etc.)
The monitor target is the remote master station.

3.5 List editor function specifications



Refer to Section 2.2 for restrictions on the List editor function.

3.5.1 PLC CPU that allows for list edit

PLC CPUs that allow list edit are either the QCPU(A mode) or the ACPU.
For details, refer to Section 2.2 (2).



In using the A2USH-S1/A2SH-S1/A2SH/A1SH/A1SJHCPU, the following restrictions should be observed in the range of list edit.

In using the A2USHCPU-S1 : In the range of the A3UCPU

In using the A2SH-S1/A2SH/A1SH/A1SJHCPU : In the range of the A3NCP

3.5.2 Access range that allows for list edit

For information about the access range that allows for list edit, see Chapter 2 of the GOT-A900 Series User's manual (Connection System Manual).


3.5.3 Precautions for List editor function

Precautions for the List editor function are as follows:

- (1) Precaution for reading with the specified command
The command cannot be specified to read the ladder.
- (2) Precaution for use with the ladder monitor function
If list edit is performed while the ladder monitor function is started, the edit details are not shown on the ladder monitor screen.
To show the edit details, the ladder monitor must be read from the PLC again.
- (3) Precaution for list edit
While the corresponding PLC is at stop status, perform list edit.
The list cannot be edited during PLC running.
- (4) Precaution for parameter changing on the other peripheral device
If parameter settings are changed on the other peripheral device during use of the list edit function, they will be different from the settings of the internal parameters of the list edit function.
For this reason, reset the GOT unit or make PC No. setting again to read the parameters.
- (5) Precaution for Ethernet connection
To use the list editing function for Ethernet connection, the host setting on GT Designer2 must be preset to the ACPU or QCPU (A mode).

3.5.4 List of key arrangement and key functions

Key arrangement and key functions of the list edit window are shown below.



No.	Name	Key	General description of function
1)	Control key	SET	Key that declares start of step number input or automatic scroll. Switch key that makes the lower character valid on each key with dual functions. Whether upper or lower character is valid can be checked on the display.
		SHIFT	Switch key that makes the upper character valid on each key with dual functions. Whether upper or lower character is valid can be checked on the display.
		CLEAR	If the Clear key is pressed when the system is not in the Parameter mode, Other mode or Help function, the screen returns to the initial status of the mode selection. (The input commands or device numbers except for the mode are cleared.) This is used for repeating the procedure if incorrect keys are pressed.
			In the Parameter mode, the process is cancelled. After restarting, continue the operation.
			In the Other mode, the screen returns to the previous display.
			When the Help function is used, the screen returns to the display at the input of the HELP key.
		SP	Key that provides blank space at the command and at between device names.
(←), (→)	Key that moves the cursor on the display (▶, ■) or determines scroll directions.*		
GO	Press this key at the last of a series of key operations to execute the operation. Check the details of key operations on the display before pressing this key.		
2)	Mode key	READ WRITE to PARAM OTHER	Key that selects each mode of the List editor function. Switch the upper/lower character mode with the SHIFT key.
3)	Help key	HELP	Key that selects the help function in the mode supporting the help function.
4)	Command key Advice key	FROM A to END Z	Key that inputs K/H at the input of command, device name and constant input. Only when the valid key of upper/lower character needs to be switched, switching is allowed with input of the SHIFT and SET keys.
5)	Command key Device No./ Constant setting key	RST 0 to MC F	Key that inputs the command, device number and constant. Only when the valid key of upper/lower character needs to be switched, switching is allowed with input of the SHIFT and SET keys.

* Movement of the cursor key between steps, between the menu items and in the input area is explained below.

(1) Keep pressing the cursor key to repeat the movement toward the specified key direction.

(2) Movement between steps and between menu items

To display the program immediately before/after the current step number command, Input either

↑ or ↓ key.

↑ : Program immediately before the command (no change after 0 step)

↓ : Program immediately after the command (no change after the last step)

R	0	L D	X 0 0 0 5
▲	1	A N D	M 2
	2	▶ O U T	T 0
	3	K 1 2 3	

" ▶ " moves to the specified direction (upward/downward) with ↑ or ↓ key.

(3) Movement in the input area

To move the cursor between command names, between sources, and between destinations, input

either ← or → key.

W	1 1 5	M 5	
▼	1 2 0	L D	M 3
	1 2 1	▶ N O P	
P	K 2 1 4 7 4 8 3 6 4 7	D 1 0 0 0	■

← Input area

↑ Display example for DWOVP K2147483647 D1000

" ■ " moves to the specified direction (left/right) with ← or → key.

In this operating manual, the List editor function key is represented in the following abbreviation form.

- (1) Expression of Key 1 → Key 2 → Key n means the sequential input from Key 1 to Key 2.
- (2) Expression of Key 1 + Key 2 means input of Key 1 and Key 2 at the same time.
- (3) As in RST
0 key or MOV
M key, keys with dual functions for input of the command or the device/constant or control keys that control the List editor function are represented as follows:
 - (a) The mode command or only alphanumeric characters are described.


(Example
RST
0 → RST or 0 , MOV
M → MOV or M)

- (b) Only commands are shown for explanation of command input. (Alphanumeric characters are omitted.)
 Only alphanumeric characters are shown for explanation of alphanumeric characters.
 (Command expressions are omitted.)

(Example
 To express MOV
M key
 When input of command is explained..... MOV
 When input of alphanumeric characters is explained... M)

3.5.5 Display format on the display

The following describes the position and content of each data field in the display area provided by the List editor function.




(1) Mode and valid key display

The following describes the mode and valid key display.

The mode display shows the list editor function mode selected by the user.

The valid key display shows which of the two functions assigned to each key is currently available: the function indicated at the upper part of the key or the function indicated at the lower part of the key.





(Display)	(Mode)
R	Read mode
W	Write mode
I	Insert mode
D	Delete mode
P	Parameter mode
O	Other mode

Valid key display (This display is not always available.)

With regard to keys framed in dotted lines in the figure shown at the left, the valid key display indicates which of the two functions assigned to each key is valid:

- ▲ : Function indicated at the upper part of each key is available.
- ▼ : Function indicated at the lower part of each key is available.

Example: FROM key



To switch between two functions of keys (functions indicated at upper and lower parts of the keys), press the **SHIFT** and **SET** keys.
For details, see Section 20.1.1.


(2) Cursor display

The GOT controls the display of the cursor when the user has to input data; it displays a "■" at the cursor position. For more information, see Paragraph (6) below.

If the cursor overlaps the display of a character, however, the character and "■" alternate on the display.

(3) Indication of the selected line

When a program list is displayed, the line currently selected for editing is indicated by "▶" appearing immediately after the step number.




You can use the  and  keys to move "▶" up and down.

(4) Step number display

A step number is displayed as a decimal number.

On the 1st and 2nd lines in the display area, significant digits in the lower four digits of a step number are displayed.

On the 3rd and 4th lines in the display area, up to five significant digits in a step number are displayed.



(5) Device display

Two or more device specifications attached to a basic or application instruction are displayed using the same step number.


For information on the step numbers, see Paragraph (4) above.

(6) Display of data input from the keys

Data input from the keys will appear at the cursor position. As more characters are input, the cursor moves to the right.

The cursor appears as "■".

Example: The user enters  →  → 



(7) Shifting of data to the left during the input of a program

When the user inputs a program, the codes entered before a touch on the **GO** key will appear on the 4th (bottom) line of the display area.

If the codes cannot appear on a single line, the display on the 4th line only will shift by a single character position to the left each time the user touches a key. (Each character that goes out of the display area by the left-shift operation is retained in the memory.)

```

W  1 1 5      M 5          X 0 0 0 5
▲  1 2 0      L D          M 3
   1 2 1 ►    N 0 P
P  K 2 1 4 7 4 8 3 6 4 7  D 1 0 0 0
  
```

↑ The user has entered "DMOV P K2147483647 D1000".

(8) Numerical display

The following describes the display of numerical values in devices and of constants in a program input by the user. Note, however, that only some examples are shown. For details, see Chapter 20.

Example: D1000 **4231H**

1) Display in decimal format

Only significant digits are displayed with zero-suppression.

```

M  D 1 0 0 0          1 6 4 9 5
  
```

2) Display in hexadecimal format

Four digits are displayed without zero-suppression.

```

M  D 1 0 0 0          H 4 2 3 1
  
```

3) Display in octal format

Six digits are displayed without zero-suppression.

```

M  D 1 0 0 0          0 0 4 1 0 6 1
  
```

4) ASCII format

A numerical value in the specified device is read in byte units and converted into associated character codes.

If a value fell outside the ranges 20H through 7FH and A0H through DFH, dots "." will appear.

```

M  D 1 0 0 0          a s c i i  B 1
  
```

(9) Display of an error message

An error message will appear on the 4th line of the display area.

If an error message appears, perform corrective action as described in Chapter 21.

An error message on the display is cleared when you press any key. Then the display resumes the state before the appearance of the error message.

3.5.6 List of List editor function

Mode (mode display)	Function				Action
Write (W)	Write program				Writes, adds, or modifies a program.
	Change device				Changes a device used at the selected step in the program
	Help	Write	Instruction help	Display/ select instruction	Displays a list of instructions that start with the specified character and allows the user to choose from them.
				Read step	Reads a program after allowing the user to specify a step number.
		NOP continuous		Declares the specified part of the program NOP.	
Comment display				Displays a comment for the specified device.	
Read (R)	Read program				Reads a program after allowing the user to specify a step number. Reads a program after allowing the user to specify an instruction used. Reads a program after allowing the user to specify a device used.
	Automatic scrolling				Automatically scrolls the display of a program that has been read up to a specified step.
	Help	Read	Step		Corresponds to program read and automatic scroll functions described above.
			Instruction		
			Device		
Automatic scrolling					
Comment display				Displays a comment for the specified device.	
Insert (I)	Insert program				Inserts a new program into the displayed program.
	Help	Insert	Instruction help	Display/ select instruction	Displays a list of instructions that start with the specified character and allows the user to choose from them.
				Read step	Reads a program after allowing the user to specify a step number.
			Move		Moves the selected part of the program to a specified part of the program.
			Copy		Copies the selected part of the program to a specified part of the program.
Comment display				Displays a comment for the specified device.	
Delete (D)	Delete program				Deletes a program at the specified step.
	Help	Delete	Specified block	Deletes the specified block in the program.	
			All NOPs	Deletes all NOP instructions found in program codes described before the END instruction. (NOPLF instructions will not be deleted.)	
Comment display				Displays a comment for the specified device.	
Parameter (P)	Clear all parameters				Clears all parameters in the ACPU only.
	Set parameter				Sets or changes various parameters like those for the memory capacity, timer/counter, and latching range. Sets or changes a keyword.

Mode (mode display)	Function		Action		
Others (O)	Change T/C set values		Changes values set to timer/counter devices.		
	PC check	Read erroneous step	Displays details of an error in the ACPU and the associated step number.		
		Program check		Checks duplex coils, instruction codes, and other elements in the program.	
	PC system	Monitor	Buffer memory batch monitor	With regard to a special function unit of the specified I/O number, monitors the contents of the buffer memory at the specified address.	
			Clock monitor		Monitors the ACPU clock (D9025 through D9027).
		Monitor All clear	PC memory		Clears all contents of the ACPU memory and resets it to the initial state.
			Program		Clears the program (Main/Sub) currently selected.
			Device memory		Clears all device memories except for special-D, special-M, and R.
		Switch	PC No. setup		Switches the target ACPU in GOT operations in each mode.
	Switch Main/Sub		Switches the target program (Main/Sub) in GOT operations in each mode.		
	Others	Remote RUN/STOP		Forcibly changes the ACPU running status between RUN and STOP.	
		Machine language read/write		Performs a read or write operation to the ACPU memory in the machine language.	

1	OVERVIEW
2	BEFORE BEGINNING OPERATION
3	SPECIFICATIONS
4	OPERATING THE UTILITY FUNCTION
5	OPERATING LADDER MONITOR
6	OPERATING THE VARIOUS LADDER MONITOR SCREENS
7	ERROR MESSAGES FOR LADDER MONITOR
8	OPERATING SYSTEM MONITOR

3.6 Specifications of the motion monitor function



Refer to Section 2.2 for the restrictions on the motion monitor function.

3.6.1 PLC CPUs that can be monitored

The motion controller CPUs that can be monitored are only the Q172CPU and Q173CPU.
Refer to Section 2.2 (2) for details.

3.6.2 Access ranges that can be monitored

For the access ranges where the motion monitor function can be performed, refer to Chapter 2 of the GOT-A900 Series User's Manual (Connection System Manual).

3.6.3 Precautions for use of the motion monitor function

- (1) When using the motion monitor function, use the motion controller CPU (Q172CPU, Q173CPU) that satisfies the following conditions.
 - Installed motion controller OS version: "00E" or later
 - Serial No.: "K*****" or later (Q172CPU)
"J*****" or later (Q173CPU)

- (2) When the CNC monitor function is used, the motion monitor function cannot be used.

3.6.4 Memory space necessary to use the motion monitor function

The following indicates the memory spaces for motion monitor data.
The memory space needed to store data into the built-in memory of the GOT is the same as the memory space needed to store data into the hard disk of the personal computer.

Stored Data	Memory Space [k bytes]
Information common to motion monitor data	13.4
A985GOT	200
A97*GOT	200
A960GOT	200
A956WGOT	115
A95*GOT	110

3.7 Specifications of the Servo Amplifier Monitor Functions



Refer to Section 2.2 for the restrictions on the servo amplifier monitor functions.

3.7.1 List of servo amplifier models that can be monitored and functions

The following table lists the servo amplifier models, where the servo amplifier monitor functions can be performed, and the functions.

Function		Servo Amplifier	MR-J2S-□A	MR-J2S-□CP	MR-J2M A Series	
					MR-J2M-P8A	MR-J2M-□DU
Setup	Model selection		○	○	○	○
	Baudrate		○	○	○	○
	Station number selection		○	○	---	---
	Station number setting		○	○	○	○
	IFU station number		---	---	○	○
Monitor	Batch display		○	○	○	○
Alarm	Alarm display		○	○	○	○
	Alarm history		○	○	○	○
Diagnostics	DI/DO display		○	○	○	---
	Function device display		—	○	○	○
	Amplifier information display		○	○	○	○
	ABS data display		○	○	---	○
	Module composition list display		---	---	○	○
Parameters	Parameter setting		○	○	---	---
	Parameters (IFU)		---	---	○	○
	Parameters (DRU)		---	---	○	○
Test	JOG operation		○	○	---	○
	Positioning operation		○	○	---	○
	Motorless operation		○	○	---	○
	DO forced output		○	○	○	---

○ : Function available ---: Function unavailable

3.7.2 Access range that can be monitored

The access range where the servo amplifier monitor functions can be performed is as follows.

- (1) When RS-232C communication function is used
Only the connected servo amplifier can be monitored.
- (2) When RS-422 communication function is used (multidrop communication)
The servo amplifier from among up to 32 axes of servo amplifiers, stations 0 to 31, on the same bus as the connected servo amplifier can be monitored.

3.7.3 Precautions for use of the servo amplifier monitor functions

- (1) Before starting test operations, always read the precautions in Section 26.7.1.
- (2) The maximum communication speed between the GOT and servo amplifier is 38400bps. Set the servo side communication speed to 38400bps or less.
- (3) If the PLC CPU connected to the GOT does not have clock data, the time displayed by the servo amplifier monitor functions is not precise.
- (4) The settings of the GOT side servo amplifier monitor functions (setup screen (refer to Section 26.3.1)) should be the same as the servo amplifier side settings. If they are different, normal communication may not be made.
- (5) When the servo amplifier monitor functions are used, communication from GT Designer2 (OS installation/monitor screen data downloading) cannot be made. Before starting communication from GT Designer2, terminate the servo amplifier monitor functions.
- (6) When the servo amplifier is connected, the bar code function cannot be used.
- (7) The transparent function cannot be used on the GOT where the servo amplifier monitor function operating system (OS) has been installed.

3.7.4 System configuration for servo amplifier connection

The system configurations for servo amplifier connection are shown below.

Connection Condition	System Configuration
When only one servo amplifier is connected	
When multiple ^{*3} (2 to 32) servo amplifiers are connected	

*1 Connect the GOT side connector into the RS-232C interface at the bottom of the GOT used for downloading the monitor screen data.

*2 Connect the servo amplifier side connector to CN3.

*3 As the servo amplifier to be monitored, select one from among the 32 servo amplifiers.

3.7.5 Screens and memory capacity

The monitor screens used for the servo amplifier monitor functions change depending on the GOT model and monitored servo amplifier model.

The following tables indicate the monitor screen types and memory capacities necessary to use the servo amplifier monitor functions.

(1) When A985GOT is used

Function Details	Stored Screen Data	Memory Capacities [Bytes]				
		For MR-J2S-□A monitor	For MR-J2S-□CP monitor	For MR-J2M-P8A monitor	For MR-J2M-□DU monitor	
Servo amplifier monitor data common information		18416				
Monitor	600 "Servo (A985) Monitor: ALL"	4132				
Alarm	Alarm display	613 "Servo (A985) Alarms: ALL"				
	Alarm history	615 "Servo (A985) Alarms Hist.: ALL"				
Diagnostic function	DI/DO display	617 "Servo (A985) I/O Display: S-A"	2436	---	---	---
		618 "Servo (A985) I/O Display: S-CP"	---	2608	---	---
		619 "Servo (A985) I/O Display: M-A IFU"	---	---	4522	---
		620 "Servo (A985) I/O Display: M-A D01"	---	---	---	3488
	Function device display	624 "Servo (A985) Function Dev.: S-CP"	---	2948	---	---
		625 "Servo (A985) Function Dev.: M-A IFU"	---	---	4808	---
		626 "Servo (A985) Function Dev.: M-A DRU"	---	---	---	4744
	Amplifier information display	628 "Servo (A985) Amp inf.: S-A"	2112	---	---	---
		629 "Servo (A985) Amp inf.: S-CP"	---	2188	---	---
		630 "Servo (A985) Amp inf.: M-A IFU"	---	---	2012	---
		631 "Servo (A985) Amp inf.: M-A DRU"	---	---	---	2204
	ABS data display	635 "Servo (A985) ABS data: S-A"	2700	---	---	---
		636 "Servo (A985) ABS data: S-CP"	---	2916	---	---
		637 "Servo (A985) ABS data: M-A DRU"	---	---	---	2928
Unit composition list display	639 "Servo (A985) Unit Comp.: M-A IFU"	---	---	3444	---	
	640 "Servo (A985) Unit Comp.: M-A DRU"	---	---	---	3432	
Parameter setting	643 "Servo (A985) Parameters: S-**"	3656		---	---	
	644 "Servo (A985) Parameters: M-A IFU"	---	---	3872		
	645 "Servo (A985) Parameters: M-A DRU"	---	---	---	4452	
Test	Jog operation	678 "Servo (A985) Jog op.: S-**"	2672		---	---
		679 "Servo (A985) Jog op.: M-A DRU"	---	---	---	2476
	Positioning operation	682 "Servo (A985) Positioning: S-**"	3056		---	---
		683 "Servo (A985) Positioning: M-A DRU"	---	---	---	2860
	Motor-less operation	685 "Servo (A985) Motor-less op: S-**"	2300		---	---
		686 "Servo (A985) Motor-less op: M-A DRU"	---	---	---	2140
	DO forced output	688 Servo (A985) DO Forced Out: S-A"	2844	---	---	---
		689 Servo (A985) DO Forced Out: S-CP"	---	2724	---	---
690 "Servo (A985) DO Forced Out: M-A IFU"		---	---	4692	---	
691 "Servo (A985) DO Forced Out: M-A D01"		---	---	2540	---	

(2) When A97*GOT/A960GOT is used

Function Details		Stored Screen Data	Memory Capacities [Bytes]			
			For MR-J2S-□A monitor	For MR-J2S-□CP monitor	For MR-J2M-P8A monitor	For MR-J2M-□DU monitor
Servo amplifier monitor data common information			18416			
Monitor		700 "Servo (A97*) Monitor: ALL"	4132			
Alarm	Alarm display	713 "Servo (A97*) Alarms: ALL"	2268			
	Alarm history	715 "Servo (A97*) Alarms Hist.: ALL"	3020			
Diagnostic function	DI/DO display	717 "Servo (A97*) I/O Display: S-A"	2436	---	---	---
		718 "Servo (A97*) I/O Display: S-CP"	---	2608	---	---
		719 "Servo (A97*) I/O Display: M-A IFU"	---	---	4452	---
		720 "Servo (A97*) I/O Display: M-A D01"	---	---	3488	---
	Function device display	724 "Servo (A97*) Function Dev.: S-CP"	---	2948	---	---
		725 "Servo (A97*) Function Dev.: M-A IFU"	---	---	4920	---
		726 "Servo (A97*) Function Dev.: M-A DRU"	---	---	---	4908
	Amplifier information display	728 "Servo (A97*) Amp inf.: S-A"	2112	---	---	---
		729 "Servo (A97*) Amp inf.: S-CP"	---	2188	---	---
		730 "Servo (A97*) Amp inf.: M-A IFU"	---	---	2012	---
		731 "Servo (A97*) Amp inf.: M-A DRU"	---	---	---	2204
	ABS data display	735 "Servo (A97*) ABS data: S-A"	2700	---	---	---
		736 "Servo (A97*) ABS data: S-CP"	---	2916	---	---
		737 "Servo (A97*) ABS data: M-A DRU"	---	---	---	2928
Unit composition list display	739 "Servo (A97*) Unit Comp.: M-A IFU"	---	---	3444	---	
	740 "Servo (A97*) Unit Comp.: M-A DRU"	---	---	---	3432	
Parameter setting	743 "Servo (A97*) Parameters: S-*	3656		---	---	
	744 "Servo (A97*) Parameters: M-A IFU"	---	---	3872		
	745 "Servo (A97*) Parameters: M-A DRU"	---	---	---	4180	
Test	Jog operation	778 "Servo (A97*) Jog op.: S-*	2672		---	---
		779 "Servo (A97*) Jog op.: M-A DRU"	---	---	---	2476
	Positioning operation	782 "Servo (A97*) Positioning: S-*	3056		---	---
		783 "Servo (A97*) Positioning: M-A DRU Motor-less operation"	---	---	---	2860
		785 "Servo (A97*) Motor-less op: S-*	2300		---	---
		786 "Servo (A97*) Motor-less op: M-A DRU"	---	---	---	2140
	DO forced output	788 Servo (A97*) DO Forced Out: S-A"	2724	---	---	---
		789 Servo (A97*) DO Forced Out: S-CP"	---	2724	---	---
790 "Servo (A97*) DO Forced Out: M-A IFU"		---	---	4692	---	
791 "Servo (A97*) DO Forced Out: M-A D01"		---	---	2540	---	

(2) When A95*GOT/A956WGOT is used

Function Details		Stored Screen Data	Memory Capacities [Bytes]			
			For MR-J2S-□A monitor	For MR-J2S-□CP monitor	For MR-J2M-P8A monitor	For MR-J2M-□DU monitor
Servo amplifier monitor data common information			18416			
Monitor		800 "Servo (A95*) Monitor: ALL"	2252			
Alarm	Alarm display	822 "Servo (A95*) Alarms: ALL"	1612			
	Alarm history	824 "Servo (A95*) Alarms Hist.: ALL"	2040			
Diagnostic function	DI/DO display	826 "Servo (A95*) I/O Display: S-A"	1944	---	---	---
		827 "Servo (A95*) I/O Display: S-CP"	---	2124	---	---
		828 "Servo (A95*) I/O Display: M-A IFU"	---	---	3436	---
		829 "Servo (A95*) I/O Display: M-A D01"	---	---	---	2808
	Function device display	833 "Servo (A95*) Func.Dev.: S-CP"	---	2188	---	---
		834 "Servo (A95*) Func.Dev.In1: M-A IFU"	---	---	2740	---
		835 "Servo (A95*) Func.Dev.In2: M-A IFU"	---	---	2696	---
		836 "Servo (A95*) Func.Dev.Out1: M-A IFU"	---	---	2804	---
		837 "Servo (A95*) Func.Dev.Out2: M-A IFU"	---	---	2848	---
		838 "Servo (A95*) Func.Dev.In1: M-A DRU"	---	---	---	2792
		839 "Servo (A95*) Func.Dev.In2: M-A DRU"	---	---	---	2684
		840 "Servo (A95*) Func.Dev.Out1: M-A DRU"	---	---	---	2728
	Amplifier information display	843 "Servo (A95*) Amp inf.: S-A"	1396	---	---	---
		844 "Servo (A95*) Amp inf.: S-CP"	---	1472	---	---
		845 "Servo (A95*) Amp inf.: M-A IFU"	---	---	1296	---
		846 "Servo (A95*) Amp inf.: M-A DRU"	---	---	---	1488
	ABS data display	850 "Servo (A95*) ABS data Cur.: S-A"	1744	---	---	---
		851 "Servo (A95*) ABS data Orig: S-A"	1816	---	---	---
		852 "Servo (A95*) ABS data Cur.: S-CP"	---	1960	---	---
		853 "Servo (A95*) ABS data Orig: S-CP"	---	2032	---	---
		854 "Servo (A95*) ABS data Cur.: M-A DRU"	---	---	---	1972
	Unit composition list display	855 "Servo (A95*) ABS data Orig: M-A DRU"	---	---	---	2044
		857 "Servo (A95*) Unit Comp.: M-A IFU"	---	---	2512	---
	858 "Servo (A95*) Unit Comp.: M-A DRU"	---	---	---	2500	
	Parameter setting	861 "Servo (A95*) Parameters: S-***"	2860		---	---
862 "Servo (A95*) Parameters: M-A IFU"		---	---	3064		
863 "Servo (A95*) Parameters: M-A DRU"		---	---	---	3300	
Test	Jog operation	906 "Servo (A95*) Jog operation: S-***"	1944		---	---
		907 "Servo (A95*) Jog operation: M-A DRU"	---	---	---	1752
	Positioning operation	910 "Servo (A95*) Positioning: S-***"	2328		---	---
		911 "Servo (A95*) Positioning: M-A DRU"	---	---	---	2136
	Motor-less operation	913 "Servo (A95*) Motor-less op: S-***"	1584		---	---
		914 "Servo (A95*) Motor-less op: M-A DRU"	---	---	---	1388
	DO forced output	916 Servo (A95*) DO Forced Out: S-A"	2128	---	---	---
		917 Servo (A95*) DO Forced Out: S-CP"	---	2008	---	---
918 "Servo (A95*) DO Forced Out: M-A IFU"		---	---	3332	---	
		919 "Servo (A95*) DO Forced Out: M-A D01"	---	---	1728	---

1 OVERVIEW
2 BEFORE BEGINNING OPERATION
3 SPECIFICATIONS
4 OPERATING THE UTILITY FUNCTION
5 OPERATING LADDER MONITOR
6 OPERATING THE VARIOUS LADDER MONITOR SCREENS
7 ERROR MESSAGES FOR LADDER MONITOR
8 OPERATING SYSTEM MONITOR

3.8 CNC monitor function specifications



Refer to Section 2.2 for the GOTs that can use the CNC monitor function.

3.8.1 CNC models that can be monitored

The model for which the CNC monitor function can be performed is only the MELDAS C6/C64.

3.8.2 CNC functions that can be monitored

The CNC monitor function allows the following functions to be monitored.
For details of the functions, refer to the MELDAS C6/C64 manual.

- Position Display Monitor
- Alarm Diagnosis Monitor
- Tool Offset/Param
- Program Monitor
- F0

3.8.3 Access ranges to be monitored

The CNC monitor function is usable only when connected to the MELSECNET/10 or Ethernet.
For connection with the MELDAS C6/C64 in the MELSECNET/10 or Ethernet, refer to GOT-A900 Series User's Manual (Connection System Manual).

- (1) Ethernet connection
One GOT can monitor up to 64 MELDAS units.
One MELDAS unit can be monitored by up to eight GOTs.
- (2) MELSECNET/10 connection
GOT monitors the control station only.

3.8.4 Precautions when using the CNC monitor function

- (1) When the motion monitor function is used, the CNC monitor function cannot be used.

3.9 Font change function specifications



For GOTs that support the font change function, refer to Section 2.2.

3.9.1 Available fonts

This function changes the font to/from the following.

- Standard font
- Chinese (simplified characters) font

3.9.2 Applicable range for each font

The following table shows the applicable range for each font.

○ : Applicable, × : N/A

Item	Details	Standard font	Chinese (simplified characters) font
Monitor screen	The font displayed on the monitor screen	○	○ *1
Utility	The font displayed on the utility.	○	○ *2
Extended function	The font displayed on the screen for the following functions. <ul style="list-style-type: none"> ▪ Ladder monitor ▪ System monitor ▪ Special function module monitor ▪ Network monitor ▪ List editor function ▪ Motion monitor ▪ Servo amplifier monitor ▪ CNC monitor 	○	○ *2*3
Offline screen	The font displayed on the screen for OS installation or monitor data download.	○	×

*1 As the ASCII display/input function supports the ASCII codes and Shift JIS codes only, the Chinese characters other than these codes cannot be displayed. Therefore, when displaying Chinese characters, use the comment display or text figure.

*2 Applicable only when the message (utility set-up) is displayed in Japanese.

*3 Please note that the ladder monitor supports MELSEC-A/FX ladder monitor only. (MELSEC-Q/QnA ladder monitor is not supported.)


3.9.3 Precautions when using the font change function

- (1) Changing to the Chinese (simplified characters) font makes the MELSEC-Q/QnA ladder monitor function unusable. Do not install the extended function OS for MELSEC-Q/QnA ladder monitor function into the GOT. If this function is started, this deletes the font data installed in the GOT. In this case, it is required to install the font data again to use the font change function.

- (2) To use HQ fonts of Chinese (simplified characters) font for characters and comments, the font environment of the GT Designer2 is required to be changed to Chinese (simplified characters). For how to change the font environment of the GT Designer2, refer to "Section 31.2.3 Installing font data".
When not changing the font environment, the characters and comments set in HQ fonts will be displayed in standard fonts.

- (3) To preview in Chinese (simplified characters), the font environment of the GT Designer2 is required to be changed to Chinese (simplified characters).
For how to change the font environment of the GT Designer2, refer to "Section 31.2.2 Displaying Chinese (simplified characters) fonts with Preview of the GT Designer2".
When not changing the font environment, the characters and comments will be previewed in standard fonts.

- (4) When changing the font environment of the monitor data created in standard fonts to Chinese (simplified characters), the Chinese (simplified characters) font can be displayed by downloading and uploading the data with the following procedure.



When opening the data created in standard font environment with the GT Designer2 where the font environment is changed to Chinese (simplified characters) and then downloading it to the GOT, HQ characters of standard font may be displayed.

3.10 System dialog language switching function specifications

The following shows the specifications of the system dialog language switching function. For the system dialog language switching function, extended function OS is not required to be installed in the GOT.

3.10.1 Switchable languages

The following languages are available for language switching.

- Japanese
- English
- Chinese (simplified characters)
- Chinese (traditional characters)

3.10.2 Precautions when using the system dialog language switching function

- (1) The system dialog language switching function is applicable to some system dialogs. For system dialogs to which language switching is applicable, refer to Section 32.3.
- (2) When using Chinese (simplified characters) for the system dialog language, set Chinese (simplified characters) font.
- (3) When using Chinese (traditional characters) for the system dialog language, set standard font. Refer to "Chapter 31 FONT CHANGE FUNCTION" for character font setting.

4 OPERATING THE UTILITY FUNCTION

4.1 Utility function table


Functions	Description	Remarks	Ref. section
Brightness/contrast adjustment	Adjusting the brightness/contrast of a monitor screen.	This function changes with the GOT used.	Section 4.3
System monitor	Monitoring or changing devices in a PLC CPU.	This function can be executed only after installing an OS, monitor data on the GOT by using GT Designer2.	Chapter 9
Special module monitor	Monitoring or changing buffer memory of a special module.	This function can be executed only when the GOT memory is extended and the OS is installed from the GT Designer2 to the GOT.	Chapter 12
Screen & OS copy	Copying of screen data between internal memory and memory card Copying of OS data between internal memory and memory card	Refer to the GT Designer2 Version2 Operating Manual to install the OS (from memory card to internal memory).	Section 4.4
Setup	The options of settings include: <ul style="list-style-type: none"> • Language used in a message display (Japanese/English) • Buzzer sound adjustment • Sounds from an external speaker • Idle time for a screen saver • Backlighting for a screen saver • Protocol and baud rate when connected to a microcomputer • Reverse display • Extension number and slot number for bus with QCPU • Transmission speed for Computer link connection • Transmission speed for Omron/Yaskawa/Hitachi/Matsushita PLC connection • Startup time, transmission delay and CCU monitor registration (Matsushita Electric Works PLC only) for Yaskawa/Matsushita Electric Works PLC connection • Transmission speed and address for SIEMENS/Allen-Bradley PLC connection • Transmission time-out setting for CC-Link (ID) driver installation • Setting of disable-enable/detection sensitivity/OFF delay for screen save/human sensor • Grip switch enable/disable setting (A950 handy GOT only) • Adjusting the color balance/contrast/brightness/color power of a video window. • Adjusting the clock phase H-Position/V-Position of an RBG window, and setting the touch key position for a return to the monitor screen. 		Section 4.5
Self-test	The self-test include diagnostic checks on GOT hardware as follows: <ul style="list-style-type: none"> • Drawing check • Font check • Memory card check • User-space-in-the-internal-memory check • OS-space-in-the-internal-memory check • CPU communications check • Touch key check 		Section 4.6
Memory information	The contents of GOT memory information include: <ul style="list-style-type: none"> • OS version number • Status of communications with the PLC CPU • Available space in the internal memory • Availability of memory cards and available space in a memory card • Availability of the ladder monitor function 		Section 4.7
Ladder monitor	Monitoring the sequence programs on the PLC CPU.	This function can be executed only when the GOT memory is extended and the OS is installed from the GT Designer2 to the GOT.	Chapter 6
Clock	Setting date and time.		Section 4.8
Screen cleanup	Displaying the display area cleanup screen.		Section 4.9
Network monitor	Monitoring the line status of MELSECNET.	This function can be executed only when the GOT memory is extended and the OS is installed from the GT Designer2 to the GOT.	Chapter 17
Security password	Changing the security levels of numeric input and objects.	If a security password is defined by using GT Designer2, security levels can be changed.	Section 4.10
Password	Defining a password for limited access to the utility menu screen.		Section 4.11
List edit	List editing of PLC programs in PLC CPU	This function can be executed only when the GOT memory is extended and the OS is installed from the GT Designer2 to the GOT.	Chapter 19
Motion/CNC monitor	Motion controller CPU (Q172CPU/Q173CPU) Changing of servo monitor/servo parameter setting	This function can be executed only when the GOT memory is increased and the OS is installed from GT Designer2 to the GOT.	Chapter 22
	Monitor and parameter change of MELDAS C6/C64		Chapter 28
Servo amplifier monitor	Servo amplifier monitor, servo parameter setting change, test operation		Chapter 25

4.2 Selecting the utility function

This section describes how to select the utility function.
The utility function can be activated with a touch of the screen.


To select the utility function, follow either of the following two steps.

- (1) Touch the upper right and left corners of the screen at the same time.



- (2) Touch a touch key displayed on the monitor screen. A touch key can be set in the touch key (expanded) function settings.


The following flowchart outlines the steps involved in selecting the utility function.



4.3 Utility Menu Screen

(1) Display screen

The display screen differs with the GOT used.



(2) Function

- Menu screen used to select any of the utility functions.
- Used to adjust the brightness/contrast of the monitor screen.

(3) Operation

(a) Basic operation

Directly touch the portion where the function you will select is being displayed.

(b) Return to the monitor screen

Touch  to return to the monitor screen.

(c) Brightness/contrast adjustment

- Touch   and at top of the screen to make contrast adjustment.
- You can adjust the contrast in about 20 steps.
- Touch  at top right of the screen to show the brightness adjustment- screen.
- For details of the adjustment method on the brightness adjustment screen, refer to Section 4.12.

Point 

- If the OS is not installed on the GOT, items are displayed on the system monitor, but they cannot be selected.
- If the following conditions for use of the corresponding functions are not satisfied, the special function module monitor, ladder monitor, network monitor, motion monitor, servo amplifier monitor and CNC monitor items are displayed in the utility menu but cannot be selected.
 - (a) A985/97*/960GOT/956WGOT
 - The memory board is loaded in the GOT.
 - The extended function OS is installed in the GOT.
 - (b) A95*GOT
 - The compatible model (A95*GOT-*BD-M3) is used.
 - The extended function OS is installed in the GOT.
- If the GOT is connected to the PLC CPU without clock function, items are displayed on the clock window, but they cannot be selected.


(4) On-screen error messages

Message	Cause	Corrective Action
Can't be selected (When system monitor, special module monitor, ladder monitor, motion/CNC monitor, servo amplifier monitor or clock setting is selected)	<ul style="list-style-type: none"> • The OS is not installed on the GOT. • The memory board is not installed in the A985/97*/960/960WGOT. • The A95*GOT used is other than the A95*GOT-*BD-M3. • The GOT is connected to a PLC CPU without a clock function. 	<ul style="list-style-type: none"> • Install the OS. • Install the memory board in the A985/97*/960/960WGOT. • Use the A95*GOT-*BD-M3. • Replace the CPU with one with a clock function or do not use the clock setting.

4.4 Screen & OS Copy

(1) Display screen

Sample screen



(2) Features

- Project data stored in the internal memory can be saved to the memory card.
- Project data stored in the memory card can be saved to the internal memory.
- OS data can be backed up by copying them from the internal memory to the memory card.

(3) Procedure

(a) Basic operation

- Touch or to select options.
- Touching will display a message asking you to answer the question "Do you want to execute?"
- If you answers Yes to the question, touch again. Touch or to select another option. To quit the backup copy, touch to return to the Utility Menu screen.

(b) To return to the Utility Menu screen:


- Touch to return to the Utility Menu screen.

(4) On-screen error messages

Message	Cause	Corrective Action
Cancel write protect function	The memory card is write-protected.	Release write protection of the memory card.
Install memory card	A memory card is not installed on the GOT.	Install a memory card on the GOT.
Format memory card	The installed memory card is not yet formatted.	Format the memory card.
Write Error (M-CARD capacity shortage) Data transfer error	Memory card loaded has memory space less than written data.	Change the memory card for the one having enough memory space.
M-CARD error Data transfer error	Write error occurred in the memory card during copying, or the memory card used has no free space.	Change the memory card, or increase the free space of the memory card.
Memory card error	The hardware of the installed memory card is defective.	Replace the memory card with a new one.

- (5) Directory tree in a memory card
The directory tree in a memory card is shown as follows.

(File structure)



- (a) The copied screen data is stored under the UserData folder.
Since the OS and screen data are managed by the Dlist.ini file and the Flist.ini files in the corresponding folders, always install or download the GT Designer2 OS (specify the memory card as the download destination) to create the memory card.
If Explorer or like in the personal computer is used to copy the OS, the GOT cannot recognize the data in the memory card.
- (b) Do not edit the screen data in the memory card directly using GT Designer2.
When edit the screen data, use the following method.
- Connect the GOT to a PC with the RS-232C cable and edit the uploaded screen data.
 - Copy the data in the memory card to a PC and edit the data.
- (c) When copy a file (alarm history data, recipe data) in the memory card to a PC or delete it, install the memory card to the PC and copy/delete the file by the Explorer.
- (d) The SRAM type memory card can be formatted on the GOT.
Check the memory card with the self-diagnostics of the utility function.
When the memory card is checked, the memory card is formatted after the check.
The compact flash PC card cannot be formatted on the GOT.
Use the personal computer to format it.
For the way to format the memory card, refer to the GT Designer2 Version2 Operating Manual.
- (e) The dat format file is used in the GOT system.
There fore, the user must not create the file with the extension of "dat".





You cannot use this function to install the OS (from memory card to internal memory).
For details of OS installation, refer to the GT Designer2 Version2 Operating Manual.


4.5 Setup



After changing any of the items in Setup, touching automatically resets the GOT and shows the monitor screen.

- (1) Display screen
The display screen differs with the GOT used.

GOT Used	Screen Example
<p>A97*GOT/ A960GOT</p>	 <p>This screen example assumes that the communication driver "Computer" has been installed.</p>
<p>A985GOT (-V)</p>	 <p>This screen example assumes that the communication driver "Bus (Q)" has been installed. A video window (channel, etc.) and RGB screen (H-Position, etc.) may be set only when the A985GOT-V is used.</p>

GOT Used	Screen Example	
A95*GOT		
<p>This screen example assumes that the communication driver other than "Bus(A, QnA)" has been installed. The grip switch setting and grip switch cancel-time key OFF setting are available only for use of the A950 handy GOT.</p>		

(2) Functions

(a) Data that can be set on any GOT

- Buzzer volume
You can select the length of the beep sound.(Factory-set to SHORT)
- Outside speaker sound
You can select whether or not voice output is provided from the external speaker (only the voice specified for the touch input sound on the GT Designer2).
(Factory-set to OFF)
- Screen save time
Set the time until the monitor screen display is switched off by the screen saver function.
You can set the time between "00 minutes" and "60 minutes".
When this setting is "0", the monitor screen is always displayed.(Factory-set to 0)
- Screen save light
When this setting is OFF, the backlight goes off as soon as the display is erased by the screen saver function.
When this setting is ON, the display will disappear but the backlight will not go off.
- Language
You can select the language (Japanese or English) of the messages to be displayed on the screen. (Factory-set to Japanese)



As message display languages, four languages (Japanese/English/Chinese (simplified characters)/Chinese (traditional characters)) are available for some system dialogs, while two languages (Japanese/English) are available normally. (Refer to Section 3.10, Section 32.)

1	OVERVIEW
2	BEFORE BEGINNING OPERATION
3	SPECIFICATIONS
4	OPERATING THE UTILITY FUNCTION
5	OPERATING LADDER MONITOR
6	OPERATING THE VARIOUS LADDER MONITOR SCREENS
7	ERROR MESSAGES FOR LADDER MONITOR
8	OPERATING SYSTEM MONITOR

- (b) Data that can be set when the corresponding communication driver is installed
- 1) When communication driver for bus connection (Q) is installed
 - QBUS extension number
Set the GOT extension number for bus connection to the QCPU.
(Factory set to extension 7)
 - QBUS slot number
Set the slot number where the GOT is assigned for bus connection to the QCPU. (Factory set to slot 0)
 - 2) When communication driver for microcomputer connection is installed
 - Microcomputer connection baud rate
You can select the transmission speed when the GOT is connected to a microcomputer.(Factory-set to 19200)
 - Microcomputer connection communication form
You can select the protocol when the GOT is connected to a microcomputer.(Factory-set to FORM-1)
 - 3) When communication driver for computer link connection (AJ71QC24) is installed
 - QC24 Baud rate
Set the transmission speed for connection with the QC24N.
(Factory-set to 19200bps)
 - 4) When communication driver for OMRON/Hitachi PLC connection is installed
 - Baud rate
Choose the transmission speed for connection with the Omron or Hitachi PLC. (Factory-set to 19200bps)
 - 5) When communication driver for Yasukawa PLC connection is installed
 - Baud rate
Choose the transmission speed (4800, 9600, 19200, 38400).
(Factory-set to 19200bps)
 - Startup time
Set when (seconds) to start communication with the PLC CPU after power-on of the GOT.
(Factory-set to 16 seconds for the GL series or 1 second for other than the GL series)
 - Send message delay
Set the waiting time from when the GOT has received data from the PLC CPU until the GOT send the next data to the PLC CPU. (Factory-set to 0msec)
 - 6) When communication driver for SIEMENS PLC connection is installed
 - Baud rate
Choose the transmission speed (4800, 9600, 19200, 38400).
(Factory-set to 19200bps)
 - Adapter address
Specify the MPI address on PROFIBUS assigned to the HMI adaptor connected to the GOT. (Factory-set to 2)
 - Host (FF) address
Specify the MPI address on PROFIBUS assigned to the HMI adaptor connected to the GOT. The specified PLC CPU is the "host" when monitor device setting is made on GT Designer2.
For details of monitor device setting, refer to the GT Designer2 Version2 Reference Manual. (Factory-set to 2)

- 7) When communication driver for Allen-Bradley PLC connection is installed
- Baud rate
Choose the transmission speed (4800, 9600, 19200, 38400).
(Factory-set to 19200bps)
 - Adapter address
Set the address on the DH-485 network assigned to the HMI adaptor connected to the GOT. This setting is required only when multiple CPUs are connected to the GOT. Set the same address as the DH-485 Node Address specified for the adaptor. The DH-485 Node Address specified should not overlap the Node Address of the PLC on the DH-485 network. (Factory-set to 1)
 - Host (FF) address
Specify the address on the DH-485 network assigned to the PLC CPU to which the HMI adaptor is connected. The specified PLC CPU is the "host" when monitor device setting is made on GT Designer2. For details of monitor device setting, refer to the GT Designer2 Version2 Reference Manual. (Factory-set to 1)
- 8) When communication driver for Matsushita Electric Works PLC connection is installed
- Baud rate
Choose the transmission speed (4800, 9600, 19200, 38400).
(Factory-set to 19200bps)
 - Startup time
Set when (seconds) to start communication with the PLC CPU after power-on of the GOT.
(Factory-set to 0msec)
 - Send message delay
Set the waiting time from when the GOT has received data from the PLC CPU until the GOT send the next data to the PLC CPU. (Factory-set to 3msec)
 - C.C.U monitor registration
Choose whether CCU monitor registration is made or not. When multiple GOTs/peripheral devices are connected to one CPU via the C.C.U., up to one unit(When the CPU is the FP10SH, up to five units can be set) can be registered for C.C.U. monitor. When two or more GOTs are used or they are used with peripheral devices together, set "No" for C.C.U. monitor registration.
- 9) When communication driver for Ethernet connection is installed
- 10) When extended function OS for gateway functions is installed

11) When A9GT-J71E71-T module is connected

- GOT NET No.
Set the network number of the GOT. (Factory-set to 1)
- GOT PC No.
Set the station number of the GOT.
Do not set the same number as the PC No. of the Ethernet module to be monitored.
(Factory-set to 1)
- GOT IP address
Set the IP address of the GOT.
- GOT port No.
Set the port number of the GOT. (Factory-set to 5001)
- Router address
When the network is connected to the other network by a router, set the router address of the network where the GOT is connected.
(Factory-set to 000.000.000.000)
- Sub-net mask
When the GOT is connected to the Ethernet network which is controlled the sub-network, set the sub-network mask set commonly to the networks. When the sub-network is not used, operation is performed at the default value. (Factory-set to 255.255.255.000)
- Send message wait
Set the transmission wait time to reduce loads on the network and target PLC. (Factory-set to 0)
- Send message time
Set the time-out period. (Factory-set to 3)
- Startup time
Set when (seconds) to start communication after power-on of the GOT. (Factory-set to 3msec)

12) When communication driver for CC-Link connection (CC-Link (ID)) is installed.

- Send message time
Set the time-out period. (Factory-set to 3)

(c) Data that can be set when the specific GOT is used

1) Setting of display mode (may be made for the A95*GOT-LBD(-M3) only)

▪ Reverse display

The display mode (normal display (No)/highlighted display (Yes)) is selected. (Only A95*GOT-LBD (-M3) can be selected. Normal display is set at the time of shipment.)

2) Setting of human sensor (may be made for the A985GOT(-V) only)

▪ Screen save Human sensor

You can select whether the screen saver is deactivated or not when the Human sensor has detected a man's motion. (Available for the A985GOT only, factory-set to Invalid)

▪ Human sensor detection sensitivity

You can select the detection sensitivity of the Human sensor in any of 11 steps, levels 0 to 10, so that the sensor will not detect a motion such as a man passing before the GOT. (Available for the A985GOT only, factory-set to 10)

Detection sensitivity setting	10	9	8	7	6	5	4	3	2	1	0
Monitor time [sec]	0	0.1	0.2	0.4	0.8	1	1.5	2	2.5	3	4

▪ Human sensor OFF delay

The Human sensor can be turned off when it does not detect a man's motion after it has turned on. You can set that period between "00 min. 10 sec." and "60 min. 00 sec.". (Available for the A985GOT only, factory-set to 00 min. 10 sec.)

3) Setting of grip switch (may be made for the A950 handy GOT only)

▪ Grip switch

You can set whether the grip switch will be used or not.

When the setting is USE, hold down the grip switch and perform operation.

Setup and self-diagnostic operations can be performed independently of the grip switch. (May be set only for the A950 handy GOT, factory-set to USE)

▪ If it is released

You can set whether the touch key pressed on the GOT display will be turned off or not at the time of grip switch cancel.

At the setting of "NO ACTION", the pressed touch key is turned off when it is released. (May be set only for the A950 handy GOT, factory-set to KEY OFF)

4) Setting of video window (may be selected only when the A9GT-80V4 is fitted to the A985GOT-V)

▪ Channel

You can choose the video channel for which video window settings are made.

The settings can be made per video channel.

▪ Signal

You can choose the video picture input system (NTSC/PAL).

▪ Video width

You can choose the video window resolution (720_480 dots/640_480 dots)

▪ Color balance/contrast/brightness/color power

You can adjust the contrast, brightness and others of the video picture displayed on the GOT. (May be selected only when the A9GT-80V4 is fitted to the A985GOT-V, factory-set to 50%)


5) Setting of RGB screen (may be selected only when the A9GT-80R1 is fitted to the A985GOT-V)

- Clock phase
You can adjust the flicking of the RGB screen displayed on the GOT.
- H-Position/V-Position
You can adjust the position of the RGB screen displayed on the GOT.
- RGB close key
You can select which position of the screen to touch to switch from the RGB screen to the GOT monitor screen.
You can also turn on/off the bit device (RGB display controlling bit) to switch the screen.
For the RGB display controlling bit, refer to the GT Designer2 Version2 Reference Manual.
(Factory set to FULL)

Point 

- If the touch panel is not touched within the specified time, the screen saver function switches off the display to prevent "burn-in" of the display device. Especially for the display screen type of EL, it is recommended to use this function.
- Dedicated to the A985GOT, the Human sensor function automatically deactivates the screen saver, without any touch on the touch panel, by means of a signal detected by the Human sensor.
- Using the system information function of the GOT, the signal detected by the Human sensor may also be controlled by the PLC CPU. For full information on the system information function, refer to the GT Designer2 Version2 Reference Manual.

Signal detection timings are shown below.



(3) Operation

(a) Basic operation


- Touch  or  to select the necessary item.
- When the A985GOT, A950 handy GOT is used, select the last item on Page 1/2 and touch  to show Page 2/2.
- For the setting item whose value will be changed, highlight the digit to be set by touching  , and set the value by touching  or .
(If you are going to select another setting item after that, return the highlight to the setting item by touching , and make selection by touching  or .)
- After setting, touch .
After touching , the GOT is automatically reset and the monitor screen appears.

(b) Return to each screen

- If any change has been made to the Setup settings, touching  resets and restarts the GOT.
- If any change has been made to the Setup settings, touching  resets and restarts the GOT.
The display returns to the utility menu or monitor screen.

4.6 Self-Test

(1) Display screen



(2) Features

Diagnostic checks on GOT hardware include the following options:

- Graphic Check Allows you to perform visual inspection on screen display for discoloration and lack of display.
- Fontrom Check Allows you to perform visual inspection for deformation in font size. The font changed by the font change function can be also checked. For changing fonts, refer to Section 31.
- Memcard Check..... Allows you to make a check on the hardware of a memory card. After checking, a memory card are initialized.
- Userrom Check..... Allows you to check for user space in the internal memory. The password must be entered to check the user area of the built-in memory. The password is "1111" (fixed). (The entered password is displayed as "*****" on the screen.) After checking, user space is cleared to delete any data contained in the user space.
- OS Area Check..... Allows you to check for OS space in the internal memory.
- Comm. Check..... Allows you to check for GOT-to-PLC CPU communications.
- Touchsw Check..... Allows you to check for touch keys.

The GOT performs these checks.

(3) Procedure


(a) Basic operation

- Select the desired button to perform a diagnostic check.
- Select options as instructed on-screen.
- You will see a message indicating that the selected diagnostic check was successfully completed.
- If an error is detected, you will see a message indicating the occurrence of the error.
- The Image Check allows you to view the following elements:
 - 1) The entire screen is displayed in one color. Display colors are changed in the order of red-green-blue.
 - 2) Basic figures are displayed, including circles and squares.
 - 3) Ellipses and checkered patterns are tiled or cascaded on-screen.

4.7 Memory Information

(1) Display screen

Sample screen



(2) Features

The contents of GOT memory information include:

- OS version number
- Status of communications with the PLC CPU
- Available space in the internal memory
- Availability of memory cards and available space in a memory card
- Availability of the ladder monitor function

(3) Procedure

(a) Basic operation

Touch ▲ ▼ to scroll screens.

(b) To return to the Utility Menu screen


Touch ☐ to return to the Utility Menu screen.

4.8 Clock

(1) Display screen

Sample screen

Sample screen



* The time when the Clock Settings screen was displayed is shown in the window panel. The time indicator in the upper-right corner of the screen shows the current time. After correcting the date or time, check the clock for the current time.

(2) Features

- The date, time, and a day of the week can be set to adjust the clock of the PLC CPU and the A9GT-RS2T.

(3) Procedure

(a) Basic operation

- Touch to select the desired option.
- Touch or to change numeric values.
- Touch or to change the numerical values in increments of 10.
- Touch to set the clock of the PLC CPU.

(b) To return to the Utility Menu screen

- Touch to return to the Utility Menu screen.

Point

- Adjust the clock when you start up the system.
- The clock cannot be properly adjusted while reading or writing clock data by running sequence programs on the PLC CPU side (or when M9028 is turned on by sequence programs in the case of the ACPU).
- Selecting the clock setting screen (above screen) within the utility displays "This function can't be used now.", when connected to the PLC CPU that does not include the clock function.
For the PLC CPUs that include the function, refer to the GT Designer2 Version2 Reference Manual.

4.9 Screen Cleanup

(1) Display screen




(2) Features

- A black screen is displayed when cleaning up the display area. This makes the screen easy to view.

(3) Procedure

(a) Basic operation

- Touch the upper right and left corners of the screen at the same time to return to the Utility Menu screen.



4.10 Security Password

(1) Screen display



(2) Features


- If objects (numeric input or touch keys, etc.) are secured by using GT Designer2, their security levels can be changed by entering a password.
- If the characters entered match a password, a message appears on-screen, telling that the security levels have been properly changed. Touching  will return to the Utility Menu screen.
- If the characters entered do not match a password, an error message appears on-screen. Touching  will return to the Utility Menu screen.
- Numerical numbers and alphabets  to  can be used for a password.
- Details about security levels, see the GT Designer2 Version2 Reference Manual.

(3) Procedure

- To enter a password, follow these steps:
 - Touch  to  and  to  to enter a password.
 - Touch  to confirm the password entered.
 - To correct the password entered, touch  to delete wrong characters and enter correct characters again.
- (a) To quit entering a password:
 - Touch  to return to the previous monitor screen.

4.11 Password

(1) Screen display



(2) Features

- Password protection can be set on the GOT by using GT Designer2. If access to the Utility Menu screen is password-protected, a screen asking you to enter a password is displayed when you touch the upper right and left corners of the screen or when you touch a touch key on the screen. A dialog box for defining a password is contained in the common settings menu of GT Designer2.
- If the characters entered match a password, the Utility Menu screen appears.
- If the characters entered do not match a password, an error message appears on-screen.
Touching **Exit** will return to the previous monitor screen.
- Numerical numbers and alphabets **A** to **F** can be used for a password.

(3) Procedure

(a) To enter a password, follow these steps:


- Touch **0** to **9** and **A** to **F** to enter a password.
- Touch **Enter** to confirm the password entered.
- To correct the password entered, touch **DEL** to delete wrong characters and then enter correct characters again.

(b) To quit entering a password:

- Touch **Exit** to return to the previous monitor screen.

4.12 Brightness/Contrast Adjustment

(1) Display screen



(2) Function

- Adjust the brightness of the monitor screen.

(3) Operation

(a) Basic operation

- The basic operation differs depending on the GOT.

(b) Brightness/contrast adjustment

For screen 1)

- Touch  to select the brightness.
- Touch  to adjust the contrast.
- Touch  to store the settings into the GOT.

For screen 2)

- Touch  to select the brightness.
- Touch  to store the setting into the GOT.

For screen 3)

- Touch  to adjust the contrast.

Every time CONTRAST is touched, the setting is stored into the GOT.

For screen 4)

- Touch  to adjust the contrast.
- Touch  to store the setting into the GOT.

(c) Returning to the utility menu screen

- Touch  to return to the utility menu screen.

Point

Some GOTs display the brightness adjustment switch on the screen though they cannot use the brightness adjustment function.

The brightness adjustment switch can be hidden in the following method.

(1) Corresponding GOTs

Type : A975GOT-TBA, A970GOT-TBA

Serial number : 9806AA to 9807AA

Confirm the serial number in the DATE field of the product rating plate.

(2) Method

Install the system programs into the GOT.

Install all system programs (except ROM_BIOS) that have been installed into the target GOT. The system programs installed in the GOT can be confirmed in the following method.

1) Confirmation on the GOT

You can confirm the system programs in the memory information of the utility function.

2) Confirmation from GT Designer2

You confirm the system programs in the built-in memory information of GT Designer2.


Refer to GT Designer2 Version2 Operating Manual for details of the built-in memory information.

5 OPERATING LADDER MONITOR

The operation procedures to follow when using the ladder monitor function are explained in the following section.


5.1 Operation procedures before starting ladder monitoring

This section contains a summary of the procedures for transmitting the system program (OS) for the ladder monitor function from the personal computer to the GOT until it is installed in the built-in memory. For details, please refer to the GT Designer2 Version2 Operating Manual. Details of the screen display and key operation are shown in the Help.



5.2 Operation procedures from display of user-created monitor screen to start of ladder monitoring

This section shows the operation procedures for the GOT when starting each operation of the ladder monitor function after the ladder monitor function system program (OS) has been installed in the GOT built-in memory.



- *1 The ladder monitor function can be started in either of the following two methods.
 Starting from the touch key Touch the touch key where the extension key (ladder monitor) has been set.
 Starting from the utility menu of the GOT Touch **LADDER MON.** in the utility menu.

6 OPERATING THE VARIOUS LADDER MONITOR SCREENS

The following sections describe each screen operation when using the ladder monitor function. The screens used for explanations in this chapter are mainly those of the A975GOT. The ladder monitor display screen varies slightly with the GOT used. Refer to Section 6.1 for differences between the display screens.

6.1 Display screens

The ladder monitor display screen varies with the used GOT and target PLC CPU.







(1) MELSEC-A/FX ladder monitor

Used GOT	PLC read screen	Ladder monitor screen
A985/ A97*/ 960GOT		<ul style="list-style-type: none"> • Sequence program : Max. 8 lines (1 line: Max. 11 contacts) displayed • When the display screen type is the EL, the [Print Screen] and [Cancel Print] keys are not displayed.

(2) MELSEC-QnA ladder monitor

Used GOT	PLC read screen	Ladder monitor screen
A985/ A97*/ 960GOT		<ul style="list-style-type: none"> • Sequence program : Max. 8 lines (1 line: Max. 11 contacts) displayed • When the display screen type is the EL, the [Print Screen], [Cancel Print], [JUMP] and [JUMP] keys are not displayed.

(3) MELSEC-Q ladder monitor

Used GOT	PLC read screen	Ladder monitor screen
A985GOT		 <ul style="list-style-type: none"> Sequence program : Max. 15 lines (1 line: Max. 11 contacts) displayed
A97*/960 GOT		 <ul style="list-style-type: none"> Sequence program : Max. 8 lines (1 line: Max. 11 contacts) displayed When the display screen type is the EL, the [Print Screen], [Cancel Print], [JUMP↑] and [JUMP↓] keys are not displayed.
A956W GOT	 <ul style="list-style-type: none"> Headings are not displayed in the file list. 	 <ul style="list-style-type: none"> Sequence program : Max. 5 lines (1 line: Max. 7 contacts) displayed. The [Print Screen] and [Cancel Print] keys are not displayed.

1 OVERVIEW
 2 BEFORE BEGINNING OPERATION
 3 SPECIFICATIONS
 4 OPERATING THE UTILITY FUNCTION
 5 OPERATING LADDER MONITOR
 6 OPERATING THE VARIOUS LADDER MONITOR SCREENS
 7 ERROR MESSAGES FOR LADDER MONITOR
 8 OPERATING SYSTEM MONITOR

6.2 Screen operation and screen changes when monitoring

This section includes an explanation of the PLC read operation that reads out the sequence program from the PLC CPU when executing the ladder monitor, the ladder read operation that specifies the sequence program to be displayed on the ladder monitor screen, and the screen movement when executing the ladder monitor.

6.2.1 Reading data from the PLC

The operation of reading the sequence program for the ladder monitor from the PLC CPU is described below.


The operation procedures vary depending on the PLC CPU to be monitored.

All of the keys used with the operation are touch keys displayed on the screen.


Touch the position where the object key is displayed and enter the data.

- (1) When the MELSEC-A/FX ladder monitor is executed

[Operation procedure]



LADDER MON. (Touch)



To the following page

- 1) Touch the ladder monitor starting touch switch on the monitor screen prepared by the user or touch the **LADDER MON.** on the utility screen to start the ladder monitor function.


- 2) Specify the network No. and station No. for the object PLC CPU.

(For data link system, CC-Link system)


NET NO : 0
 : FF (Own station)
 READ ST. : 0 (Master station)
 : 1 to 64 (Local stations)

(For network system)

NET NO : 1 to 255 (Host Net)
 : 0 (Master station)
 READ ST. : FF (Own station)
 : 1 to 64 (Control station)
 : 1 to 64 (Normal station)



- 3) In "Read Selection", specify the sequence program to be read from the object station. Specify whether or not to perform comment read.
- 4) Input the keyword that is registered to that station. If no keyword has been registered, nothing has to be entered.
- 5) The contents and capacity of the read procedure are displayed. When you touch **Break**, the read procedure is interrupted. When reading resumes, it starts at the beginning.
- 6) "Completed" is displayed.



Change screen.

*1 Data being entered can be cleared by the following keys.

Exit : Moves to screen where ladder monitor function starts.

AC : Clears all data being entered to the object area.

DEL : Clears one character at the cursor position.

Ladder : Moves to ladder monitor screen.


PLCRD. : Moves to PLC read screen.



Once this data has been read from the PLC, it does not need to be read again. If data for screens created by the user is downloaded from the computer after this data has been read, however, the data will have to be read again.

(2) When the MELSEC-Q/QnA ladder monitor is executed


[Operation procedure]



- 1) Touch the ladder monitor starting touch switch on the monitor screen prepared by the user or touch the **LADDER MON.** on the utility screen to start the ladder monitor function.

Point

If ROM_BIOS is not installed, an error message is displayed. Touch the **END** button and install the ROM_BIOS (H version or later).



- 2) The key window is displayed. Set the network No./station No. / CPU No.*1 of the applicable PLC CPU with the following keys.

- : Select the input area.
- Alphanumeric** : Input the network No. and the station No.
- AC** : Clear all input data to the applicable area.
- : Define the input.

Point


Designate the network No./ the station No. and CPU No.*1 of the applicable PLC CPU.

(For CC-Link system)
 Network No. : 0
 Station No. : 0 (mask station)

(For network system)
 Network No. : 1 to 255 (self-loop)
 Station No. : 1 to 64 (control station)
 1 to 64 (normal station)

(For Ethernet connection)*2
 Network No. : 1 to 239
 Station No. : 1 to 64


(For multi-CPU system)
 CPU No. : 0 to 4 (CPU number)



- 3) The PLC read screen appears.
 First, touch the **Set Up** key to display the setting window.

To the following page


From the previous page




4) The setting window appears.

Make the setting for initial ladder monitor start.

Touching the **MEMORY** key changes the setting choice as indicated below.




After the setting is over, touch the button.



5) Then, touch the **Drive** key to select the drive (applicable memory) which stores the applicable ladder data to be monitored.


To the following page

From the previous page



6) The Drive Selection Window is displayed. Select the drive (applicable memory) with the following keys.

- to : Input the drive number.
- : Clear all input data on the drive.
- : Define the input.




7) The file list of the selected drive is displayed. Select the ladder to be read with the following keys.

- : Move the cursor upward.
- : Move the cursor downward.
- : Display the previous page.
- : Display the next page.
- : Move the cursor and touch the key to change select (*)/cancel.
- : Start reading the selected ladder.

Point

- MELSEC-Q ladder monitor
When a password is registered at the PLC CPU, a file password window is displayed at the start of reading. Input the password. (It does not have to be input if it is not registered.)
- MELSEC-QnA ladder monitor
When a keyword is registered at the PLC CPU, a key window is displayed at the start of reading. Input the keyword. (It does not have to be input if it is not registered.)



8) Contents and capacity of the reading process are displayed.

Touch to stop the reading process.

To read the ladder again, start from the beginning.

9) When the message "Completed" is displayed, reading is completed. Change the screen with the following keys.

- : Move to the screen when the ladder monitor is started.
- : Move to the ladder monitor screen.
- : Start from setting window (2) for the network No. /station No.


Point

Once PLC reading is performed, operations for PLC reading are not required from the next time onward.

6.2.2 Ladder read operation

This section describes the object sequence program of the ladder monitor that is read from the PLC CPU, for the operation displayed on the ladder monitor screen.


[Operation procedure]



* When there is a  at the upper left of the screen, touch it to return to the original screen.

MENU (Touch)

When the screen below is currently displayed, it is not necessary to touch this.





The ladder read operation is executed.

When specifying and reading the device, contact point or coil used in the program (*4)

(Touch any of these.)

(When entering device name)

(When entering device No.)




: Select input area.
 Alphanumeric: Enter device name and device No.
 (*1)

1)



Move to ladder monitor screen (*2)

(Touch: Input confirmation)



*1 Data being entered can be cleared by the following keys.

AC : Clears all data being entered to the target area.

DEL : Clears one character at the cursor position.


*2 When specifying and reading a device, contact point or coil used in the program, the search targets all programs starting from the step number displayed on the previous ladder monitor screen, to the program immediately previous to the one displayed.

After moving to the screen monitor screen, continuous reading by the same device is enabled by touching on the screen.


If you touch any other key but , the continuous read function is canceled.

*3 When device search, contact point search, or coil search is performed during ladder monitoring, only the ladder block which includes the read search device is displayed.

Example) 1) When the device name to be searched is entered as "X0001"



2) When the same search is repeated



*4 Please note that the indirect specification device (index register (z)) cannot be specified and read while the MELSEC-QnA ladder monitor is executed.

6.2.3 Using the defect search


The defect search enables you to examine a ladder block that caused a failure. It helps you to search from the ladder block backward so that you can determine why any coil was turned ON or OFF during the ladder monitoring, or whether its contact is conductive or nonconductive.



While the MELSEC-QnA ladder monitor is performed, the factor search function cannot be used.

(The touch key of **Fact.Sea.** is not displayed.)

[Operation procedure]



- (1) Search for and display a ladder block where a failure occurred.
Example: When a valve connected to Coil Y0030 does not operate properly, begin searching for Coil Y0030 and view its ladder block on the screen.

- (2) Touch **Mon.** to start the ladder monitoring.

- (3) Touch **Menu** and then select **Fact.Sea.** from among options that appear on-screen.

If you touch **Fact.Sea.** without executing the ladder monitor function, operation changes depending on the type of the ladder monitor used.

For MELSEC-A ladder monitor: The "No MONITORING" message appears and the following operation cannot be performed.
(Operation is enabled after execution of monitor.)

For MELSEC-Q ladder monitor: Monitor is executed automatically and the following operation is enabled.
After termination of a defect search, monitor stops automatically with the search result retained.

- (4) Another dialog box where you can specify a device name or device number is displayed on-screen. Specify any contact of which coil is not turned ON as a search device.
Example: Specify "M120" as the search device.

		: Used to select a data entry field.
Alphanumeric: Used to enter a device name or device number. *1		
	: Used to stop the defect search, returning to the ladder monitor screen.	

*1 Use the following touch keys if you want to delete any data entry:

AC : Clears all the data entered in a specific field.

DEL : Clears one character at the cursor position.

- (5) Start searching for a device that caused a failure and view search results on the ladder monitor screen. Search from the last step number backward as displayed on the ladder monitor screen.

Please note that any touch keys other than **Esc** and **Exit** are enabled until the defect search is completed.

[Search results]


Search results reveal any occurrences of the search device. They are useful when you determine whether a defective device is conductive or nonconductive.

If any occurrence of the search device is not found as a result of the search, a message appears on-screen, telling that "PROGRAM NOT FOUND."


- (1) When an occurrence of the search device is found:

If an occurrence of the search device is found as a result of the search, the search for another defective device will automatically be started.

Example: After searching for Device M120 that is in the OFF state, "M669" will be displayed as a device that caused a failure.



(This automatically begins searching for the defect that caused M669 to be turned OFF.)



(This automatically begins searching for the defect that caused M111 to be turned OFF.)

A search for another defect is repeated.

After searching for Coil M120 that is in the OFF state, "M669" is displayed as a device that is not conductive.

Example: 6 9L

* After searching for a device that is in the ON state, a device that is conductive is displayed. The entire field of the device name and number is highlighted on-screen.


Example: 1

After searching for Coil M669 that is in the OFF state, "M111" is displayed as a device that is not conductive.

Example: 1 11

- (2) When two occurrences of the search device are found.
If there are two or more devices that caused a failure, the "the defect search is interrupted" message appears and the defect search is terminated.

Example: After searching for Device M120 that is in the OFF state, "M669" and "X0025" will be displayed as devices that caused a failure.



After searching for Coil M120 that is in the OFF state, "M669" and "X0025" are displayed as devices that are not conductive.

Example: 6 9L, 0 2

* After searching for a device that is in the ON state, devices that are conductive are displayed. The entire field of the device name and number is highlighted on-screen.

Example: 1,

When resuming the defect search, specify either of the found contacts M669 and X0025.
(After touching **Esc** to change it into **Menu**, execute the defect search.)

(3) Precautions for making defect search

- (a) If a B-contact is found defective as a result of the defect search, a search for the cause of the ON/OFF state will be automatically switched.
- (b) After the end of the defect search, the GOT stops monitor and displays the search result. Hence, the monitor screen of the GOT shows the result retained during the defect search.
- (c) While the search result is displayed after the end of the defect search, the searched ladder can be displayed backwards by pressing (single ladder block scroll) or (10 ladder block jump (available for only the MELSEC-Q ladder monitor function)). Up to 100 ladders can be displayed on-screen. The following messages will appear at the start or the end of the search results.
- When viewing the start of search results: "This is the start of search results."
 - When viewing the end of the search results: "This is the end of search results."
- (d) The ON/OFF of the contact and coil is displayed as described below.
- 1) During automatic search execution
 - MELSEC-A ladder monitor: Displays ON/OFF in the entire ladder displayed on the screen.
 - MELSEC-Q ladder monitor: Displays ON/OFF in the ladder displayed last.
 - 2) During search result display
 - The ON/OFF of the ladder block searched last and the monitor results of word devices are displayed.
- (e) When the defect search starts, changes into .
- Touch during the defect search to stop the defect search and display the search result.
- Further, touch to change into and display the normal ladder.
- (f) The screen during the defect search operates as described below.
- 1) If the display data exceeds one screen during the defect search
 - The screen is scrolled automatically.
 - 2) If the ladder step searched during the defect search exceeds one screen
 - MELSEC-A ladder monitor: The screen is scrolled automatically to the last line of the ladder step.
 - MELSEC-Q ladder monitor: The screen is not scrolled automatically to display the ladder step.
- (g) Touching can stop the defect search. Search results are continuously displayed on-screen until is touched.
- The ladder step searched last is displayed as described below.
- MELSEC-A ladder monitor: ON/OFF display is not provided.
 - MELSEC-Q ladder monitor: ON/OFF display is provided.

6.2.4 Touch search operation

A touch search is the function designed to search for the coil of a device when its contact displayed in the ladder monitor is touched and to search for the contact of a device when its coil is touched.

A search can be made from the beginning of a ladder to its last step.


This function is always valid when a normal ladder is displayed.




- The touch search function cannot be used when MELSEC-A/FX/QnA ladder monitor is executed.
- The function cannot be used for instructions other than contacts and coils and for word devices.
- When the defect search function is in use, the touch search function cannot be used.

(Touch **Esc** to terminate the defect search.)


[Operation procedures (when contact is touched to search for coil)]



(1) Touch the contact on the ladder monitor screen.




(2) The coil of the device whose contact was touched is searched for, and the single ladder block including the coil found is added to the display.
(The found device is highlighted.)




(3) Touch **↓** to search the ladder downward continuously.

[Operation procedures (when coil is touched to search for contact)]


(1) Touch the coil on the ladder monitor screen.



(2) The contact of the device whose coil was touched is searched for, and the single ladder block including the contact found is added to the display.
(The found device is highlighted.)




(3) Touch  to search the ladder downward continuously.



6.2.5 Changing from one screen to another

This section describes the screen movements when executing the ladder monitor from the status where the user-created monitor screen is displayed.



*1 Touch the key where the touch switch (expanded) function was set with the GT Designer2, and start the system monitor function.

When the Utility screen is displayed, touch **LADDER MON.** to start the system monitor function.

The system monitor function and special module monitor function can also be started from the Utility screen.

6.3 Ladder monitor

The ladder monitor screen display and the keys that are shown at the top of the screen are explained in this section.


6.3.1 Ladder monitor screen display and key functions

The ladder monitor screen varies depending on the type of PLC CPU to be monitored.



After executing PLC read, if the PLC CPU comment or comment capacity is changed, the comment may not be correctly displayed on the ladder monitor screen.
When changing the comment or comment capacity, re-start the GOT.

- (1) When MELSEC-A/FX ladder monitor is executed
(a) Display



When comment is not displayed : maximum 8 lines
When comment is displayed : maximum 3 lines

ON/OFF status display for ladder monitor

- ON status
- OFF status

* The MCR command is normally displayed as

1)	Sequence program is displayed. A maximum of 11 contact points is displayed in one line of a ladder; for 12 contact points or more, move to the next line. When a comment display is specified, a comment is also displayed; expanded comments are given priority (For the method of displaying comments, see Sec. 6.3.3.).
2)	A maximum of eight devices is displayed for the word device current value, timer and counter current value (upper row), and set value (lower row). When the set value is an indirect specification, the value of the indirectly specified device is displayed. (To switch between decimal and hexadecimal for the displayed value, see Sec. 6.3.3.).
3)	Display the keys used with the operation on the ladder monitor screen shown in (b) (Touch input).
4)	The display step number (left) and the remaining step number (right) are displayed.


- (b) Key functions

This table shows the key functions used with the operations on the ladder monitor screen.

Key	Function
	Return to screen where ladder monitor function starts.
	Move to PLC read screen to read sequence program being monitored from PLC CPU (PLC read).
	Move to ladder monitor menu screen, to specify sequence program to be displayed on ladder monitor screen (Ladder read).
	Start monitoring of sequence program that is displayed on ladder monitor screen.
	Activates the List editor function. (For details of the List editor function, see Chapter 19.)
	Switch display device when there are nine or more devices displaying current values and set values.
	Display one ladder; scroll up or down.
	When reading ladder with device specification, read next program with same device specification (see *2 in Sec. 6.2.2.).

(2) When MELSEC-Q/QnA ladder monitor is executed

(a) Display



When comment is not displayed : maximum 8 lines
 When comment is displayed : maximum 3 lines

ON/OFF status display for ladder monitor

- ON status
- OFF status

* The MCR command is normally displayed as

1)	Sequence program is displayed. A maximum of 11 contact points is displayed in one line of a ladder; for 12 contact points or more, move to the next line. *1 When a comment display is specified, a comment is also displayed; expanded comments are given priority (For the method of displaying comments, see Sec. 6.3.3.).
2)	A maximum of eight devices is displayed for the word device current value, timer and counter current value (upper row), and set value (lower row). When the set value is an indirect specification, the value of the indirectly specified device is displayed. (To switch between decimal and hexadecimal for the displayed value, see Sec. 6.3.3.).
3)	Display the keys used with the operation on the ladder monitor screen shown in (b) (Touch input). *2
4)	The network No., the station No. and CPU No. are displayed.
5)	The drive is displayed.
6)	The file name of the PLC program is displayed.
7)	The total number of steps in the current monitor PLC program is displayed.

*1 Depending on the GOT model, a display is provided on the MELSEC-Q ladder monitor screen as indicated below.

- A985GOT: Max. 15 lines displayed (1 line: Max. 11 contacts)
- A956WGOT: Max. 5 lines displayed (1 line: Max. 7 contacts)

*2 When the A985GOT or A956WGOT is used, the operation keys appear on the right side of the MELSEC-Q ladder monitor screen.

(b) Key functions

This table shows the key functions used with the operations on the ladder monitor screen.

Key	Function
	Return to screen where ladder monitor function starts.
	Move to PLC read screen to read sequence program being monitored from PLC CPU (PLC read).
	Move to ladder monitor menu screen, to specify sequence program to be displayed on ladder monitor screen (Ladder read).
	Start monitoring of sequence program that is displayed on ladder monitor screen.
	Switch display device when there are nine or more devices displaying current values and set values.
	Display one ladder; scroll up or down.
	When reading ladder with device specification, read next program with same device specification (see *2 in Sec. 6.2.2.).
	Displays the search history of the device/contact/coil search or touch search one place backward.
	Scrolls the display up or down by ten ladders.


About the  key

- Immediately after the  key has been pressed to go back in the history, a continuous device search using the  key cannot be executed.
- Using the  key, you can go back into the history up to 100 ladders.
- When any of the following operations is performed, the search history is cleared to return to the normal ladder display.
 1. When the   key is touched
(When a single ladder block takes up more than one screen, scrolling can be made within the block.)
 2. When the   key is touched
 3. When a step search, END search or defect search is executed
 4. When a comment display is changed
 5. When a new ladder is read by touching .

6.3.2 Precaution during ladder monitoring

- (1) When making connection to the FXCPU
 - (a) The comment display is kana comments only.
 - (b) During PLC read operation, the PLC read can only be performed for own station only.
 - (c) STL (step ladder), the FXCPU exclusive instruction, is not a contact point, but treated as an instruction and displayed in the following manner:

When monitoring with the peripheral device for FX



When ladder monitoring with GOT




- (d) When searching for STL instruction, search for "S (state)" in the device search.
- (e) The ladder data in which the following instructions are used cannot be displayed on the GOT. Do not use the following instructions when executing the ladder monitoring on the GOT.

FNC No.	Instruction	FNC No.	Instruction	FNC No.	Instruction
External device SER		Clock operations		Data table processing	
87	RS2	164	HTOS	256	LIMIT
Floating point		165	STOH	257	BAND
112	EMOV	Other instructions		258	ZONE
116	ESTR	184	RND	259	SCL
117	EVAL	188	CRC	External device communication (inverter communication)	
124	EXP	189	HCMOV		
125	LOGE	Character string control		270	IVCK
126	LOG10	202	\$+	271	IVDR
128	ENEG	203	LEN	272	ICRD
133	ASIN	204	RIGHT	273	ICWR
134	ACOS	205	LEFT	274	IVBWR
135	ATAN	206	MIDR	External device communication (inverter communication)	
136	RAD	207	MIDW		
137	DEG	208	\$MOV	280	HSCT
Positioning		Data processing 3		Extension file register control	
150	DSZR	212	POP	290	LOADR
151	DVIT	213	SFR	291	SAVER
----	----	214	SFL	292	INITR
----	----	----	----	293	LOGR

- (f) The FX3UC series can be monitored only in the device range of FX2N series.
Create the ladder data within the device range of FX2N series when executing the ladder monitoring on the GOT.
The ladder data including devices that are not provided for the FX2N series cannot be displayed on the GOT.
 - (g) Make the memory capacity of the ladder data monitored on the GOT to 16000 or less.
The ladder data with memory capacity of 32000 or more cannot be displayed on the GOT.
- (2) When making connection with the motion controller CPU
- (a) When the OS version is "SV5***" in the SVST instruction, "J***" appears as the tag name of MC.
- (3) When making connection to the QCPU (Q mode) and QnACPU
Set more than 16 characters for a comment.
If 15 characters or less are set, the comment will not be displayed correctly.

This setting can be made on the following screen or tab of GX Developer.

- "Setup comment range" screen
- Common tab on "Write to PLC" screen




6.3.3 Switching displays

You can switch the display form (decimal/hexadecimal) of the word device value or the timer/counter value that is displayed on the ladder monitor screen. You can also specify whether or not to display a comment for the object device or switch the language.

- (1) Switching the display form (decimal/hexadecimal)
When monitoring, display the word device current value, the timer/counter current value (upper row) or the set value (lower row) in decimal or hexadecimal (When decimal is displayed, the display changes to hexadecimal.).
- (2) Switching the comment display on and off
Display the comment that is written in the object PLC CPU (When no comment is displayed, this turns on the comment display). Comment display priority order: expanded comment > Japanese character comment or Japanese kana comment
- (3) Language switching (for MELSEC-Q ladder monitor only)
In the MELSEC-Q ladder monitor, language switching (Japanese/Korean) is available for displaying the following items of a sequence program.
(To switch the language, register the following items with the language (Japanese/Korean) used for the PLC READING DATA DISPLAY. To display Korean, for example, register the following items with Korean on GX Developer.)
 - File name
 - Title
 - CommentItems other than the above (such as menu) are displayed with the language set on [GOT setup]. For details, refer to Section 6.3.4 Language switching of the sequence program (MELSEC-Q ladder monitor).

The display change operation is explained below.

[Operation procedure]




* When there is a  at the upper left of the screen, touch it to return to the original screen.

When the screen below is currently displayed, it is not necessary to touch this.


Touch the appropriate display position on the ladder monitor menu.

..... After moving to the ladder monitor screen, the word device value is  when you touch .

(When changing to hexadecimal display)



(When changing to comment display)



6.3.4 Language switching (MELSEC-Q ladder monitor)

In the MELSEC-Q ladder monitor, language switching (Japanese/Korean) is available for displaying the following items of a sequence program.

(To switch the language, register the following items with the language (Japanese/Korean) used for the PLC READING DATA DISPLAY. To display Korean, for example, register the following items with Korean on GX Developer.)


- File name
- Title
- Comment

Items other than the above (such as menu) are displayed with the language set on [GOT setup].

(1) Switching method



Example) PLC reading screen



Example) Ladder monitor screen

Display procedure for the PLC reading screen (Section 6.2.1)



PLC reading screen




(Continued to next page)

1) Touch the **Set Up** key. The setting window appears.

(From previous page)



- 2) The setting window appears. Perform the PLC READING DATA DISPLAY. The settings shown below switch with every touching of the  key.



- 3) After completing the setting, touch the button to close the setting window.
- 4) The display is switched.

(2) Precautions on language switching

(a) Precautions on switching displayed characters

When switching displayed characters (Japanese/Korean), the characters may not be displayed depending on the line wrapping position.

In such a case, the display becomes normal by an operation such as scrolling the screen and then displaying it again.

(b) Precautions on displaying Korean

Some character codes of Unicode1.1 can be used for Korean.

The following shows displayability of Korean character codes.

KS character code	Displayability	KS character code	Displayability
8141H to A1A1H	N/A	A8A6H	Available
A1A2H to A1FEH	Available	A8A7H	N/A
A241H to A2A0H	N/A	A8A8H to A8AFH	Available
A2A1H to A2E5H	Available	A8B0H	N/A
A2E6H to A3A0H	N/A	A8B1H to A8FEH	Available
A3A1H to A3FEH	Available	A941H to A9A0H	N/A
A441H to A4A0H	N/A	A9A1H to A9FEH	Available
A4A1H to A4FEH	Available	AA41H to AAA0H	N/A
A541H to A5A0H	N/A	AAA1H to AAF3H	Available
A5A1H to A5AAH	Available	AAF4H to ABA0H	N/A
A5ABH to A5AFH	N/A	ABA1H to ABF6H	Available
A5B0H to A5B9H	Available	ABF7H to ACA0H	N/A
A5BAH to A5C0H	N/A	ACA1H to ACC1H	Available
A5C1H to A5D8H	Available	ACC2H to ACD0H	N/A
A5D9H to A5E0H	N/A	ACD1H to ACF1H	Available
A5E1H to A5F8H	Available	ACF2H to B0A0H	N/A
A5F9H to A6A0H	N/A	B0A1H to B0FEH	Available
A6A1H to A6E4H	Available	B141H to C6FEH (Lower **41 to **A0)	N/A
A6E5H to A7A0H	N/A	B141H to C6FEH (Lower **A1 to **FE)	Available
A7A1H to A7EFH	Available	C7A1H to C8FEH	Available
A7F0H to A8A0H	N/A	C9A1H to C9FEH	N/A
A8A1H to A8A4H	Available	CAA1H to FDFEH	Available
A8A5H	N/A	FEA1H to FEFEH	N/A

Remark

Characters displayable on the GOT can be displayed on the GT Designer2.

Accordingly, displayability of Korean characters, displayed on the GX Developer, on the GOT can be confirmed by copying the text data to the GT Designer2.



By copying a comment to be checked to a text figure or an object of the GT Designer2, displayability of the comment can be confirmed.

6.3.5 Changing the device value

CAUTION

● Read the manual carefully and fully understand the operation before the test operation (ON/OFF of bit devices, modifying current value of a word device, modifying timer/counter setting, modifying the current value, or modifying the current value of a buffer memory) of ladder monitor. In addition, never modify data in a test operation to a device, which performs a crucial operation to the system. It may cause an accident by a false output or malfunction.

Changing the device value on the screen during ladder monitoring is described. Switches for the timer/counter value display format (decimal/hexadecimal), and the comment display for the corresponding device (on/off) can be performed.


Point

When the FXCPU or MELDAS C6/C64 is monitored, the timer and counter values cannot be changed.

(1) Device value changing method

The device value changing method during ladder monitoring is described below:

<Circuit monitor Screen>




Display the ladder monitor screen by touching

LADDER MON.


1) Display the screen shown in 2) by touching **Menu**.

2) Display the test window by touching **TEST**.



3) As the test window will open, perform the operation by seeing Sec. 9.6.

After the device change is complete, the changed contents can be verified in the ladder monitor.




Note

The current value display of the word device becomes hidden from view due to the test window. Using the **→** **←** key entries, the hidden current value display can be displayed by scrolling to the right/left.

6.3.6 About Hardcopy Output

This section describes the way to print the ladder monitor screen with the printer or to save it in the memory card in the BMP/JPEG file format during ladder monitor.



Depending on the used GOT, output the hardcopy in the following corresponding method.

- (1) When A985GOT or A97*GOT is used

Touch the or key displayed on the ladder monitor screen to output the hardcopy.

- (2) When A95*GOT or A956WGOT is used

Set the start/stop triggering device of the hardcopy function on GT Designer2 and turn that device ON/OFF to output the hardcopy.

Point

- When printing out the ladder monitor screen, always install the option driver into the GOT.
- Set the output destination (Memory card/printer) of the hardcopy in the hardcopy setting of GT Designer2.
Refer to GT Designer2 Version2 Reference Manual for details of the hardcopy setting.

7 ERROR MESSAGES FOR LADDER MONITOR

The following chart shows the error messages that are displayed during the ladder monitor operation and the method of handling them.

Error Message	Description	Method of Handling
ENTRY CODE MISMATCH	The specified keyword is different from the keyword that is registered in the object PLC CPU.	Check the keyword that is registered in the object PLC CPU and specify again.
FILE NOT FOUND	(1) An attempt was made to switch to the ladder monitor screen when a sequence program had not been read. (2) When the file is selected and the <input type="button" value="Read"/> key is pressed, the selected file does not exist in the PLC drive.	Read the sequence program that is written in the object PLC CPU. (Ex.) A sub-sequence program can only be specified as A3 [] CPU/A4UCPU.
PLC COMMUNICATION ERROR	(1) Cannot communicate with PLC CPU of the specified network No. or station No. (2) The specified drive does not exist.	Check and correct the following: (1) Does the specified PLC CPU exist? (2) Is it online? (Data communication status?) (3) Has an error occurred?
LOCK ON OTHER MACHINE. PLEASE CANCEL	File is locked with the peripheral equipment (GX Developer, GPPQ).	After reading and writing with the peripheral equipment (GX Developer, GPPQ), read the file again.
NOT EXISTING DRIVE, DRIVE ERROR	(1) The specified drive does not exist. (2) The specified drive is faulty.	(1) Check whether the specified drive exists or not. (2) Check whether the specified drive is faulty or not.
ENTRY CODE MISMATCH	The specified file password differs from the one registered as the file password of the corresponding PLC CPU.	Confirm the file password registered to the drive of the corresponding PLC CPU, and specify it again.
FILE NOT FOUND	When you selected the file and pressed the <input type="button" value="Read"/> key, the selected file did not exist in the PLC CPU drive.	(1) Perform read from the PLC on the network No./station number input screen, and update the file list. (2) Change the specified drive (corresponding memory).
USE BY OTHER MACHINE. PLEASE CANCEL	The sequence or comment is being used by the peripheral device (GX Developer).	Perform file read again after completion of read/write from/to the peripheral device (GX Developer).
2M bytes of comments were read since they exceeded 2M bytes.	Only 2M bytes of the comment file was read because its size is greater than 2M bytes.	---
Outside CPU reset/device range/ special module illegal access	The accessed special module is faulty or does not exist.	Check the system configuration.

8 OPERATING SYSTEM MONITOR


The operation procedures for using the system monitor function are explained in this section.

8.1 Operation procedures before starting system monitoring

This section contains a summary of the procedure for transmitting the system program (OS) for the system monitor function from the Personal computer to the GOT until it is installed in the built-in memory.


For details, please refer to the GT Designer2 Version2 Operating Manual.

Details of the screen display and key operation are shown in the Help.



8.2 Operation procedures from user-created monitor screen display to start of system monitoring

This section explains the operation procedure for the GOT when starting each operation of the system monitor function, after the system program (OS) of the system monitor function has been installed in the GOT built-in memory.



9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS

This chapter contains an explanation of each screen operation when using the system monitor function.



With any of the four windows, when changing the station/monitor device or executing the test operation, it is not possible to do an operation with another window until that series of operations is finished.


9.1 Screen configuration, common operations and changing screens when monitoring

The common operations of each monitor function such as screen configuration and target PLC CPU specification when executing system monitoring are described below.

9.1.1 Basic screen configuration and key functions (menu)

The basic screen configuration displayed in the windows and the key functions displayed on the screen are shown below.

(1) Display



(2) Key functions

The functions of keys that are used with the basic screen operation are shown in the chart below.

Key	Function
DEV MON	The entry monitor is executed with the applicable window (see Sec. 9.2.).
BAT MON	The batch monitor is executed with the applicable window (see Sec. 9.3.).
TC MON	The timer/counter monitor is executed with the applicable window (see Sec. 9.4.).
BM MON	The buffer memory monitor is executed with the applicable window (see Sec. 9.5.).
END	System monitoring ends; display returns to the screen where system monitors function started.

9.1.2 Switching displays

- (1) Switching the display form (decimal/hexadecimal)
Display the word device present value or the timer/counter present value or set value in decimal or hexadecimal.
- (2) Switching the comment display on and off
Display the comment that is written in the object PLC CPU (Comment display priority order: expanded comment > Japanese character comment or Japanese kana comment).

(When changing to hexadecimal display)

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]	STATION[FF]			
D 15	H	80000000		
D 10	H	8001		
X 001	●			
M 25	○			
Y 70	●			
W 200	H	002B		
R 50	H	04135		
C 200	H	7000		

(When changing to comment display)


DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]	STATION[FF]			
D 200	50			▲
	[Production line A]			
W 200	43			
	[Production quantity]			
R 50	68378428	DW		
	[link status]			
X 10	100			▼
	[Production line B]			

- (3) Precautions for comment display
 - (a) When any of the following CPUs is being monitored, comments are not displayed.
 - 1) FXCPU
 - 2) Motion controller CPU (Q172CPU, Q173CPU)
 - 3) QnACPU whose serial number indicated in the DATE field of the rating plate is earlier than 9707B
 - 4) MELDAS C6/C64
 - (b) When any of the following devices is being monitored, comments are not displayed.
 - 1) Internal device (GB, GD, GS) of GOT
 - 2) Host device (B, W, SB, SW) at the time of MELSECNET connection
 - 3) Host device (X, Y, WW, WR) at the time of CC-Link connection
 - (c) When monitoring the QCPU (Q mode) or QnACPU, comments are not displayed if any of the following settings has been made in the PLC parameter setting (PLC file setting).
 - 1) "Not used" has been selected for the comment file.
 - 2) "Use the same file name as the program" has been selected for the comment file.
 - 3) Password has been set to the comment file for the QCPU (Q mode).
 - 4) Keyword has been registered to each memory for the QnACPU.
 - * Comments are displayed if the setting is changed using GX Developer or like.
 - (d) When the Q00J/Q00/Q01CPU is being monitored, comments are not displayed if the comment file "MAIN" does not exist in the program memory.


Below is an explanation of the operation for changing the display, using the Entry Monitor window as an example.

The operation procedure is the same for changing the display when selecting windows other than Entry Monitor.

[Operation procedure]



FORM (Touch)



(Change display form.)

DEC HEX

(Change comment display)

YES NO

EXECUTE (Touch)

(Return)
Monitor screen

When you touch **MENU** you return to the basic screen.

When you touch, **SET**, the monitor station and device).....can be specified. (See Sec. 9.1.3)

When you touch **FORM**, you can change this display.

The selected **FORM** display is also found on the screen displayed after selecting the monitor function with the basic screen and on each menu screen, in addition to each monitor screen.

) Display monitor station network no. and station

* When you touch **CANCEL**, the display change is interrupted and the display returns to the monitor screen.

(1) Touch the display position of the selected menu.



After starting the system monitor, if the PLC CPU comment or comment capacity is changed, the comment may not be correctly displayed on each monitor screen.

When changing the comment or comment capacity, re-start the GOT.

9.1.3 Specifying the monitor station and device (SET)

An explanation of the procedure for specifying the monitor station and the device for executing the system monitor is explained below, using the Entry Monitor window as example. The operation procedure is the same for specifying the monitor station and device when selecting windows other than Entry Monitor.

* When there is a  (key window), touching it returns to the monitor screen.

[Operation procedure]

Select monitor function with basic screen.
Or, display  monitor screen or  menu screen.

..... See Sec. 9.1.1.

..... See the explanatory section for each monitor screen and the menu screen.

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
D	15	-2147483648	DW	
D	10	-32767		
X	001	●		
M	25	○		
T	30	100	200	
W	200	43		
R	50	68378428	DW	
C	5	300	300	

..... When you touch  you return to the basic screen.

When you touch , you change this display. (See Sec. 9.1.2.)


When you touch , you can specify the monitor station and device.

 (Touch)

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
ENTRY	DELETE	ALL CLR		
TEST				
CANCEL				

 (Touch)

1)



(1) Specify network No., station No.*1 and CPU No.*2 of object PLC CPU.

(For data link system)

NET WK No.: 0
 STATION : FF (Host station)
 0 (Master station)
 1 to 64 (Local station)

(For network system)

NET WK No.: 0 (Host loop)
 1 to 255 (Specified loop)
 STATION : FF (Host station)
 0 (Control station)
 1 to 64 (Normal station)

(For Ethernet connection)*3

NET WK No.: 1 to 239
 STATION : 1 to 64

(For multi-CPU system)

CPU No. 0 to 4 (CPU number)

(2) Specify the device to be monitored.

(3) When specifying the word device or buffer memory as a monitor device, specify the monitor module.


0: 16-bit (1-word) module

1: 32-bit (2-word) module


* Match the data to be entered; the touch key display at the bottom of the screen will change.

(EX.)

(When entering network no.)



(When entering device no.)



*1 For the station, with either system, specify "FF", which shows the PLC CPU to be accessed, or "0" to "64".

*2 Displayed for QCPU monitor only.

*3 The monitor target must be preset using GT Designer2.

For ACPU monitor, specify the network number/station number set on GT Designer2.

Refer to the GOT-A900 series User's Manual (Connection System Manual) for details of the monitor target setting for Ethernet connection.

*4 Data being entered can be cleared by the following keys.

AC : Clears all data being entered to the target area.

DEL : Clears one character at the cursor position.


*5 The form of data to be entered is displayed at the right side of the screen.

DEC : Enter in decimal

HEX : Enter in hexadecimal

9.1.4 Changing screens

This section shows the screen changes when executing each monitoring operation of the system monitor function from the status where the user-created monitor screen is displayed.




9.2 Entry monitor

Enter the device to be monitored in advance. The function that monitors only the device that was entered is called the "entry monitor".

The entry monitor operation when executing the system monitor function is explained below.

9.2.1 Basic operation

The entry monitor operation procedure is shown below.



See Sec. 9.1.1.

..... When a screen other than the basic screen is displayed, touch **MENU** at the top of the currently displayed screen, display the basic screen, and select Device Monitor.

..... When you touch **MENU**, you return to the basic screen.

When you touch **FORM**, you can change this display (See Sec. 9.1.2.).

When you touch **SET**, you can specify the monitor station and device (See Sec. 9.1.3.).

..... Set the station and device to be monitored. For the setting method, see Sec. 9.1.3.

*1 Monitor device entry is in station modules.

If you change the station for the monitor device, all monitor devices entered before that are invalid.

*2 A maximum of 8 entry devices can be entered.

To enter more than 8, delete in order from the old entry device. The 8 most recent entry device will be monitored.

As needed, re-enter after deleting the entry device. (For the method of deletion, see Sec. 9.2.3.)

..... Do if needed.

For the display change method, see Sec. 9.1.2.

9.2.2 Entry monitor screen display and key functions

In this section, the Entry Monitor screen display and the functions of the keys displayed at the top of the screen are explained.

(1) Display

1) **DEVICE MONITOR** | **TEST** | **MENU** | **FORM** | **SET**

2) NETWK No.[0] STATION[FF]

D 200 30 ▲

[Line 1 current units]

W 200 43

[Production line A]

3) R 50 68378428 DW

[link status]

X 3 ●

[Input switch 3] ▼

1) When comment is not displayed: max. 8 devices
When comment is displayed : max. 4 devices
Display when system monitoring
Bit device..... ●: ON ○: OFF
Word device.....Current value

1)	Displays the keys that are used with the operation of the Entry Monitor screen shown in (2) (Touch input).
2)	Displays the monitor station network No., station No. and CPU No.*1
3)	Displays the status and current value of the device.

*1 Displayed for QCPU monitor only.

(2) Key functions

The chart below shows the functions of the keys that are used with the Entry Monitor screen operation.

Key	Function
MENU	Move to basic screen (function change menu screen) to change to another monitor function or ending the system monitor (See Sec. 9.1.1.).
FORM	Move to the display change menu screen to change the numerical display on the Entry Monitor screen (decimal, hexadecimal) or changing the comment display (on/off) (See Sec. 9.1.2.).
SET	Move to device setting menu screen to enter the monitor device, delete the device, or execute a test. <ul style="list-style-type: none"> ▪ Entry of monitor device (See Sec. 9.1.3.) ▪ Deletion of entry device (See Sec. 9.2.3.) ▪ Test (See Sec. 9.6.)
▲ ▼	Scroll the display up or down one line, and display the monitor device that is not displayed (just before or after the current display). When five or more monitor devices are entered, operation is enabled when the monitor device comment is displayed. <ul style="list-style-type: none"> ▼ : Scrolls down one line. ▲ : Scrolls up one line.

9.2.3 Deleting a registered device


The operation of deleting (erasing) the entry of the device being monitored with the Entry Monitor screen is explained below.

The following two methods can be used to delete the registered device.

- Random deletion Deletes only one specified device.
- Batch deletion Deletes all devices that are currently registered.

* If there is a  at the upper left of the screen, touching the  returns to the monitor screen.

..... See Sec. 9.2.2.



- (1) Specify the device to be deleted.
- * Match the data to be entered; the touch key display at the bottom of the screen will change.

*1 Data being entered can be cleared by the following keys.

 : Clears all data being entered to the object area.

 : Clears one character at the cursor position.


9.3 Batch monitor

When monitoring, the function of specifying the device at the beginning of an optional device range and monitoring it is called the "batch monitor".

The batch monitor operation when executing the system monitor is explained below.

9.3.1 Basic operation

The batch operation procedure is shown below.



See Sec. 9.1.1.

..... When a screen other than the basic screen is displayed, touch **MENU** at the top of the currently displayed screen, display the basic screen, and select "Batch monitor".

..... When you touch **MENU**, you return to the basic screen.

When you touch **FORM**, you can change this display (See Sec. 9.1.2.).

When you touch **SET**, the monitor station and device can be specified (See Sec. 9.1.3.)

(1) Specify the station and device to be monitored.
For the method of specifying, see Sec. 9.1.3.

..... Do if needed.

For the display change method, see Sec. 9.1.2.

9.3.2 Batch monitor screen display and key functions

In this section, the Batch Monitor screen display and the functions of keys displayed at the top of the screen are explained.

(1) Display

2)

3)

BATCH MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
D 10	32767	[]	▲
D 11	0	[Inventory quantity]	
D 12	0	[Shipment quantity]	
D 13	-1	[]	
D 14	0	[Warehouse A temperature]]	
D 15	3	[Warehouse B temperature]]	
D 16	0	[]	
D 17	0	[Production plan]	▼

1)

When comment is not displayed: max. 16 devices
 When comment is displayed : max. 8 devices
 Display when system monitoring
 Bit device.....● : ON ○ : OFF
 Word device.....Current value

1)	Displays the keys that are used with the operation of the Batch Monitor screen shown in (2) (Touch input).
2)	Displays the monitor station network No., station No. and CPU No.*1
3)	Displays the status and current value of the monitor device (The screen above shows when the monitor module is 16 bits.).

*1 Displayed for QCPU monitor only.

(2) Key functions

The chart below shows the functions of the keys that are used with the Batch Monitor screen operation.


Key	Function
MENU	Move to basic screen (function change menu screen) for changing to another monitor function or ending the system monitor (See Sec. 9.1.1.).
FORM	Move to display change menu screen for changing the numerical display on the Batch Monitor screen (decimal/hexadecimal) or changing the comment display (on/off) (See Sec. 9.1.2.).
SET	Move to device setting menu screen to change the monitor device or execute a test. • Change of monitor device (See Sec. 9.1.3.) • Test (See Sec. 9.6.)
<div style="display: flex; justify-content: space-around;"> ▲ ▼ </div>	Scroll the display up or down one line, and display the monitor device that is not displayed (just before or after the current display). <div style="display: flex; justify-content: space-between;"> ▼ : Scrolls down one line. ▲ : Scrolls up one line. </div>

9.4 TC Monitor (monitor of timer and counter)

The function that monitors only the time (T) and counter (c) when monitoring is called the TC monitor. The TC monitor operation when executing the system monitor is explained below.

9.4.1 Basic operation

The TC operation procedure is shown below.



See Sec. 9.1.1.

..... When a screen other than the basic screen is displayed, touch **MENU** at the top of the currently displayed screen, display the basic screen, and select "TC Monitor".

..... When you touch **MENU**, you return to the basic screen. When you touch **FORM**, you can change this display (See Sec. 9.1.2.).

When you touch **SET**, the monitor station and device can be specified (See Sec. 9.1.3.).

(1) Specify the station and device to be monitored. For the method of the specifying, see Sec. 9.1.3.

..... Do if needed. For the display change method, see Sec. 9.1.2.

9.4.2 TC Monitor screen display and key functions

In this section, the TC Monitor screen display contents and the function of keys displayed at the top of the screen are explained.

(1) Display

1) **TC MONITOR** | **TEST** | **MENU** | **FORM** | **SET**

2) NETWK No.[0] STATION[33]
FILE [ABCDEF.PRG]

3) T 0 PV 0 SV 0

[Production line A]

T 1 PV 0 SV 0

[Production line B]

T 2 PV 150 SV 150

[Production line C]

T 3 PV 0 SV 0

[Production line D]

1) When comment is not displayed: max. 8 devices
When comment is displayed : max. 4 devices
Display when system monitoring
T/Ccurrent value, set value
(Contact point, coil) : ON
 : OFF

1)	Displays the keys that are used with the operation of the TC Monitor screen shown in (2) (Touch input).
2)	Displays the monitor station network No., station No. and CPU No.*1 When connected to QCPU and QnACPU, the execution file name is displayed (If there are more than one file, the first file name is displayed.).
3)	Displays the current value, set value, contact point and coil status of the monitor device (The screen above shows when the monitor module is 16 bits.).

*1 Displayed for QCPU monitor only.

(2) Key functions

The chart below shows the function of the keys that are used with the operation of the TC Monitor screen.

Key	Function
	Move to basic screen (function change menu screen) for changing to another monitor function or ending the system monitor (See Sec. 9.1.1.).
	Move to display change menu screen for changing the numerical display on the TC monitor screen (decimal/hexadecimal) or changing the comment display (on/off) (See Sec. 9.1.2).
	Move to device setting menu screen to change the monitor device or execute a test. • Change of monitor device (See Sec. 9.1.3.) • Test (See Sec. 9.6.)
	Scroll the display contents up or down one line to display the monitor device that is not displayed (just before or after the current display). Operation is enabled when monitor device comment is displayed. : Scrolls down one line. : Scrolls up one line.


9.5 BM Monitor (monitor of buffer memory)

When monitoring, the function that monitors the buffer memory of the special function module is called the "BM monitor".

The BM monitor screen when executing the system monitor is explained below.

9.5.1 Basic operation

The BM Monitor operation procedure is shown below.



See Sec. 9.1.1.

..... When a screen other than the basic screen is displayed, touch **MENU** at the top of the currently displayed screen, display the basic screen, and select "BM Monitor".

..... When you touch **MENU**, you return to the basic screen. When you touch **FORM**, you can change this display (See Sec. 9.1.2.).

When you touch **SET**, the monitor station and device can be specified (See Sec. 9.1.3.).

(1) Specify the station and device to be monitored, and the monitor module (16-/32-bit module).

(2) For the method of the specifying, see Sec. 9.1.3. Specify the module to be monitored and the buffer memory as follows.

Initial Y [] []

Specify the initial address of the buffer memory in decimal.

When the initial I/O signal of module is displayed with three digits, specify the first two digits.

..... Switching between decimal and hexadecimal display is enabled. Do this as needed. For the display change method, see Sec. 9.1.2.

9.5.2 BM Monitor screen display and key functions

In this section, the BM Monitor screen display and the functions of keys displayed at the top of the screen are explained.

(1) Display

	BM MONITOR	TEST	MENU	FORM	SET
2)	NETWK No.[0] STATION[FF]		I/O NO[1]		
3)	BM 1110	-32767	BM 1118	0	
	BM 1111	64	BM 1119	0	
	BM 1112	149	BM 1120	150	
	BM 1113	-1111	BM 1121	131	
	BM 1114	126	BM 1122	-32768	
	BM 1115	160	BM 1123	555	
	BM 1116	255	BM 1124	2368	
	BM 1117	1200	BM 1125	11000	

1)

Displays current value of a maximum of 16 devices.

1)	Displays the keys that are used with the operation of the BM Monitor screen shown in (2) (Touch input).
2)	Displays the monitor station network No., station No., CPU No.*1 and the first 2 digits of the I/O signal No. of the object module.
3)	Displays the current values of the buffer memory (The screen above shows when the monitor module is 16 bits.).

*1 Displayed for QCPU monitor only.

(2) Key functions

The chart below shows the function of the keys that are used with the operation of the BM Monitor screen.

Key	Function
MENU	This moves to basic screen (function change menu screen) for changing to another monitor function or ending the system monitor (See Sec. 9.1.1.).
FORM	This moves to display change menu screen for changing the number display on the BM monitor screen (decimal/hexadecimal) (See Sec. 9.1.2.).
SET	This moves to device setting menu screen to change the monitor device or execute a test. <ul style="list-style-type: none"> • Change of monitor device (See Sec. 9.1.3.) • Test (See Sec. 9.6.)

9.6 Test



CAUTION

- Read the manual carefully and fully understand the operation before the test operation (ON/OFF of bit devices, modifying current value of a word device, modifying timer/counter setting, modifying the current value, or modifying the current value of a buffer memory) of system monitor.
In addition, never modify data in a test operation to a device which performs a crucial operation to the system. It may cause an accident by a false output or malfunction.

When monitoring with the system monitor function, you can specify an optional station or device to be monitored and test it.

The operation of testing a bit device, word device, or special module buffer memory of the PLC CPU is explained in this section.

9.6.1 Basic operation

The operation procedure for testing when monitoring with the system monitor function is shown below.

See Sec. 9.5.2.

[Operation procedure]

When monitoring with the system monitor function, display any monitor screen.

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
D	15	-2147483648	DW	
D	10	-32767		
X	001	●		
	25	○		

SET (Touch)

Display device setting menu screen.

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
DEVICE	DELETE	ALL CLR		
TEST				
CANCEL				

TEST (Touch)

Display test menu screen.

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
SET/RST	VALUE16	BM VAL16		
SET VAL	VALUE32	BM VAL32		
CANCEL				

1)

..... When a screen other than the monitor screen is displayed, display any monitor screen according to the explanatory section for each monitor function.
When Device Monitor screen is displayed.

..... When you touch **CANCEL**, the display moves (returns) to the previous monitor screen.

..... When you touch **CANCEL**, the display moves (returns) to the previous monitor screen.

*1 The data being entered can be cleared by using the following keys.

AC : Clear all data being entered in the object area.

DEL : Clear one character from the cursor position.

*2 The format for the data being entered is displayed on the right side of the screen.

DEC : Enter in decimal.

HEX : Enter in hexadecimal.

*3 The monitor target must be preset using GT Designer2.

For ACPU monitor, specify the network number/station number set on GT Designer2.


Refer to the GOT-A900 series User's Manual (Connection System Manual) for details of the monitor target setting for Ethernet connection.

*4 Even when the setting value/current value is changed after the timer (T) has timed out and the counter (C) has finished counting, the time-up status/count-up status do not change. The current status is maintained.

(When the setting value is changed to a large value/when the current value is changed to a small value)

*5 When an index-qualified T/C set value is changed, only its constant part is changed. Its index-qualified part is not changed.

Example) Changing the set value of T5 from "300" to "200"



9.6.2 Quick test function

In addition to the existing tests for the direct input of device, station No., etc. during monitoring with the system monitor function, this function enables the bit device SET/RESET, word device, buffer memory data to change by a single touch.

1) Operation to set the quick test function on

To perform the quick test functions, perform the following operations:

[Operation procedure]

Display one of the system monitor screen.

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
D	15	-2147483648	DW	
ZR	1042431	-32767		
X	0001	●		
M	25	○		
W	200	43		
R	50	68378428	DW	
D	0	0		
W	100	0		

..... When displaying the device monitor screen.

TEST (Touch)

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
D	15	-2147483648	DW	
ZR	1042431	-32767		
X	0001	●		
M	25	○		
W	200	43		
R	50	68378428	DW	
D	0	0		
W	100	0		

QUICK TEST MODE SET

OK

..... The quick test is turned on by clicking on **OK**.

OK

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
QUICK TEST				
D	15	-2147483648	DW	
ZR	1042431	-32767		
X	0001	●		
M	25	○		
W	200	43		
R	50	68378428	DW	
D	0	0		
W	100	0		

..... Status when the quick test function is on.

2) Operation to turn off the quick test function

When **TEST** is touched when the quick test function is on, a dialog box is displayed. When **OK** is touched, the quick test can be canceled.

3) Bit device quick test

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
QUICK TEST				
D	15	-2147483648	DW	
ZR	1042431	-32767		
X	0001	●		
M	25	○		
W	200	43		
R	50	68378428	DW	
D	0	0		
W	100	0		

..... When the device monitor screen is displayed.
Touch the device name or device no. display position for the bit device to be SET/RESET.

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
QUICK TEST				
D	15	-2147483648	DW	
ZR	1042431	-32767		
X	0001	●		
M	25	○		
W	200	43		
R	50	68378428	DW	
D	0	0		
W	100	0		

..... The device name and device no. touched is displayed high-lighted.

When the on/off display (○, ●) of the highlighted display is touched, the status is SET/RESET.

* When the current bit device is ON, then it is turned OFF (RESET).

When OFF, it will be (SET).

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]		STATION[FF]		
QUICK TEST				
D	15	-2147483648	DW	
ZR	1042431	-32767		
X	0001	○		
M	25	○		
W	200	43		
R	50	68378428	DW	
D	0	0		
W	100	0		

The on/off display area (○, ●) of the X0001 device is high-lighted.

4) Quick test for the word device, T/C monitor, and buffer memory

DEVICE MONITOR	TEST	MENU	FORM	SET
NETWK No.[0]	STATION[FF]	QUICK TEST		
D	15	-2147483648	DW	
ZR	1042431	-32767		
X	0001	●		
M	25	○		
W	0	43		
R	200	68378428	DW	
D	50	0		
W	100	0		

..... When displaying the device monitor screen.
Touch the display position of the device to be changed.

NETWK No.[0]		STATION[FF]		DEC	
DEVICE[W][200]		VL []	
7	8	9	A	B	◀ ▶
4	5	6	C	D	▼ ▲
1	2	3	E	F	↶ ↷
0	-	.	AC	DEL	↶

..... The change value input screen is displayed.
Enter the current value to be changed in the KEY window.
See Section 9.1.3 for the KEY window operations.

10 ERROR MESSAGES FOR SYSTEM MONITOR

The following chart shows the error messages that may be displayed when operating the system monitor and the method of handling them.

Error Message	Description	Method of Handling
PLC communications error	Communication could not be established with the PLC CPU.	Check the following: <ul style="list-style-type: none">• Connections between the PLC CPU and the GOT (disconnected or cut cables).• Has an error occurred in the PLC CPU?


11 OPERATING SPECIAL MODULE MONITOR

The operation procedure when using the special module monitor function is explained in this chapter.

11.1 Operation procedures before starting special module monitoring


This section contains a summary of the procedure for transmitting the system program (OS) for the special module monitor function and the special module monitor data from the personal computer to the GOT until it is installed in built-in memory.

For details, please refer to the GT Designer2 Version2 Operating Manual. Details of the screen display and key operation are shown in the Help.



11.2 Operation procedures from user-created monitor screen display to start of special module monitor

This section describes the operation procedure for the GOT when starting each operation of the special module monitor function after the system program (OS) of the special module monitor function has been installed in the GOT built-in memory, and downloading the special module monitor data.



*1 Touch the key where the touch switch (expanded) function was set with the drawing software, and start the system monitor function. When the Utility screen is displayed, touch **SP.Mon.** to start the special module monitor function.

12 OPERATING SPECIAL MODULE MONITOR SCREEN

Each screen operation when using the special module monitor function is explained in this chapter.

12.1 Screen configuration, common operation and changing screens when monitoring


The screen configuration and common operations used when executing the special module monitor are explained in this section.

12.1.1 Composition of system configuration screen and key functions

This section describes the structure of the system configuration screen that is displayed after starting the special module monitor function and the key functions displayed on the screen.

(1) When using the QCPU(A mode), QnACPU or ACPUCPU

(a) Display



The module format and related data are displayed at the end of the module data readout from the PLC CPU. (OS executes it automatically.) When connected to MELSECNET, the screen shown in Section 12.1.3 is displayed.

1)	Displays network No. and station No. of monitor station.
2)	With the module installed in the monitor station, the special function module displays the format and the initial no. of the I/O signal with the sequencer CPU; the I/O module displays "Input"/"Output" and the I/O points. For a special function module that cannot be monitored, "Special" and the initial no. of the I/O signal are displayed. The display position of the module is the key for moving the special function module monitor of that module to the screen where it is executed (Touch input)
3)	The keys used for the operation with the System Configuration screen shown in (b) are displayed. (Touch input)


(b) Key functions

The chart below shows the functions of the keys that are used with the System Configuration screen operation.

Key	Function
END	Monitoring ends; and display returns to the screen where the special module monitor function was begun.
Module display position	Moves to screen where the special module monitor for that module is executed. Slots 0 through 7 are valid for each base module.
▲ ▼	<p>Scrolls display up or down one level to display the system configuration of the level number just before or after the one that is currently displayed.</p> <p>Operation of these keys is enabled when the system configuration extends to three levels or more.</p> <p>▼ : Scrolls down one level.</p> <p>▲ : Scrolls up one level.</p>

(2) When using the QCPU(Q mode)

(a) Display





The module format and related data are displayed on completion of module data read from the PLC CPU. (OS executes it automatically.)

3)

1)	Displays the network number and station number of the monitor station.
2)	<p>For the modules installed in the monitor station, their formats, I/O points and first I/O numbers are displayed.</p> <p>For special function modules which cannot be monitored, their formats are displayed as "Special".</p> <p>The module display position acts as the key to shift to the screen where the module will be monitored. (Touch input)</p> <p>In case of a multi-CPU system, the CPU No. is displayed for the CPU and the control CPU No. is displayed for the installed module.</p>
3)	The keys used for the operation on the System Configuration screen shown in (b) are displayed. (Touch input)

(b) Key functions


The following table indicates the functions of the keys used to perform operation on the System Configuration screen.

Key	Function
	Monitoring ends, and the display returns to the screen where the special module monitor function was started.
	Shifts to the PC Information screen. (Refer to Section 12.1.3)
	Basic mode: Shifts to the screen where that special module will be monitored. Info. mode: Shifts to the screen which shows the detail information of the selected module.
	Switches the System Configuration screen to the info. mode. (Refer to Section 12.1.4)
	Switches the System Configuration screen to the Basic mode.
	Scrolls the display one base up or down to display the system configuration of the currently undisplayed base immediately before/after the currently displayed base. This operation cannot be performed when the system has three or more extension bases.  : Scrolls one base down.  : Scrolls one base up.

12.1.2 Setting method for remote station monitoring

The setting method to perform remote station monitoring during special module monitoring is described below.

<Special Module Monitor>



Touch **SP.UNIT** to display the system configuration screen. Depending on the connection method, the screen first displayed will be different as indicated below.

Bus connection and CPU direct connection	The base of the connection station is displayed.
Ethernet connection	The base of the station set as the host is displayed.
CC-Link (via G4) connection	The base of the master station is displayed.
MELSECNET (II), /B connection	No system configuration display
MELSECNET/10 connection CC-Link connection (Intelligent device station)	No system configuration display

For MELSECNET/CC-Link connections, the following operations will always be required:

- 1) Touch **NETPCNo.** to display the window shown in 2)
- 2) Touch **Alphanumeric** to specify the network No. and PLC station No..

AlphanumericEnter the network No. and PLC station No..

◀ ▶Select the input area.

←Set the area value.

In the case of data link systems	
NETWK NO. :	0
STATION :	FF (Host)
	0 (Master station)
	1 to 64 (Local station)

In the case of network systems	
NETWK NO.:	0 (Host loop)
	1 to 255 (Specified loop)
STATION :	FF (Host)
	0 (Station number of management station)
	1 to 64 (Normal station)

For Ethernet connection *1	
NETWK NO. :	1 to 239
STATION :	1 to 64

CC-Link system	
NETWK NO.:	0
STATION :	0 (master station)

*1 The monitor target must be preset using GT Designer2.

For ACPU monitor, specify the network number/station number set on GT Designer2.


Refer to the GOT-A900 series User's Manual (Connection System Manual) for details of the monitor target setting for Ethernet connection.

When the setting is finished, the system configuration of the specified station is displayed. See Sec. 12.1.6 for operations which come after these operations.

12.1.3 Composition of PC Information screen and key functions (only when QCPU(Q mode) is used)

This section describes the structure of the PC Information screen that is displayed by specifying the QCPU(Q mode) on the System Configuration screen, and the key functions displayed on the screen.

(1) Display



1)	Displays the network number and station number of the monitor station.
2)	Displays the operating status, error information and the like of the corresponding PLC CPU.
3)	The keys used for the operation on the System Configuration screen shown in (2) are displayed. (Touch input)

(2) Key functions


The following table indicates the functions of the keys used to perform operation on the System Configuration screen.

Key	Function
END	Monitoring ends, and the display returns to the screen where the special module monitor function was started.
sys. conf.	Shifts to the System Configuration screen. (Refer to Section 12.1.1)
▲ ▼	Scrolls the display one page up or down. ▼ : Scrolls one page down. ▲ : Scrolls one page up.

12.1.4 Composition of Unit Detail info screen and key functions (only when QCPU(Q mode) is used)

This section describes the structure of the Unit Detail info screen that is displayed by specifying the module in the info. mode of the System Configuration screen, and the key functions displayed on the screen.

(1) Display



3)

1)	Displays the network number and station number of the monitor station.
2)	Displays the module information, error information and the like of the corresponding module.
3)	The keys used for the operation on the System Configuration screen shown in (2) are displayed. (Touch input)

(2) Key functions


The following table indicates the functions of the keys used to perform operation on the System Configuration screen.

Key	Function
	Monitoring ends, and the display returns to the screen where the special module monitor function was started.
	Shifts to the System Configuration screen. (Refer to Section 12.1.1)
	Scrolls the display one page up or down. : Scrolls one page down. : Scrolls one page up.

12.1.5 Monitor screen configuration and key functions

This section describes the structure of the monitor screen that is displayed by specifying the module on the system configuration screen (in the Basic mode when the QCPU(Q mode) is used), and the key functions displayed on the screen.

(1) Display (with A68RD)



All types of data are displayed when the readout from the special function module is complete.
(OS executes it automatically.)

1)	Displays format of module being monitored.
2)	Displays buffer memory data of object module in its current form, or in a graph. Display status of I/O signal with the PLC CPU. When testing, tests after moving the cursor to the display position of the target data.
3)	The keys used for the operation with the monitor screen shown in (2) are displayed. (Touch input)

(2) Key functions

The chart below shows the functions of the keys that are used with the System monitor screen operation.

Key	Function
END	Monitoring ends; and display returns to the screen where the special module monitor function was begun.
MONIT MENU	Ends current monitoring and moves to screen that shows monitor menu. Operation can be used only if the special function module has a Monitor menu.
Data Chg.	Starts change of current values for buffer memory of special function module displayed on screen.
SET/RESET	Starts test set/reset for I/O signal between PLC CPU and special function module.

12.1.6 Specifying monitor module and selecting monitor menu


The operation when starting the special module monitor for an optional module is explained, using the positioning module (AD71) as an example.

[Operation procedure]

Display System Configuration screen. ...See Section 12.1.1.

[Specify module to be monitored] (Touch display position of module.)

Display screen that shows monitor menu.



[Specify menu to be monitored] (Touch display position of menu.)

Display monitor screen of specified menu.

AD71 Parameter Data Monitor Screen		SET/	Data	MONIT/	END
		[RESET]	[Data]	[MONIT]	[END]
X	Y	X Axis	Y Axis	X	ABCDDEF
V10	V11	Posit. Start	Travel/Pulse	01234567	01234567
V12		Interpolation	Finching Trav.	0123456789	0123456789
X02	X03	Posit. Compl.		01234567	01234567
X05	X06	Zero Request	Speed Limit	01234567	01234567
V13	V14	Zero Start	Jog Spd. Limit	01234567	01234567
X0C	X0D	Zero Complete	Acc/Dec Time	01234567	01234567
V17	V18	Fwd. Jog Start	Backlash Comp.	01234567	01234567
V19	V18	Rev. Jog Start	Upper Limit	0123456789	0123456789
V15	V16	Stop	Lower Limit	0123456789	0123456789
X08	X09	Pos. Started	Error Comp.	0123456789	0123456789
X04	X05	BUSY		00	00
X0E	X0F	M Code ON	Startling Bias	01234567	01234567
X00	X01	Err Man. Pulse	Compl. O/P Time	01234567	01234567
X08	X09	Batt. Err/Hi		00 mm	01 Inch
X08	X09	Erron	N/Hi	MCode/ErrCode	012 01 012 01
					10.0sec 11.FLS.

Proceed to Sec. 12.1.7 and Secs. 12.2 to 12.31.

(1) From among the modules installed in the corresponding base unit, specify the special function module whose format is displayed.

* For modules where the format is not displayed, monitor with the system monitor function (See Sec. 9.5.).

Specify input/output modules according to Sec. 13.1.

(2) Specify the menu corresponding to the type of data to be monitored.

(3) With modules for which the monitor menu cannot all be displayed in one screen, touch the ▲ ▼ keys at the right of the screen to scroll the display menu.

(4) Check the contents of the display. Carry out the subsequent operation according to Sec. 12.2 to 12.31.

(5) Carry out tests for the displayed data according to Sec. 12.1.7.

- Change current value of buffer memory
- Turn output signal from PLC CPU on and off

12.1.7 Test for special function module



CAUTION

- Read the manual carefully and fully understand the operation before the test operation (modifying the current value of a buffer memory) of special function module monitor.
In addition, never modify data in a test operation to a device which performs a crucial operation to the system. It may cause an accident by a false output or malfunction.

Testing can be performed for all buffer memory data displayed on the current monitor screen.

This section describes the operation for changing the current value of the buffer memory and turning the output signal from the PLC CPU to the special module on and off.


Point


- (1) When testing, test for the buffer memory to be written in from the PLC CPU and the output signal that is output from the PLC CPU.
- (2) Be sure to carry out the test operation with the PLC CPU in STOP status.
If the PLC CPU is tested during RUN status, it returns to the output values and output status from the sequence program.

[Operation procedure]

Display monitor screen.

		SET/	Data	MONIT	END		
		RESET	Chg.	MENU			
X	Y		X Axis	Y Axis	X ABCDEFF		
V10	V11		Travel/Pulse	01234567	01234567	0110110110110110	
V12			Interpolation	Inching Trav.	0123456789	0123456789	Y ABCDEFF
X02	X03		Posit. Compl.	Speed Limit	01234567	01234567	0110110110110110
X06	X07		Zero Request	Jog Spd.Limit	01234567	01234567	A:Pulse G/P Mode
V13	V14		Zero Start	Acc/Dec Time	01234567	01234567	0 B Type
X08	X09		Zero Complete	Backlash Comp	01234567	01234567	1 A Type
V17	V18		Fwd.Jog Start	Upper Limit	0123456789	0123456789	B:M Code Timing
V15	V16		Rev.Jog Start	Lower Limit	0123456789	0123456789	0 WITH Mode
X0B	X0C		Stop	Error Comp.	0123456789	0123456789	C:M Code DN/OFF
X0D	X0E		Pos. Started	Starting Bias	01234567	01234567	0 OFF 1 ON
X0F	X10		BUSY	Compl.G/P Time	01234567	01234567	DD:Posit. Method
X0E	X0E		M Code ON				00 ABS 01 INC
X0B	X0T		Err Man.Pulse				10 ABS + INC
X0B	Batt.ErrX:Hi		Compl.G/P Time				E:Direction
X0B	Err		X:Hi				0 Fwd 1 Rev
							FF:Unit Setting
							00 mm 01 inch
							10 dex 11 PLS





When **Data Chg.** is touched (changes current value of buffer memory)

- All of the following operations can be carried out by touching the keys in the displayed key window.
- When you touch  at the upper left of the key window, the key window closes and the display returns to the monitor screen.

(1) Move the cursor to the position where the data to be tested is displayed. (*1)

(▲ ▼ : Up/down ► ◀ : Left/right)

(2) Use the numeric keys to specify the value to be changed. (*2)

The **DEL** key can be used to clear individual characters among those input.

When **SET/RESET** is touched (tests the I/O signal)

- All of the following operations can be carried out by touching the keys in the displayed key window.
- When you touch  at the upper left of the key window, the key window closes and the display returns to the monitor screen.

(1) Use the alphabetic character keys to specify the name of the device to be tested, and then touch ►. (*1)

(2) Use the numeric keys to specify the device number, and then touch ►.

(3) Use the numeric keys to specify "Set" or "Reset".

0 : OFF **1** : ON

*1 Do not perform the following tests.

When testing, the module may not operate correctly or the buffer memory/input signal may return to the output value/output status from the special function module.

- 1) Test the buffer memory for reading-only from the PLC CPU.
- 2) Test the input signal to the PLC CPU from the special function module.

*2 When testing buffer memory data, specify the change value in the following way.

- 1) For data where 16/32 bits is displayed with one number, specify the change value in decimal.
- 2) For data where one number of 16/32 bits is displayed as a percent, such as with an A/D conversion module specify the change value corresponding to the percentage in decimal.


Example:

When the set value of the offset or gain is 0 to 2000, when specifying a change value of 50%, input 1000.

- 3) For data where 16 bits is displayed one bit at a time as "0" and "1", specify the change value of 16 bits in decimal.

12.1.8 Changing the screen

This section describes how to change the screen when executing each monitor function of the special module monitor function from the status where the user-created monitor screen is displayed.



12.2 A61LS Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>A61LS Operation Monitor Screen</p> <p>1) Limit Switch Function Program No. 0</p> <p>2) Channel No. FEDCBA9876543210 Output Status 0110110110110110 Output Enable 0110110110110110</p> <p>3) Measured Distance 0123456789</p> <p>4) Resolver Speed 0123 rpm</p> <p>5) Target Address 0123 Error 01</p> <p>6) Compensation Val. 0123 Underflow 0 Overflow 0</p> <p>7) Compensated Address 0123 Batt.Error 0</p> <p>8) 9) 10) 10)</p>	1)	11	000B
	2)	4	0004
	3)	10	000A
	4)	5, 6	0005, 0006
	5)	3	0003
	6)	12	000C
	7)	7	0007
	8)	0	0000
	9)	8	0008
	10)	2	0002
	11)	1	0001
	12)	9	0009
		13)	13 to 44
	-	---	---
<p>A61LS Input/Output Monitor Screen</p> <p>1)</p>	1)	---	---
		-	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.3 AD61 Module Monitor

Screen Image	No.	Buffer memory address																																																																																				
		dec.	hex.																																																																																			
<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: right;">SET/ Data MONIT END RESET Chg. MENU</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th>Present Value</th> <th>Set Value</th> <th>Mode</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>Channel 1</td> <td>01234567</td> <td>01234567</td> <td>0</td> <td>1: 1-Phase</td> </tr> <tr> <td>Channel 2</td> <td>01234567</td> <td>01234567</td> <td>0 3)</td> <td>2: 2-Phase</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Inputs (X)</th> <th colspan="2">Outputs (Y)</th> </tr> </thead> <tbody> <tr><td>00</td><td>CH1 Count Greater</td><td>00</td><td>CH1 Equal Reset</td></tr> <tr><td>01</td><td>CH1 Count Equal</td><td>01</td><td>CH1 Preset Cmd.</td></tr> <tr><td>02</td><td>CH1 Count Less</td><td>02</td><td>CH1 Equal O/P</td></tr> <tr><td>03</td><td>CH1 Ext. Preset</td><td>03</td><td>CH1 Down Count</td></tr> <tr><td>04</td><td>CH2 Count Greater</td><td>04</td><td>CH1 Count Enable</td></tr> <tr><td>05</td><td>CH2 Count Equal</td><td>05</td><td>CH1 Value Read</td></tr> <tr><td>06</td><td>CH2 Count Less</td><td>06</td><td>CH1 Ext. Preset</td></tr> <tr><td>07</td><td>CH2 Ext. Preset</td><td>07</td><td>CH2 Equal Reset</td></tr> <tr><td>08</td><td></td><td>08</td><td>CH2 Preset Cmd.</td></tr> <tr><td>09</td><td></td><td>09</td><td>CH2 Equal O/P</td></tr> <tr><td>0A</td><td></td><td>0A</td><td>CH2 Down Count</td></tr> <tr><td>0B</td><td></td><td>0B</td><td>CH2 Count Enable</td></tr> <tr><td>0C</td><td></td><td>0C</td><td>CH2 Value Read</td></tr> <tr><td>0D</td><td></td><td>0D</td><td>CH2 Ext. Preset</td></tr> <tr><td>0E</td><td></td><td>0E</td><td></td></tr> <tr><td>0F</td><td></td><td>0F</td><td></td></tr> </tbody> </table> </div>		Present Value	Set Value	Mode	Mode	Channel 1	01234567	01234567	0	1: 1-Phase	Channel 2	01234567	01234567	0 3)	2: 2-Phase	Inputs (X)		Outputs (Y)		00	CH1 Count Greater	00	CH1 Equal Reset	01	CH1 Count Equal	01	CH1 Preset Cmd.	02	CH1 Count Less	02	CH1 Equal O/P	03	CH1 Ext. Preset	03	CH1 Down Count	04	CH2 Count Greater	04	CH1 Count Enable	05	CH2 Count Equal	05	CH1 Value Read	06	CH2 Count Less	06	CH1 Ext. Preset	07	CH2 Ext. Preset	07	CH2 Equal Reset	08		08	CH2 Preset Cmd.	09		09	CH2 Equal O/P	0A		0A	CH2 Down Count	0B		0B	CH2 Count Enable	0C		0C	CH2 Value Read	0D		0D	CH2 Ext. Preset	0E		0E		0F		0F		1)	4, 5, 36, 37	0004, 0005, 0024, 0025
		Present Value	Set Value	Mode	Mode																																																																																	
	Channel 1	01234567	01234567	0	1: 1-Phase																																																																																	
	Channel 2	01234567	01234567	0 3)	2: 2-Phase																																																																																	
	Inputs (X)		Outputs (Y)																																																																																			
00	CH1 Count Greater	00	CH1 Equal Reset																																																																																			
01	CH1 Count Equal	01	CH1 Preset Cmd.																																																																																			
02	CH1 Count Less	02	CH1 Equal O/P																																																																																			
03	CH1 Ext. Preset	03	CH1 Down Count																																																																																			
04	CH2 Count Greater	04	CH1 Count Enable																																																																																			
05	CH2 Count Equal	05	CH1 Value Read																																																																																			
06	CH2 Count Less	06	CH1 Ext. Preset																																																																																			
07	CH2 Ext. Preset	07	CH2 Equal Reset																																																																																			
08		08	CH2 Preset Cmd.																																																																																			
09		09	CH2 Equal O/P																																																																																			
0A		0A	CH2 Down Count																																																																																			
0B		0B	CH2 Count Enable																																																																																			
0C		0C	CH2 Value Read																																																																																			
0D		0D	CH2 Ext. Preset																																																																																			
0E		0E																																																																																				
0F		0F																																																																																				
	2)	6, 7, 38, 39	0006, 0007, 0026, 0027																																																																																			
	3)	3, 35	0003, 0023																																																																																			
	4)	---	---																																																																																			
	-	---	---																																																																																			

12.4 A1SD61 Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>A1SD61 Operation Monitor Screen (CH1,2)</p> <p>1) Y10 Count Enable, Y11 Decremental Count, Y12 Preset Command, Y13 Ring Counter, X0D Sampling/Periodic, X0A External Preset, Y16 Reset Ext. Preset, Y17 Error Reset</p> <p>2) MDT Error, Error Code: 012</p> <p>3) No. of Dogs, ON CH.1 OFF, No. of Dogs, ON CH.2 OFF</p> <p>4) Channel No. Status</p> <p>5) Counter Setting: 0</p> <p>6) LS. O/P Status</p> <p>7) Present Value 01234567890</p> <p>8) Counter Function Count Value 01234567890</p> <p>9) Preset Value 01234567890</p> <p>10) Ring Counter Value 01234567890</p> <p>11) Pulse I/P Mode 012345</p>	1)	---	---
	2)	---	---
	3)	11	000B
	4)	12 to 147	000C to 0093
	5)	12 to 147	000C to 0093
	6)	5	0005
	7)	---	---
	8)	0, 1	0000, 0001
	9)	2, 3	0002, 0003
	10)	6, 7	0006, 0007
	11)	8, 9	0008, 0009
	-	---	---
<p>A1SD61 Input/Output Monitor Screen</p> <p>1) Inputs (X) and Outputs (Y) list</p>	1)	---	---
	-	---	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.5 A62DA-S1 Module Monitor




Screen Image	No.	Buffer memory address	
		dec.	hex.
	1)	0, 1	0000, 0001
	2)	2 to 5	0002 to 0005
	3)	---	---
	-	---	---
	1)	0, 1	0000, 0001
	2)	2, 4	0002, 0004
	3)	3, 5	0003, 0005
	4)	---	---
-	---	---	

12.6 A1S62DA Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
	1)	0	0000
	2)	1	0001
	3)	2	0002
	4)	---	---
	5)	1, 2	0001, 0002
	6)		
	7)		
	8)		
	9)		
	10)		
	11)	10	000A
	12)	11	000B
	13)	9	0009
	-	---	---




9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.8 A1S62RD Module Monitor




Screen Image	No.	Buffer memory address	
		dec.	hex.
 <p>A1S62RD Operation Monitor Screen</p> <p>Temp. Value [C] (16 bits), Temp. Value [C] (32 bits), Time/Count, Disabled/Enabled, Conversion, Average/Sample, Time/Count, 1: Averaging, 1: Time Average, 0: Sampling, 0: Count Average, CH.1 Disconnection detection, CH.2 Disconnection detection, WDT Error, Error Code:012345, Temp. Sensor Type 0, 0:New JIS,DIN, 1:01d JIS</p>	1)	10, 11	000A, 000B
	2)	18 to 21	0012 to 0015
	3)	2, 3	0002, 0003
	4)	0	0000
	5)	35	0023
	6)	1	0001
	7)	1	0001
	8)	---	---
	9)	34	0022
	10)	36	0024
 <p>A1S62RD Input/Output Monitor Screen</p> <p>Inputs (X), Outputs (Y), 00 WDT Error, 01 READY, 02 Error Detection, 03 CH1 Disconnected, 04 CH2 Disconnected, 05, 06, 07, 08, 09, 0A, 0B, 0C, 0D, 0E, 0F</p>	1)	---	---
	-	---	---
 <p>A1S62RD Graph Monitor Screen</p> <p>Temperature graph showing two bars, Disabled/Enabled, Conversion, Average/Sample, Time/Count, 1: Averaging, 1: Time Average, 0: Sampling, 0: Count Average, Channel 1 disconnected, Channel 2 disconnected, WDT Error, Error Code:012345, Temp. Sensor Type 0, 0:New JIS,DIN, 1:01d JIS</p>	1)	10, 11	000A, 000B
	2)	0	0000
	3)	35	0023
	4)	1	0001
	5)	1	0001
	6)	---	---
	7)	34	0022
	8)	36	0024
-	---	---	

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.9 A1S63ADA Module Monitor




Screen Image		No.	Buffer memory address	
			dec.	hex.
 <p>1) CH No. Setting: 321 (0110110110110110) / 21 (0110110110110110)</p> <p>2) Sample/Average: 21 / 21</p> <p>3) CH No. Setting: 21 (0110110110110110)</p> <p>4) Input Status: 0: Sampling, 1: Averaging</p> <p>5) CH 1: 012345, CH 2: 012345</p> <p>6) CH 3: 012345</p> <p>7) Error Code: 012, Resolution Setting: 0 [1:1/4000,2:1/8000,3:1/12000]</p> <p>11) 12)</p>		1)	0	0000
		2)	15	000F
		3)	1	0001
		4)		
		5)	2, 3	0002, 0003
		6)	11, 12	000B, 000C
		7)	4	0004
		8)	5	0005
		9)	10	000A
		10)	13	000D
		11)	16	0010
		12)	14	000E
		-	---	---
 <p>1) Exec.Enable: 0: Disabled, 1: Enabled, Y11</p> <p>2) Control Mode: 012345</p> <p>3) Constant A: 012.45, Constant B: 012.45, Constant C: 012345</p> <p>7) 8)</p>		1)	---	---
		2)	6	0006
		3)	7, 8, 9	0007, 0008, 0009
		4)	18 to 37	0012 to 0025
		5)		
		6)	17	0011
		7)	16	0010
		8)	14	000E
		-	---	---
 <p>1)</p>		1)	---	---
		-	---	---

12.10 A1S64AD Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
 <p>The screen shows channel settings and input status for four channels. Channel 1 is selected. Resolution is set to 0 (1/4000). Error code is 012.</p>	1)	0	0000
	2)	1	0001
	3)	1	0001
	4)	2 to 5	0002 to 0005
	5)	10 to 13	000A to 000D
	6)	18	0012
	7)	20	0014
-	-	---	---
 <p>The screen displays a list of inputs (X) and outputs (Y) from 00 to 0F. Input 00 is HDT Error Flag, and output 02 is Error Reset.</p>	1)	---	---
	-	-	---
 <p>The screen shows three bar graphs for Channel 1, 2, and 3 at three different resolutions: 1 (1/4000), 2 (1/8000), and 3 (1/12000). Resolution 0 is selected.</p>	1)	10 to 13	000A to 000D
	2)	20	0014
	3)	---	---
	4)	---	---
-	-	---	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NETWORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.11 A68AD Module Monitor




Screen Image		No.	Buffer memory address																																			
			dec.	hex.																																		
 <p>A68AD Operation Monitor Screen</p> <p>Channel No. 87654321 87654321 0:Sampling 0:Count Average Setting 01101101 10110110 1:Averaging 1:Time Average</p> <table border="1"> <thead> <tr> <th>Count/Time Value</th> <th>Input Status [%]</th> </tr> </thead> <tbody> <tr><td>Channel 1</td><td>01234</td></tr> <tr><td>Channel 2</td><td>01234</td></tr> <tr><td>Channel 3</td><td>01234</td></tr> <tr><td>Channel 4</td><td>01234</td></tr> <tr><td>Channel 5</td><td>01234</td></tr> <tr><td>Channel 6</td><td>01234</td></tr> <tr><td>Channel 7</td><td>01234</td></tr> <tr><td>Channel 8</td><td>01234</td></tr> </tbody> </table> <p>No. of Channels Used 0 Writing Data Error 01</p>		Count/Time Value	Input Status [%]	Channel 1	01234	Channel 2	01234	Channel 3	01234	Channel 4	01234	Channel 5	01234	Channel 6	01234	Channel 7	01234	Channel 8	01234	1)	1	0001																
		Count/Time Value	Input Status [%]																																			
		Channel 1	01234																																			
		Channel 2	01234																																			
		Channel 3	01234																																			
		Channel 4	01234																																			
Channel 5	01234																																					
Channel 6	01234																																					
Channel 7	01234																																					
Channel 8	01234																																					
2)	1	0001																																				
3)	2 to 9	0002 to 0009																																				
4)	10 to 17	000A to 0011																																				
5)	0	0000																																				
6)	34	0022																																				
		-	---	---																																		
 <p>A68AD Input/Output Monitor Screen</p> <table border="1"> <thead> <tr> <th>Inputs (X)</th> <th>Outputs (Y)</th> </tr> </thead> <tbody> <tr><td>00 WDT Error</td><td>10</td></tr> <tr><td>01 READY</td><td>11</td></tr> <tr><td>02</td><td>12</td></tr> <tr><td>03</td><td>13</td></tr> <tr><td>04</td><td>14</td></tr> <tr><td>05</td><td>15</td></tr> <tr><td>06</td><td>16</td></tr> <tr><td>07</td><td>17</td></tr> <tr><td>08</td><td>18</td></tr> <tr><td>09</td><td>19</td></tr> <tr><td>0A</td><td>1A</td></tr> <tr><td>0B</td><td>1B</td></tr> <tr><td>0C</td><td>1C</td></tr> <tr><td>0D</td><td>1D</td></tr> <tr><td>0E</td><td>1E</td></tr> <tr><td>0F</td><td>1F</td></tr> </tbody> </table>		Inputs (X)	Outputs (Y)	00 WDT Error	10	01 READY	11	02	12	03	13	04	14	05	15	06	16	07	17	08	18	09	19	0A	1A	0B	1B	0C	1C	0D	1D	0E	1E	0F	1F	1)	---	---
		Inputs (X)	Outputs (Y)																																			
00 WDT Error	10																																					
01 READY	11																																					
02	12																																					
03	13																																					
04	14																																					
05	15																																					
06	16																																					
07	17																																					
08	18																																					
09	19																																					
0A	1A																																					
0B	1B																																					
0C	1C																																					
0D	1D																																					
0E	1E																																					
0F	1F																																					
		-	---	---																																		
 <p>A68AD Graph Monitor Screen</p> <p>Input [%]</p> <table border="1"> <thead> <tr> <th>Channel</th> <th>Input [%]</th> </tr> </thead> <tbody> <tr><td>Channel 1</td><td>50</td></tr> <tr><td>Channel 2</td><td>75</td></tr> <tr><td>Channel 3</td><td>50</td></tr> <tr><td>Channel 4</td><td>60</td></tr> <tr><td>Channel 5</td><td>65</td></tr> <tr><td>Channel 6</td><td>80</td></tr> <tr><td>Channel 7</td><td>40</td></tr> <tr><td>Channel 8</td><td>35</td></tr> </tbody> </table> <p>Legend: ■ WDT Error</p>		Channel	Input [%]	Channel 1	50	Channel 2	75	Channel 3	50	Channel 4	60	Channel 5	65	Channel 6	80	Channel 7	40	Channel 8	35	1)	10 to 17	000A to 0011																
		Channel	Input [%]																																			
Channel 1	50																																					
Channel 2	75																																					
Channel 3	50																																					
Channel 4	60																																					
Channel 5	65																																					
Channel 6	80																																					
Channel 7	40																																					
Channel 8	35																																					
		2)	---	---																																		
		-	---	---																																		

12.12 A1S68AD Module Monitor




Screen Image	No.	Buffer memory address																												
		dec.	hex.																											
<p>A1S68AD Movement Monitor Screen</p> <p>1) A/D Conversion 01101101 0: Disabled 1: Enabled</p> <p>2) A/D Method 01101101 0: Sampling 1: Averaging</p> <p>3) Averaging 01101101 0: Number 1: Time</p> <p>4) A/D Conversion 01101101 0: Incomplete 1: Complete</p> <table border="1"> <thead> <tr> <th>CH</th> <th>Averaging Time/Number</th> <th>Input Status [%]</th> </tr> </thead> <tbody> <tr><td>CH 1</td><td>01234</td><td>01234.6</td></tr> <tr><td>CH 2</td><td>01234</td><td>01234.6</td></tr> <tr><td>CH 3</td><td>01234</td><td>01234.6</td></tr> <tr><td>CH 4</td><td>01234</td><td>01234.6</td></tr> <tr><td>CH 5</td><td>5) 01234</td><td>6) 01234.6</td></tr> <tr><td>CH 6</td><td>01234</td><td>01234.6</td></tr> <tr><td>CH 7</td><td>01234</td><td>01234.6</td></tr> <tr><td>CH 8</td><td>01234</td><td>01234.6</td></tr> </tbody> </table> <p>Error Code 012</p> <p>7)</p>	CH	Averaging Time/Number	Input Status [%]	CH 1	01234	01234.6	CH 2	01234	01234.6	CH 3	01234	01234.6	CH 4	01234	01234.6	CH 5	5) 01234	6) 01234.6	CH 6	01234	01234.6	CH 7	01234	01234.6	CH 8	01234	01234.6	1)	0	0000
	CH	Averaging Time/Number	Input Status [%]																											
	CH 1	01234	01234.6																											
	CH 2	01234	01234.6																											
	CH 3	01234	01234.6																											
	CH 4	01234	01234.6																											
	CH 5	5) 01234	6) 01234.6																											
CH 6	01234	01234.6																												
CH 7	01234	01234.6																												
CH 8	01234	01234.6																												
	2)	2	0002																											
	3)	2	0002																											
	4)	28	001C																											
	5)	10 to 17	000A to 0011																											
	6)	20 to 27	0014 to 001B																											
	7)	1	0001																											
	-	---	---																											
<p>A1S68AD Input/Output Monitor Screen</p> <p>1) 00 HDT Error 10 00 10</p> <p>01 Ready 11 01 11</p> <p>02 Error Detect 12 02 03 Error Reset</p> <p>03 13 03 13</p> <p>04 14 04 14</p> <p>05 15 05 15</p> <p>06 16 06 16</p> <p>07 17 07 17</p> <p>08 18 08 18</p> <p>09 19 09 19</p> <p>0A 1A 0A 1A</p> <p>0B 1B 0B 1B</p> <p>0C 1C 0C 1C</p> <p>0D 1D 0D 1D</p> <p>0E 1E 0E 1E</p> <p>0F 1F 0F 1F</p>	1)	---	---																											
		-	---	---																										
<p>A1S68AD Graph Monitor Screen</p> <p>1) CH 1 50</p> <p>CH 2 45</p> <p>CH 3 60</p> <p>CH 4 1) 35</p> <p>CH 5 10</p> <p>CH 6 30</p> <p>CH 7 90</p> <p>CH 8 25</p> <p>2) HDT Error</p>	1)	20 to 27	0014 to 001B																											
		2)	---	---																										
	-	---	---																											

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.13 A68ADN Module Monitor




Screen Image		No.	Buffer memory address	
			dec.	hex.
 <p>The screenshot shows the 'A68ADN Operation Monitor Screen'. It includes fields for Channel, Setting, Sample/Average, and Count/Time. A table lists input status for 8 channels. At the bottom, it shows Error Code 012 and Resolution Selection 0. Callouts 1) through 7) point to specific elements: 1) Channel Setting, 2) Sample/Average, 3) Count/Time, 4) Channel 4 Count/Time, 5) Input Status Resolution 1, 6) Error Code, and 7) Resolution Selection.</p>		1)	0	0000
		2)	1	0001
		3)	1	0001
		4)	2 to 9	0002 to 0009
		5)	10 to 17	000A to 0011
		6)	18	0012
		7)	20	0014
		-	---	---
 <p>The screenshot shows the 'A68ADN Input/Output Monitor Screen'. It displays a table of inputs (X) and outputs (Y) from 00 to 0F. Callout 1) points to the '00 WDT Error' entry.</p>		1)	---	---
		-	---	---
 <p>The screenshot shows the 'A68ADN Graph Monitor Screen'. It features three bar graphs for Resolution 1, 2, and 3, showing input percentages for 8 channels. Callout 1) points to the Channel 3 bar in Resolution 1. Callouts 2), 3), and 4) point to Resolution Selection 0, Error, and WDT Error respectively.</p>		1)	10 to 17	000A to 0011
		2)	20	0014
		3)	---	---
		4)	---	---
		-	---	---

12.14 A68RD Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
 <p>A68RD Operation Monitor Screen</p> <p>Temp. Value (16 bits), Temp. Value (32 bits), Time/Count, Disabled/Enabled, Conversion, Average/Sample, Time/Count, HDT Error, Error Code, Temp. Sensor Type, New JIS, DIN</p>	1)	10 to 17	000A to 0011
	1)	18 to 33	0012 to 0021
	2)	2 to 9	0002 to 0009
	3)	0	0000
	4)	35	0023
	5)	1	0001
	6)	1	0001
	7)	---	---
	8)	34	0022
	9)	36	0024
 <p>A68RD Input/Output Monitor Screen</p> <p>Inputs (X), Outputs (Y)</p>	10)	---	---
	-	---	---
 <p>A68RD Graph Monitor Screen</p> <p>Temperature Graph, Disabled/Enabled, Conversion, Sample/Average, Count/Time, HDT Error, Error Code, Temp. Sensor Type, New JIS, DIN</p>	1)	10 to 17	000A to 0011
	2)	0	0000
	3)	35	0023
	4)	1	0001
	5)	1	0001
	6)	---	---
	7)	34	0022
	8)	36	0024
-	---	---	

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.15 A1S68DAI,A1S68DAV Module Monitor

Screen Image	No.	Buffer memory address																																					
		dec.	hex.																																				
 <p>A1S68DAV Movement Monitor Screen</p> <p>SET/RESET Data Chg. MONIT MENU END</p> <p>C H 8 7 6 5 4 3 2 1</p> <p>Analog Output 01101101 0 : Enabled</p> <p>1 : Disabled</p> <table border="1"> <thead> <tr> <th>CH</th> <th>Output Status [%]</th> <th>Up Limit</th> <th>Low Limit</th> </tr> </thead> <tbody> <tr><td>CH 1</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 2</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 3</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 4</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 5</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 6</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 7</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 8</td><td>012345.7</td><td>0</td><td>0</td></tr> </tbody> </table> <p>Up/Low Limit 0 : OK 1 : Error</p>	CH	Output Status [%]	Up Limit	Low Limit	CH 1	012345.7	0	0	CH 2	012345.7	0	0	CH 3	012345.7	0	0	CH 4	012345.7	0	0	CH 5	012345.7	0	0	CH 6	012345.7	0	0	CH 7	012345.7	0	0	CH 8	012345.7	0	0	1)	0	0000
	CH	Output Status [%]	Up Limit	Low Limit																																			
	CH 1	012345.7	0	0																																			
	CH 2	012345.7	0	0																																			
CH 3	012345.7	0	0																																				
CH 4	012345.7	0	0																																				
CH 5	012345.7	0	0																																				
CH 6	012345.7	0	0																																				
CH 7	012345.7	0	0																																				
CH 8	012345.7	0	0																																				
2)	1 to 8	0001 to 0008																																					
3)	10 to 17	000A to 0011																																					
4)	10 to 17	000A to 0011																																					
	-	---	---																																				
 <p>A1S68DAV Input/Output Monitor Screen</p> <p>SET/RESET Data Chg. MONIT MENU END</p> <table border="1"> <thead> <tr> <th>X</th> <th>Y</th> </tr> </thead> <tbody> <tr><td>00 WDT Error</td><td>10 CH1 Enable</td></tr> <tr><td>01 Ready</td><td>11 CH2 Enable</td></tr> <tr><td>02 Error Detect</td><td>12 CH3 Enable</td></tr> <tr><td>03</td><td>13 CH4 Enable</td></tr> <tr><td>04</td><td>14 CH5 Enable</td></tr> <tr><td>05</td><td>15 CH6 Enable</td></tr> <tr><td>06</td><td>16 CH7 Enable</td></tr> <tr><td>07</td><td>17 CH8 Enable</td></tr> <tr><td>08</td><td>18 Error Reset</td></tr> <tr><td>09</td><td>19</td></tr> <tr><td>0A</td><td>1A</td></tr> <tr><td>0B</td><td>1B</td></tr> <tr><td>0C</td><td>1C</td></tr> <tr><td>0D</td><td>1D</td></tr> <tr><td>0E</td><td>1E</td></tr> <tr><td>0F</td><td>1F</td></tr> </tbody> </table>	X	Y	00 WDT Error	10 CH1 Enable	01 Ready	11 CH2 Enable	02 Error Detect	12 CH3 Enable	03	13 CH4 Enable	04	14 CH5 Enable	05	15 CH6 Enable	06	16 CH7 Enable	07	17 CH8 Enable	08	18 Error Reset	09	19	0A	1A	0B	1B	0C	1C	0D	1D	0E	1E	0F	1F	1)	---	---		
	X	Y																																					
00 WDT Error	10 CH1 Enable																																						
01 Ready	11 CH2 Enable																																						
02 Error Detect	12 CH3 Enable																																						
03	13 CH4 Enable																																						
04	14 CH5 Enable																																						
05	15 CH6 Enable																																						
06	16 CH7 Enable																																						
07	17 CH8 Enable																																						
08	18 Error Reset																																						
09	19																																						
0A	1A																																						
0B	1B																																						
0C	1C																																						
0D	1D																																						
0E	1E																																						
0F	1F																																						
	-	---	---																																				
 <p>A1S68DAV Graph Monitor Screen</p> <p>SET/RESET Data Chg. MONIT MENU END</p> <p>Output [%] 0 50 100</p> <table border="1"> <thead> <tr> <th>CH</th> <th>Output [%]</th> </tr> </thead> <tbody> <tr><td>CH 1</td><td>~60</td></tr> <tr><td>CH 2</td><td>~75</td></tr> <tr><td>CH 3</td><td>~40</td></tr> <tr><td>CH 4</td><td>~65</td></tr> <tr><td>CH 5</td><td>~55</td></tr> <tr><td>CH 6</td><td>~20</td></tr> <tr><td>CH 7</td><td>~45</td></tr> <tr><td>CH 8</td><td>~85</td></tr> </tbody> </table> <p>C H 8 7 6 5 4 3 2 1 0 : Enabled</p> <p>Analog Output 01101101 1 : Disabled</p> <p>Legend: ■ WDT Error, ■ Error</p>	CH	Output [%]	CH 1	~60	CH 2	~75	CH 3	~40	CH 4	~65	CH 5	~55	CH 6	~20	CH 7	~45	CH 8	~85	1)	1 to 8	0001 to 0008																		
	CH	Output [%]																																					
	CH 1	~60																																					
	CH 2	~75																																					
CH 3	~40																																						
CH 4	~65																																						
CH 5	~55																																						
CH 6	~20																																						
CH 7	~45																																						
CH 8	~85																																						
2)	0	0000																																					
3)	---	---																																					
4)	10 to 17	000A to 0011																																					
	-	---	---																																				




12.16 A616AD Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>A616AD Operation Monitor Screen</p> <p>1) Enable FEDCBA9876543210 0110110110110110 0: Disabled 1: Enabled</p> <p>2) Data Format FEDCBA9876543210 Setting 0110110110110110</p> <p>3) CH 0 01234.6 01234.6 CH 8 01234.6 01234.6 CH 1 01234.6 01234.6 CH 9 01234.6 01234.6 CH 2 01234.6 01234.6 CH A 01234.6 01234.6 CH 3 01234.6 01234.6 CH B 01234.6 01234.6 CH 4 01234.6 01234.6 CH C 01234.6 01234.6 CH 5 01234.6 01234.6 CH D 01234.6 01234.6 CH 6 01234.6 01234.6 CH E 01234.6 01234.6 CH 7 01234.6 01234.6 CH F 01234.6 01234.6</p> <p>4) Error Code 01 Error FEDCBA9876543210 CNT No. 0110110110110110</p> <p>5) Sampling time 01234 ms</p> <p>6) Input Status For Data Format 0: Refer to left hand side values. Format 1: Refer to right hand side values.</p> <p>7) Direct Access INPUT CH:0 MX CH:0 I/P: 01234.6 01234.6</p>	1)	15	000F
	2)	4	0004
	3)	48 to 63	0030 to 003F
	4)	5	0005
	5)	3	0003
	6)	0	0000
	7)	2	0002
-	-	---	---
<p>A616AD Operation Monitor Screen CONNECT No.0</p> <p>1) Enable FEDCBA9876543210 0110110110110110 0: Disabled 1: Enabled</p> <p>2) Data Format * Setting 0110110110110110</p> <p>3) CH 0 01234.6 01234.6 CH 8 01234.6 01234.6 CH 1 01234.6 01234.6 CH 9 01234.6 01234.6 CH 2 01234.6 01234.6 CH A 01234.6 01234.6 CH 3 01234.6 01234.6 CH B 01234.6 01234.6 CH 4 01234.6 01234.6 CH C 01234.6 01234.6 CH 5 01234.6 01234.6 CH D 01234.6 01234.6 CH 6 01234.6 01234.6 CH E 01234.6 01234.6 CH 7 01234.6 01234.6 CH F 01234.6 01234.6</p> <p>4) Error Code 01 Error FEDCBA9876543210 CNT No. 0110110110110110</p> <p>5) Sampling time 01234 ms</p> <p>6) Input Status For Data Format 0: Refer to left hand side values. Format 1: Refer to right hand side values.</p> <p>7) Direct Access INPUT CH:0 MX CH:0 I/P: 01234.6 01234.6</p> <p>8) 9)</p>	1)	---	---
	2)	16 to 23	0010 to 0017
	3)	4	0004
	4)	256 to 383	0100 to 017F
	5)	5	0005
	6)	6	0006
	7)	3	0003
	8)	1	0001
	9)	2	0002
-	-	---	---
<p>A616AD Input/Output Monitor Screen</p> <p>1) Inputs (X) Outputs (Y)</p> <p>00 WDT Error 10 00 10 01 READY 11 01 11 02 Error 12 02 12 03 13 03 13 04 14 04 14 05 15 05 15 06 16 06 16 07 17 07 17 08 18 08 18 09 19 09 19 0A 1A 0A 1A 0B 1B 0B 1B 0C 1C 0C 1C 0D 1D 0D 1D 0E 1E 0E 1E 0F 1F 0F 1F</p> <p>19 Direct Access</p>	1)	---	---
-	-	---	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>A616AD Graph Monitor Screen</p> <p>Input [%] 0/0 50 100/50 100</p> <p>Channel 0 to Channel F</p> <p>Scale A (0): Data Format 0</p> <p>Scale B (0): Data Format 1</p> <p>Legend: ■ WDT Error, ■ Error</p> <p>Channel No. FEDCBA9876543210</p> <p>Data Format 0110110110110110</p> <p>Enable 0110110110110110</p> <p>0: Disabled 1: Enabled</p>	1)	48 to 63	0030 to 003F
	2)	---	---
	3)	4	0004
	15	000F	
-	-	---	---
<p>A616AD Graph Monitor Screen</p> <p>CONNECT No. 0</p> <p>Input [%] 0/0 50 100/50 100</p> <p>Channel 0 to Channel F</p> <p>Scale A (0): Data Format 0</p> <p>Scale B (0): Data Format 1</p> <p>Legend: ■ WDT Error, ■ Error</p> <p>Connect No. * Channel No. FEDCBA9876543210</p> <p>Data Format 0110110110110110 Enable 0110110110110110</p> <p>0: Disabled 1: Enabled</p>	1)	---	---
	2)	256 to 383	0100 to 017F
	3)	---	---
	4)	4	0004
	16 to 23	0010 to 0017	
-	-	---	---

12.17 A616DAI,A616DAV Module Monitor

Screen Image	No.	Buffer memory address																																																																									
		dec.	hex.																																																																								
 <p>A616DAI Operation Monitor Screen</p> <p>Channel No. FEDCBA9876543210</p> <p>D/A Conversion 0110110110110110 0: Disabled</p> <p>Output Enable 0110110110110110 1: Enabled</p> <table border="1"> <thead> <tr> <th></th> <th>Output [%]</th> <th>Over Error</th> <th>Under Error</th> <th></th> <th>Output [%]</th> <th>Over Error</th> <th>Under Error</th> </tr> </thead> <tbody> <tr><td>CH 0</td><td>012345.7</td><td>0</td><td>0</td><td>CH 8</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 1</td><td>012345.7</td><td>0</td><td>0</td><td>CH 9</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 2</td><td>012345.7</td><td>0</td><td>0</td><td>CH A</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 3</td><td>012345.7</td><td>0</td><td>0</td><td>CH B</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 4</td><td>012345.7</td><td>0</td><td>0</td><td>CH C</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 5</td><td>012345.7</td><td>0</td><td>0</td><td>CH D</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 6</td><td>012345.7</td><td>0</td><td>0</td><td>CH E</td><td>012345.7</td><td>0</td><td>0</td></tr> <tr><td>CH 7</td><td>012345.7</td><td>0</td><td>0</td><td>CH F</td><td>012345.7</td><td>0</td><td>0</td></tr> </tbody> </table> <p>Over/Under Error 0: Normal 1: Error</p>		Output [%]	Over Error	Under Error		Output [%]	Over Error	Under Error	CH 0	012345.7	0	0	CH 8	012345.7	0	0	CH 1	012345.7	0	0	CH 9	012345.7	0	0	CH 2	012345.7	0	0	CH A	012345.7	0	0	CH 3	012345.7	0	0	CH B	012345.7	0	0	CH 4	012345.7	0	0	CH C	012345.7	0	0	CH 5	012345.7	0	0	CH D	012345.7	0	0	CH 6	012345.7	0	0	CH E	012345.7	0	0	CH 7	012345.7	0	0	CH F	012345.7	0	0	1)	0	0000
		Output [%]	Over Error	Under Error		Output [%]	Over Error	Under Error																																																																			
	CH 0	012345.7	0	0	CH 8	012345.7	0	0																																																																			
	CH 1	012345.7	0	0	CH 9	012345.7	0	0																																																																			
CH 2	012345.7	0	0	CH A	012345.7	0	0																																																																				
CH 3	012345.7	0	0	CH B	012345.7	0	0																																																																				
CH 4	012345.7	0	0	CH C	012345.7	0	0																																																																				
CH 5	012345.7	0	0	CH D	012345.7	0	0																																																																				
CH 6	012345.7	0	0	CH E	012345.7	0	0																																																																				
CH 7	012345.7	0	0	CH F	012345.7	0	0																																																																				
		1	0001																																																																								
	2)	---	0010 to 001F																																																																								
	3)	48 to 63	0030 to 003F																																																																								
	4)	48 to 63	0030 to 003F																																																																								
	-	---	---																																																																								
 <p>A616DAI Input/Output Monitor Screen</p> <table border="1"> <thead> <tr> <th colspan="2">Inputs (X)</th> <th colspan="2">Outputs (Y)</th> </tr> </thead> <tbody> <tr><td>00</td><td>WDT Error</td><td>10</td><td>00</td></tr> <tr><td>01</td><td>READY</td><td>11</td><td>01</td></tr> <tr><td>02</td><td>Error</td><td>12</td><td>02</td></tr> <tr><td>03</td><td></td><td>13</td><td>03</td></tr> <tr><td>04</td><td></td><td>14</td><td>04</td></tr> <tr><td>05</td><td></td><td>15</td><td>05</td></tr> <tr><td>06</td><td></td><td>16</td><td>06</td></tr> <tr><td>07</td><td></td><td>17</td><td>07</td></tr> <tr><td>08</td><td></td><td>18</td><td>08</td></tr> <tr><td>09</td><td></td><td>19</td><td>09</td></tr> <tr><td>0A</td><td></td><td>1A</td><td>0A</td></tr> <tr><td>0B</td><td></td><td>1B</td><td>Output Enable</td></tr> <tr><td>0C</td><td></td><td>1C</td><td></td></tr> <tr><td>0D</td><td></td><td>1D</td><td></td></tr> <tr><td>0E</td><td></td><td>1E</td><td></td></tr> <tr><td>0F</td><td></td><td>1F</td><td></td></tr> </tbody> </table>	Inputs (X)		Outputs (Y)		00	WDT Error	10	00	01	READY	11	01	02	Error	12	02	03		13	03	04		14	04	05		15	05	06		16	06	07		17	07	08		18	08	09		19	09	0A		1A	0A	0B		1B	Output Enable	0C		1C		0D		1D		0E		1E		0F		1F		1)	---	---				
	Inputs (X)		Outputs (Y)																																																																								
00	WDT Error	10	00																																																																								
01	READY	11	01																																																																								
02	Error	12	02																																																																								
03		13	03																																																																								
04		14	04																																																																								
05		15	05																																																																								
06		16	06																																																																								
07		17	07																																																																								
08		18	08																																																																								
09		19	09																																																																								
0A		1A	0A																																																																								
0B		1B	Output Enable																																																																								
0C		1C																																																																									
0D		1D																																																																									
0E		1E																																																																									
0F		1F																																																																									
 <p>A616DAI Graph Monitor Screen</p> <p>Channel 0 to Channel F</p> <p>Output Enable 0110110110110110 1: Enabled</p> <p>Legend: ■ WDT Error, ■ Error</p>	1)	16 to 31	10 to 1F																																																																								
		2)	0	0																																																																							
			1	1																																																																							
		3)	---	---																																																																							
	-	---	---																																																																								

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.18 A616TD Module Monitor

Screen Image	No.	Buffer memory address																																																																					
		dec.	hex.																																																																				
<p>A616TD Operation Monitor Screen INPUT 0-F</p> <p>Channel No. FEDCBA9876543210 Error Code 01</p> <p>Conversion 0110110110110110</p> <p>Enable 0: Disabled 1: Enabled Error FEDCBA9876543210</p> <p>Channel No. FEDCBA9876543210 CNT No. 0110110110110110</p> <p>Data Format 0110110110110110 Sampling Time 01234 ms</p> <p>Input Status For Data Format 0: Refer to left hand side values Format 1: Refer to right hand side values</p> <table border="1"> <tr><td>CH 0</td><td>01234.6</td><td>01234.6</td><td>CH 8</td><td>01234.6</td><td>01234.6</td></tr> <tr><td>CH 1</td><td>01234.6</td><td>01234.6</td><td>CH 9</td><td>01234.6</td><td>01234.6</td></tr> <tr><td>CH 2</td><td>01234.6</td><td>01234.6</td><td>CH A</td><td>01234.6</td><td>01234.6</td></tr> <tr><td>CH 3</td><td>01234.6</td><td>01234.6</td><td>CH B</td><td>01234.6</td><td>01234.6</td></tr> <tr><td>CH 4</td><td>01234.6</td><td>01234.6</td><td>CH C</td><td>01234.6</td><td>01234.6</td></tr> <tr><td>CH 5</td><td>01234.6</td><td>01234.6</td><td>CH D</td><td>01234.6</td><td>01234.6</td></tr> <tr><td>CH 6</td><td>01234.6</td><td>01234.6</td><td>CH E</td><td>01234.6</td><td>01234.6</td></tr> <tr><td>CH 7</td><td>01234.6</td><td>01234.6</td><td>CH F</td><td>01234.6</td><td>01234.6</td></tr> </table> <p>Digital Value Error Temp. Values Error Discontinuity Error</p>	CH 0	01234.6	01234.6	CH 8	01234.6	01234.6	CH 1	01234.6	01234.6	CH 9	01234.6	01234.6	CH 2	01234.6	01234.6	CH A	01234.6	01234.6	CH 3	01234.6	01234.6	CH B	01234.6	01234.6	CH 4	01234.6	01234.6	CH C	01234.6	01234.6	CH 5	01234.6	01234.6	CH D	01234.6	01234.6	CH 6	01234.6	01234.6	CH E	01234.6	01234.6	CH 7	01234.6	01234.6	CH F	01234.6	01234.6	1)	15	000F																				
	CH 0	01234.6	01234.6	CH 8	01234.6	01234.6																																																																	
	CH 1	01234.6	01234.6	CH 9	01234.6	01234.6																																																																	
	CH 2	01234.6	01234.6	CH A	01234.6	01234.6																																																																	
	CH 3	01234.6	01234.6	CH B	01234.6	01234.6																																																																	
	CH 4	01234.6	01234.6	CH C	01234.6	01234.6																																																																	
	CH 5	01234.6	01234.6	CH D	01234.6	01234.6																																																																	
	CH 6	01234.6	01234.6	CH E	01234.6	01234.6																																																																	
	CH 7	01234.6	01234.6	CH F	01234.6	01234.6																																																																	
	2)	0	0000																																																																				
3)	1	0001																																																																					
4)	2	0002																																																																					
5)	4	0004																																																																					
6)	112 to 127	0070 to 007F																																																																					
7)	---	---																																																																					
8)	---	---																																																																					
9)	---	---																																																																					
-	---	---																																																																					
<p>A616TD Operation Monitor Screen CONNECT No. 0</p> <p>Channel No. FEDCBA9876543210 Digital Value Err 0110110110110110</p> <p>Conversion 0110110110110110 Temp. Value Err 0110110110110110</p> <p>Enable 0: Disabled 1: Enabled Discontinuity Err 0110110110110110</p> <p>Data Format 0110110110110110 Disc. Error Enable 0110110110110110</p> <p>* 0: Normal/Disabled 1: Break/Enabled</p> <table border="1"> <tr><td>CH 0</td><td>01234.6</td><td>01234.6</td><td>0123.5</td><td>CH 8</td><td>01234.6</td><td>01234.6</td><td>0123.5</td></tr> <tr><td>CH 1</td><td>01234.6</td><td>01234.6</td><td>0123.5</td><td>CH 9</td><td>01234.6</td><td>01234.6</td><td>0123.5</td></tr> <tr><td>CH 2</td><td>01234.6</td><td>01234.6</td><td>0123.5</td><td>CH A</td><td>01234.6</td><td>01234.6</td><td>0123.5</td></tr> <tr><td>CH 3</td><td>01234.6</td><td>01234.6</td><td>0123.5</td><td>CH B</td><td>01234.6</td><td>01234.6</td><td>0123.5</td></tr> <tr><td>CH 4</td><td>01234.6</td><td>01234.6</td><td>0123.5</td><td>CH C</td><td>01234.6</td><td>01234.6</td><td>0123.5</td></tr> <tr><td>CH 5</td><td>01234.6</td><td>01234.6</td><td>0123.5</td><td>CH D</td><td>01234.6</td><td>01234.6</td><td>0123.5</td></tr> <tr><td>CH 6</td><td>01234.6</td><td>01234.6</td><td>0123.5</td><td>CH E</td><td>01234.6</td><td>01234.6</td><td>0123.5</td></tr> <tr><td>CH 7</td><td>01234.6</td><td>01234.6</td><td>0123.5</td><td>CH F</td><td>01234.6</td><td>01234.6</td><td>0123.5</td></tr> </table> <p>Digital Output/Temp. Value D=0: 0123.5 C D=4000: 0123.5 C Error</p>	CH 0	01234.6	01234.6	0123.5	CH 8	01234.6	01234.6	0123.5	CH 1	01234.6	01234.6	0123.5	CH 9	01234.6	01234.6	0123.5	CH 2	01234.6	01234.6	0123.5	CH A	01234.6	01234.6	0123.5	CH 3	01234.6	01234.6	0123.5	CH B	01234.6	01234.6	0123.5	CH 4	01234.6	01234.6	0123.5	CH C	01234.6	01234.6	0123.5	CH 5	01234.6	01234.6	0123.5	CH D	01234.6	01234.6	0123.5	CH 6	01234.6	01234.6	0123.5	CH E	01234.6	01234.6	0123.5	CH 7	01234.6	01234.6	0123.5	CH F	01234.6	01234.6	0123.5	1)	---	---				
	CH 0	01234.6	01234.6	0123.5	CH 8	01234.6	01234.6	0123.5																																																															
	CH 1	01234.6	01234.6	0123.5	CH 9	01234.6	01234.6	0123.5																																																															
	CH 2	01234.6	01234.6	0123.5	CH A	01234.6	01234.6	0123.5																																																															
	CH 3	01234.6	01234.6	0123.5	CH B	01234.6	01234.6	0123.5																																																															
	CH 4	01234.6	01234.6	0123.5	CH C	01234.6	01234.6	0123.5																																																															
	CH 5	01234.6	01234.6	0123.5	CH D	01234.6	01234.6	0123.5																																																															
	CH 6	01234.6	01234.6	0123.5	CH E	01234.6	01234.6	0123.5																																																															
	CH 7	01234.6	01234.6	0123.5	CH F	01234.6	01234.6	0123.5																																																															
	2)	16 to 23	0010 to 0017																																																																				
	3)	0	0000																																																																				
4)	384 to 511	0180 to 01FF																																																																					
5)	80 to 87	0050 to 0057																																																																					
6)	96 to 103	0060 to 0067																																																																					
7)	64 to 71	0040 to 0047																																																																					
8)	32 to 39	0020 to 0027																																																																					
9)	512 to 639	0200 to 027F																																																																					
10)	48 to 63	0030 to 003F																																																																					
11)	---	---																																																																					
-	---	---																																																																					
<p>A616TD Input/Output Monitor Screen</p> <table border="1"> <tr><th colspan="2">Inputs (X)</th><th colspan="2">Outputs (Y)</th></tr> <tr><td>00</td><td>WDT Error</td><td>00</td><td>LED Display</td></tr> <tr><td>01</td><td>READY</td><td>01</td><td>11</td></tr> <tr><td>02</td><td>Error</td><td>02</td><td>12</td></tr> <tr><td>03</td><td>Discon. Error</td><td>03</td><td>13</td></tr> <tr><td>04</td><td>Digital Error</td><td>04</td><td>14</td></tr> <tr><td>05</td><td>Temp. Error</td><td>05</td><td>15</td></tr> <tr><td>06</td><td></td><td>06</td><td>16</td></tr> <tr><td>07</td><td></td><td>07</td><td>17</td></tr> <tr><td>08</td><td></td><td>08</td><td>18</td></tr> <tr><td>09</td><td></td><td>09</td><td>19</td></tr> <tr><td>0A</td><td></td><td>0A</td><td>1A</td></tr> <tr><td>0B</td><td></td><td>0B</td><td>1B</td></tr> <tr><td>0C</td><td></td><td>0C</td><td>1C</td></tr> <tr><td>0D</td><td></td><td>0D</td><td>1D</td></tr> <tr><td>0E</td><td></td><td>0E</td><td>1E</td></tr> <tr><td>0F</td><td></td><td>0F</td><td>1F</td></tr> </table>	Inputs (X)		Outputs (Y)		00	WDT Error	00	LED Display	01	READY	01	11	02	Error	02	12	03	Discon. Error	03	13	04	Digital Error	04	14	05	Temp. Error	05	15	06		06	16	07		07	17	08		08	18	09		09	19	0A		0A	1A	0B		0B	1B	0C		0C	1C	0D		0D	1D	0E		0E	1E	0F		0F	1F	1)	---	---
Inputs (X)		Outputs (Y)																																																																					
00	WDT Error	00	LED Display																																																																				
01	READY	01	11																																																																				
02	Error	02	12																																																																				
03	Discon. Error	03	13																																																																				
04	Digital Error	04	14																																																																				
05	Temp. Error	05	15																																																																				
06		06	16																																																																				
07		07	17																																																																				
08		08	18																																																																				
09		09	19																																																																				
0A		0A	1A																																																																				
0B		0B	1B																																																																				
0C		0C	1C																																																																				
0D		0D	1D																																																																				
0E		0E	1E																																																																				
0F		0F	1F																																																																				
-	---	---																																																																					

Screen Image	No.	Buffer memory address	
		dec.	hex.

A616TD Setting Monitor Screen

	CNT No.0	CNT No.1	CNT No.2	CNT No.3	CNT No.4	CNT No.5	CNT No.6	CNT No.7
CH 1	01234	01234	01234	01234	01234	01234	01234	01234
CH 2	01234	01234	01234	01234	01234	01234	01234	01234
CH 3	01234	01234	01234	01234	01234	01234	01234	01234
CH 4	01234	01234	01234	01234	01234	01234	01234	01234
CH 5	01234	01234	01234	01234	01234	01234	01234	01234
CH 6	01234	01234	01234	01234	01234	01234	01234	01234
CH 7	01234	01234	01234	01234	01234	01234	01234	01234
CH 8	01234	01234	01234	01234	01234	01234	01234	01234
CH 9	01234	01234	01234	01234	01234	01234	01234	01234
CH A	01234	01234	01234	01234	01234	01234	01234	01234
CH B	01234	01234	01234	01234	01234	01234	01234	01234
CH C	01234	01234	01234	01234	01234	01234	01234	01234
CH D	01234	01234	01234	01234	01234	01234	01234	01234
CH E	01234	01234	01234	01234	01234	01234	01234	01234
CH F	01234	01234	01234	01234	01234	01234	01234	01234

Col. A Err. Comp. Value Error Code If Error Code 70 CNT No. 0 MX CH 0
 Col. B Sensor Type [01] Wrong Sensor Type

1) 2) 3) 4)

1)	256 to 383	0100 to 017F
2)	128 to 255	0080 to 00FF
3)	1	0001
4)	3	0003
-	---	---

A616TD Temperature Monitor Screen CONNECT No.0

CONNECT No. 0110110110110110 * CH No. FEDCBA9876543210
 Data Format 0110110110110110 Conversion 0110110110110110
 Enable 0: Disabled 1: Enabled

Legend: ■ WDT Error ■ Error ■ Temp. Value Err

1) 2) 3) 4)

1)	---	---
2)	512 to 639	0200 to 027F
3)	0	0000
	16 to 23	0010 to 0017
4)	---	---
-	---	---

A616TD Graph Monitor Screen INPUT 0-F






Channel No. FEDCBA9876543210 Channel No. FEDCBA9876543210
 Data Format 0110110110110110 Conversion 0110110110110110
 Enable 0: Disabled 1: Enabled

Legend: ■ WDT Error ■ Error ■ Digital Val. Err ■ Temp. Val. Err

1) 2) 3)

1)	16 to 23	0070 to 007F
2)	---	---
3)	0	0000
4)	15	000F
-	---	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address	
			dec.	hex.
1) 		1)	---	---
2) 		2)	384 to 511	0180 to 01FF
3) 		3)	512 to 639	0200 to 027F
4) 		4)	---	---
5) 		5)	0	0000
			16 to 23	0010 to 0017
		-	---	---

12.19 AD70,A1SD70 Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
	1)	---	---
<p>AD70 Positioning & Parameter Data Monitor Screen</p> <p>SET/RESET Data Chg. MONIT MENU END</p> <p>Y11 Ab.Posit. Start 2) Feed Position 01234567890 Present Value 01234567890 (13)</p> <p>Y12 Forward Start 3) Actual Position 01234567890 Travel Dist. 01234567890 (14)</p> <p>Y13 Reverse Start 4) Error Counter 01234567890 Velocity 012345 PLS/s (15)</p> <p>Y14 Fwd. Jog Start 5) Pos.Address P1 01234567890 Jog Velocity 012345 PLS/s (16)</p> <p>Y15 Rev. Jog Start 6) Pos.Address P2 01234567890 Upper Limit 01234567890 (17)</p> <p>Y16 Vel/Pos Restart 7) Pos.Velocity V1 012345 PLS/s Lower Limit 01234567890 (18)</p> <p>X03 Zero Rtn Complete 8) Pos.Velocity V2 012345 PLS/s Gear Ratio 0123: 0123 (19)</p> <p>X04 In-position 9) Pos.Pattern 0 Velocity Limit 012345 PLS/s (20)</p> <p>W10 W/P Switchover V/P Mode 0 Accel.Time 0123 ms (21)</p> <p>X00 WDT Error 0: Positioning Decel.Time 0123 ms (22)</p> <p>X07 Excessive Error 10) 1: Velocity In-Position Range 0123 (23)</p> <p>X08 Error Detection Error Code 1: 012 2: 012 Positioning Mode 0 (24)</p> <p>11) 12)</p>	2)	100, 101	0064, 0065
	3)	102, 103	0066, 0067
	4)	106, 107	006A, 006B
	5)	61, 62	003D, 003E
	6)	65, 66	0041, 0042
	7)	63, 64	003F, 0040
	8)	67, 68	0043, 0044
	9)	60	003C
	10)	111	006F
	11)	104	0068
	12)	105	0069
	13)	80, 81	0050, 0051
	14)	88, 89	0058, 0059
	15)	82, 83	0052, 0053
	16)	84, 85	0054, 0055
	17)	0, 1	0000, 0001
	18)	2, 3	0002, 0003
	19)	4, 5	0004, 0005
	20)	20, 21	0014, 0015
	21)	22	0016
	22)	23	0017
	23)	24	0018
	24)	25	0019

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NETWORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address	
			dec.	hex.
		1)	---	---
		2)	100, 101	0064, 0065
		3)	102, 103	0066, 0067
		4)	106, 107	006A, 006B
		5)	61, 62	003D, 003E
		6)	65, 66	0041, 0042
		7)	63, 64	003F, 0040
		8)	67, 68	0043, 0044
		9)	60	003C
		10)	111	006F
		11)	104	0068
		12)	105	0069
		13)	80, 81	0050, 0051
		14)	88, 89	0058, 0059
		15)	82, 83	0052, 0053
		16)	84, 85	0054, 0055
		17)	108, 109	006C, 006D
		18)	46, 47	002E, 002F
		19)	40, 41	0028, 0029
		20)	42, 43	002A, 002B
		21)	44, 45	002C, 002D
		1)	---	---

12.20 AD70D Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
	1)	---	---
	2)	100, 101	0064, 0065
	3)	102, 103	0066, 0067
	4)	104, 105	0068, 0069
	5)	61, 62	003D, 003E
	6)	65, 66	0041, 0042
	7)	63, 64	003F, 0040
	8)	67, 68	0043, 0044
	9)	60	003C
	10)	119	0077
	11)	120	0078
	12)	121	0079
	13)	122	007A
	14)	123	007B
	15)	80, 81	0050, 0051
	16)	86, 87	0056, 0057
	17)	82, 83	0052, 0053
	18)	84, 85	0054, 0055
	19)	89	0059
	20)	110	006E
	21)	111	006F
	22)	112	0070
	23)	113	0071
	24)	125	007D
	25)	126	007E

	SET/RESET	Data Chg.	MONIT MENU	END	
Y11 Posit. Start		Feed Position	01234567890	Present Value	01234567890
Y12 Forward Start		Actual Position	01234567890	Travel Dist.	01234567890
Y13 Reverse Start		Error Counter	01234567890	Velocity	012345 PLS/s
Y14 Fwd. Jog Start		Pos.Address P1	01234567890	Jog Velocity	012345 PLS/s
Y15 Rev. Jog Start		Pos.Address P2	01234567890	Torque Limit	012345 %
Y16 Vel./Pos. Restart		Pos.Velocity V1	012345 PLS/s	Motor Speed	012345 rpm
X05 Posit. Complete		Pos.Velocity V2	012345 PLS/s	Motor Current	012345 %
Y10 Zero Rtn Request		Pos.Pattern	0	Regen. Level	012345 %
X03 Zero Rtn Start		W/P Mode	0 0: Pos 1: Vel	Max. Torque	012345 %
X04 Zero Rtn Complete		Torque Control Mode	0	Test Mode	0110110110110110 87654321
Y17 Stop		Err. Code 1:012 2:0123 S:0123		S/Switch	0110110110110110
X00 BUSY					
Y10 Servo OFF					
X07 WDT Error					
X08 Error Detection					

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image	No.	Buffer memory address	
		dec.	hex.
	1)	---	---
	2)	100, 101	0064, 0065
	3)	102, 103	0066, 0067
	4)	104, 105	0068, 0069
	5)	30, 31	001E, 001F
	6)	32, 33	0020, 0021
	7)	34, 35	0022, 0023
	8)	108, 109	006C, 006D
	9)	106, 107	006A, 006B
	10)	36, 37	0024, 0025
	11)	119	0077
	12)	120	0078
	13)	121	0079
	14)	122	007A
	15)	123	007B
	16)	80, 81	0050, 0051
	17)	86, 87	0056, 0057
	18)	82, 83	0052, 0053
	19)	84, 85	0054, 0055
	20)	89	0059
	21)	110	006E
	22)	111	006F
	23)	112	0070
	24)	113	0071
	25)	125	007D
	26)	126	007E

AD70D Zero Return Data Monitor Screen

			SET/	Data	MONIT	
			RESET	Chg.	MENU	END
Y11 Posit. Start	Feed Position 2)01234567890	Present Value	01234567890			
Y12 Forward Start	Actual Position3)01234567890	Travel Dist.	01234567890			
Y13 Reverse Start	Error Counter 4)01234567890	Velocity	012345 PLS/s			
Y14 Fwd. Jog Start	Zero Address 5)01234567890	Jog Velocity	012345 PLS/s			
Y15 Rev. Jog Start	Zero Rtn Vel. 6)012345 PLS/s	Torque Limit	012345 %			
Y16 Vel/Pos Restart	Creep Velocity7)012345 PLS/s	Motor Speed	012345 rpm			
X05 Posit. Complete	Zero Rtn Dist. 8)01234567890	Motor Current	012345 %			
	Near Zero Dist.9)01234567890	Regen. Level	012345 %			
Y10 Zero Rtn Request	Near Zero Set.10)01234567890	V/P Mode	0 0: Pos 1: Vel			
X03 Zero Rtn Comple.	Torque Control Mode 0	Test Mode	0110110110110110			
Y17 Stop	Err. Code 1:012 2:0123 S:0123	S/Switch	0110110110110110			
X04 BUSY						
Y18 Servo OFF						
Y1C V/P Switchover						
X00 MDT Error						
X08 Error Detection						

11) 12) 13) 14) 15)

12.21 AD71 Module Monitor

Screen Image	No.	Buffer memory address			
		X		Y	
		dec.	hex.	dec.	hex.
	1)	---	---	---	---
	2)	47	002F	347	015B
	3)	48	0030	348	015C
	4)	39	0027	339	0153
	5)	602	025A	604	025C
		603	025B	605	025D
	6)	41	0029	341	0155
		42	002A	342	0156
	7)	7912	1EE8	7922	1EF2
		7913	1EE9	7923	1EF3
	8)	600	0258	601	0259
	9)	7874	1EC2	7894	1ED6
	10)	40	0028	340	0154
	11)	44	002C	344	0158
	12)	7875	1EC3	7895	1ED7
13)	46	002E	346	015A	
14)	45	002D	345	0159	
15)	0 to 37	0000 to 0025	300 to 337	012C to 0151	
	1)	---	---	---	---
	2)	47	002F	347	015B
	3)	48	0030	348	015C
	4)	39	0027	339	0153
	5)	602	025A	604	025C
		603	025B	605	025D
	6)	41	0029	341	0155
		42	002A	342	0156
	7)	7912	1EE8	7922	1EF2
		7913	1EE9	7923	1EF3
	8)	600	0258	601	0259
	9)	7874	1EC2	7894	1ED6
	10)	40	0028	340	0154
	11)	7914	1EEA	7924	1EF4
	12)	7915	1EEB	7925	1EF5
	13)	46	002E	346	015A
	14)	45	002D	345	0159
15)	7918	1EEE	7928	1EF8	
16)	7917	1EED	7927	1EF7	
17)	7916	1EEC	7926	1EF6	


Screen Image				No.	Buffer memory address			
					X		Y	
					dec.	hex.	dec.	hex.
				1)	---	---	---	---
				2)	47	002F	347	015B
				3)	7873	1EC1	7893	1ED5
				4)	7884	1ECC	7904	1EE0
				5)	7885	1ECD	7905	1EE1
				6)	7874	1EC2	7894	1ED6
				7)	7875	1EC3	7895	1ED7
				8)	7876	1EC4	7896	1ED8
				9)	7877	1EC5	7897	1ED9
				10)	7878	1EC6	7898	1EDA
				11)	7879	1EC7	7899	1EDB
				12)	7880	1EC8	7900	1EDC
				13)	7881	1EC9	7901	1EDD
				14)	7882	1ECA	7902	1EDE
				15)	7883	1ECB	7903	1EDF
				16)	7886	1ECE	7906	1EE2


Screen Image				No.	Buffer memory address			
					X		Y	
					dec.	hex.	dec.	hex.
				1)	---	---	---	---
				2)	47	002F	347	015B
				3)	46	002E	346	015A
				4)	49	0031	349	015D
				5)	48	0030	348	015C
				6)	39	0027	339	0153
				7)	45	002D	345	0159
				8)	43	002B	343	0157
				-	---	---	---	---

1)	---	---	---	---
2)	47	002F	347	015B
3)	7873	1EC1	7893	1ED5
4)	7884	1ECC	7904	1EE0
5)	7885	1ECD	7905	1EE1
6)	7874	1EC2	7894	1ED6
7)	7875	1EC3	7895	1ED7
8)	7876	1EC4	7896	1ED8
9)	7877	1EC5	7897	1ED9
10)	7878	1EC6	7898	1EDA
11)	7879	1EC7	7899	1EDB
12)	7880	1EC8	7900	1EDC
13)	7881	1EC9	7901	1EDD
14)	7882	1ECA	7902	1EDE
15)	7883	1ECB	7903	1EDF
16)	7886	1ECE	7906	1EE2
1)	---	---	---	---
2)	47	002F	347	015B
3)	46	002E	346	015A
4)	49	0031	349	015D
5)	48	0030	348	015C
6)	39	0027	339	0153
7)	45	002D	345	0159
8)	43	002B	343	0157
-	---	---	---	---

OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 ERROR MESSAGES FOR SYSTEM MONITOR
 OPERATING SP MODULE MONITOR
 OPERATING SP MODULE MONITOR SCREEN
 OPERATING I/O MODULE MONITOR SCREENS
 ERROR MESSAGES FOR SP MODULE MONITOR
 OPERATING NET-WORK MONITOR
 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image	No.	Buffer memory address			
		X		Y	
		dec.	hex.	dec.	hex.

 <p>AD71 Input/Output Monitor Screen</p> <p>1) →</p>	1)	---	---	---	---
	-	---	---	---	---

 <p>AD71 Positioning Data Monitor Screen</p> <p>1) →</p>	1)	5072 to 5111	13D0 to 13F7	7072 to 7111	1BA0 to 1BC7
	2)	4272 to 4291	10B0 to 10C3	6272 to 6291	1880 to 1893
	3)	4672 to 4691	1240 to 1253	6672 to 6691	1A10 to 1A23
	4)	3872 to 3891	0F20 to 0F33	5872 to 5891	16F0 to 1703
	5)	3872 to 3891	0F20 to 0F33	5872 to 5891	16F0 to 1703
	-	---	---	---	---

12.22 AD72,A1SD71 Module Monitor

Screen Image	No.	Buffer memory address			
		X		Y	
		dec.	hex.	dec.	hex.
	1)	---	---	---	---
	2)	47	002F	347	015B
	3)	48	0030	348	015C
	4)	39	0027	339	0153
	5)	602	025A	604	025C
		603	025B	605	025D
	6)	41	0029	341	0155
		42	002A	342	0156
	7)	7912	1EE8	7922	1EF2
		7913	1EE9	7923	1EF3
	8)	600	0258	601	0259
	9)	7874	1EC2	7894	1ED6
	10)	40	0028	340	0154
	11)	44	002C	344	0158
	12)	7875	1EC3	7895	1ED7
	13)	46	002E	346	015A
	14)	45	002D	345	0159
15)	0	0000	300	012C	
	to	to	to	to	
	37	0025	337	0151	
	1)	---	---	---	---
	2)	47	002F	347	015B
	3)	48	0030	348	015C
	4)	39	0027	339	0153
	5)	602	025A	604	025C
		603	025B	605	025D
	6)	41	0029	341	0155
		42	002A	342	0156
	7)	7912	1EE8	7922	1EF2
		7913	1EE9	7923	1EF3
	8)	600	0258	601	0259
	9)	7874	1EC2	7894	1ED6
	10)	40	0028	340	0154
	11)	7914	1EEA	7924	1EF4
	12)	7915	1EEB	7925	1EF5
	13)	46	002E	346	015A
	14)	45	002D	345	0159
15)	7918	1EEE	7928	1EF8	
16)	7917	1EED	7927	1EF7	
17)	7916	1EEC	7926	1EF6	

OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 ERROR MESSAGES FOR SYSTEM MONITOR
 OPERATING SP MODULE MONITOR
 OPERATING I/O MODULE MONITOR SCREENS
 ERROR MESSAGES FOR SP MODULE MONITOR
 OPERATING NET-WORK MONITOR SCREENS
 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image					No.	Buffer memory address			
						X		Y	
						dec.	hex.	dec.	hex.
					1)	---	---	---	---
					2)	47	002F	347	015B
					3)	7873	1EC1	7893	1ED5
					4)	7884	1ECC	7904	1EE0
					5)	7885	1ECD	7905	1EE1
					6)	7874	1EC2	7894	1ED6
					7)	7875	1EC3	7895	1ED7
					8)	7876	1EC4	7896	1ED8
					9)	7877	1EC5	7897	1ED9
					10)	7878	1EC6	7898	1EDA
					11)	7879	1EC7	7899	1EDB
					12)	7880	1EC8	7900	1EDC
					13)	7881	1EC9	7901	1EDD
					14)	7882	1ECA	7902	1EDE
					15)	7883	1ECB	7903	1EDF
					16)	7886	1ECE	7906	1EE2
					1)	---	---	---	---
					2)	47	002F	347	015B
					3)	46	002E	346	015A
					4)	49	0031	349	015D
					5)	48	0030	348	015C
					6)	200	00C8	500	01F4
					7)	39	0027	339	0153
					8)	45	002D	345	0159
-	43	002B	343	0157					
-	---	---	---	---					

Screen Image	No.	Buffer memory address			
		X		Y	
		dec.	hex.	dec.	hex.

AD72/A1SD71 Input/Output Monitor Screen

Inputs (X)				Outputs (Y)			
00	10	HDT Error	20	X In-position	00	10	X Posit. Start
01	11	READY	21	Y In-position	01	11	Y Posit. Start
02	12	X Pos. Complete	22	X Excessive Err	02	12	Interpolation
03	13	Y Pos. Complete	23	Y Excessive Err	03	13	X Zero Start
04	14	X Axis BUSY	24		04	14	Y Zero Start
05	15	Y Axis BUSY	25		05	15	X Stop
06	16	X Zero Request	26		06	16	Y Stop
07	17	Y Zero Request	27		07	17	X Fwd.Jog Start
08	18	X Posit.Started	28		08	18	X Rev.Jog Start
09	19	Y Posit.Started	29		09	19	Y Fwd.Jog Start
0A	1A	Battery Error	2A		0A	1A	Y Rev.Jog Start
0B	1B	Error Detection	2B		0B	1B	X M Code OFF
0C	1C	X Zero Complete	2C		0C	1C	Y M Code OFF
0D	1D	Y Zero Complete	2D		0D	1D	PLC READY
0E	1E	X M Code ON	2E		0E	1E	2E
0F	1F	Y M Code ON	2F		0F	1F	2F

1)

AD72/A1SD71 Positioning Data Monitor Screen No.01

X	Address	Speed	Dwell	M Code *	Y	Address	Speed	Dwell	M Code *
001	01234567	01234	012	012 0	001	01234567	01234	012	012 0
002	01234567	01234	012	012 0	002	01234567	01234	012	012 0
003	01234567	01234	012	012 0	003	01234567	01234	012	012 0
004	01234567	01234	012	012 0	004	01234567	01234	012	012 0
005	01234567	01234	012	012 0	005	01234567	01234	012	012 0
006	01234567	01234	012	012 0	006	01234567	01234	012	012 0
007	01234567	01234	012	012 0	007	01234567	01234	012	012 0
008	01234567	01234	012	012 0	008	01234567	01234	012	012 0
009	01234567	01234	012	012 0	009	01234567	01234	012	012 0
010	01234567	01234	012	012 0	010	01234567	01234	012	012 0
011	01234567	01234	012	012 0	011	01234567	01234	012	012 0
012	01234567	01234	012	012 0	012	01234567	01234	012	012 0
013	01234567	01234	012	012 0	013	01234567	01234	012	012 0
014	01234567	01234	012	012 0	014	01234567	01234	012	012 0
015	01234567	01234	012	012 0	015	01234567	01234	012	012 0
016	01234567	01234	012	012 0	016	01234567	01234	012	012 0
017	01234567	01234	012	012 0	017	01234567	01234	012	012 0
018	01234567	01234	012	012 0	018	01234567	01234	012	012 0
019	01234567	01234	012	012 0	019	01234567	01234	012	012 0
020	01234567	01234	012	012 0	020	01234567	01234	012	012 0

1) 2) 3) 4) 5)

1)	---	---	---	---
1)	5072 to 5111	13D0 to 13F7	7072 to 7111	1BA0 to 1BC7
2)	4272 to 4291	10B0 to 10C3	6272 to 6291	1880 to 1893
3)	4672 to 4691	1240 to 1253	6672 to 6691	1A10 to 1A23
4)	3872 to 3891	0F20 to 0F33	5872 to 5891	16F0 to 1703
5)	3872 to 3891	0F20 to 0F33	5872 to 5891	16F0 to 1703
-	---	---	---	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
10 ERROR MESSAGES FOR SYSTEM MONITOR
11 OPERATING SP MODULE MONITOR
12 OPERATING SP MODULE MONITOR SCREEN
13 OPERATING I/O MODULE MONITOR SCREENS
14 ERROR MESSAGES FOR SP MODULE MONITOR
15 OPERATING NET-WORK MONITOR
16 SWITCHING THE NETWORK MONITOR SCREENS

12.23 AD75, A1SD75 Module Monitor

Screen Image	No.	Buffer memory address					
		1		2		3	
		dec.	hex.	dec.	hex.	dec.	hex.
	1)	---	---	---	---	---	---
	1)	800	0320	900	0384	1000	03E8
		801	0321	901	0385	1001	03E9
	2)	812	032C	912	0390	1012	03F4
		813	032D	913	0391	1013	03F5
	3)	809	0329	909	038D	1009	03F1
	4)	807	0327	907	038B	1007	03EF
	5)	808	0328	908	038C	1008	03F0
	6)	806	0326	906	038A	1006	03EE
	7)	835	0343	935	03A7	1035	040B
	8)						
	9)	838	0346	938	03AA	1038	040E
	10)						
	11)						
	-	---	---	---	---	---	---
	1)	0	0000	150	0096	300	012C
	2)	1	0001	151	0097	301	012D
	3)	2	0002	152	0098	302	012E
	4)	3	0003	153	0099	303	012F
	5)	4	0004	154	009A	304	0130
	6)	5	0005	155	009B	305	0131
	-	---	---	---	---	---	---

Screen Image						Buffer memory address																																				
						1		2		3																																
						dec.	hex.	dec.	hex.	dec.	hex.																															
<p>AD75P Basic Parameter 2</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Valid Range</th> <th>1Axis</th> <th>2Axis</th> <th>3Axis</th> </tr> </thead> <tbody> <tr> <td>Speed Limit</td> <td>1 to 600000000 [x10⁻² mm/min] 1 to 600000000 [x10⁻³ inch/min] 1 to 600000000 [x10⁻³ deg/min] 1 to 1000000 [PLS/sec]</td> <td>012345678</td> <td>012345678</td> <td>012345678</td> </tr> <tr> <td>Accel.Time #0</td> <td>1 to 65535 /8388608 [msec]</td> <td>0123456</td> <td>0123456</td> <td>0123456</td> </tr> <tr> <td>Decel.Time #0</td> <td>1 to 65535 /8388608 [msec]</td> <td>0123456</td> <td>0123456</td> <td>0123456</td> </tr> </tbody> </table>	Parameter	Valid Range	1Axis	2Axis	3Axis	Speed Limit	1 to 600000000 [x10 ⁻² mm/min] 1 to 600000000 [x10 ⁻³ inch/min] 1 to 600000000 [x10 ⁻³ deg/min] 1 to 1000000 [PLS/sec]	012345678	012345678	012345678	Accel.Time #0	1 to 65535 /8388608 [msec]	0123456	0123456	0123456	Decel.Time #0	1 to 65535 /8388608 [msec]	0123456	0123456	0123456	1)	6	0006	156	009C	306	0132															
	Parameter	Valid Range	1Axis	2Axis	3Axis																																					
	Speed Limit	1 to 600000000 [x10 ⁻² mm/min] 1 to 600000000 [x10 ⁻³ inch/min] 1 to 600000000 [x10 ⁻³ deg/min] 1 to 1000000 [PLS/sec]	012345678	012345678	012345678																																					
	Accel.Time #0	1 to 65535 /8388608 [msec]	0123456	0123456	0123456																																					
	Decel.Time #0	1 to 65535 /8388608 [msec]	0123456	0123456	0123456																																					
		7	0007	157	009D	307	0133																																			
	2)	8	0008	158	009E	308	0134																																			
		9	0009	159	009F	309	0135																																			
	3)	10	000A	160	00A0	310	0136																																			
		11	000B	161	00A1	311	0137																																			
		-	---	---	---	---	---																																			
<p>AD75P Basic Parameter 2</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Valid Range</th> <th>1Axis</th> <th>2Axis</th> <th>3Axis</th> </tr> </thead> <tbody> <tr> <td>Speed Limit</td> <td>1 to 600000000 [x10⁻⁵ mm/min] 1 to 600000000 [x10⁻³ inch/min] 1 to 600000000 [x10⁻³ deg/min] 0 to 1000000 [PLS/sec]</td> <td>012345678</td> <td>012345678</td> <td>012345678</td> </tr> <tr> <td>Accel.Time #0</td> <td>1 to 65535 [msec]</td> <td>01234</td> <td>01234</td> <td>01234</td> </tr> <tr> <td>Decel.Time #0</td> <td>1 to 65535 [msec]</td> <td>01234</td> <td>01234</td> <td>01234</td> </tr> </tbody> </table>	Parameter	Valid Range	1Axis	2Axis	3Axis	Speed Limit	1 to 600000000 [x10 ⁻⁵ mm/min] 1 to 600000000 [x10 ⁻³ inch/min] 1 to 600000000 [x10 ⁻³ deg/min] 0 to 1000000 [PLS/sec]	012345678	012345678	012345678	Accel.Time #0	1 to 65535 [msec]	01234	01234	01234	Decel.Time #0	1 to 65535 [msec]	01234	01234	01234	1)	15	000F	165	00A5	315	013B															
	Parameter	Valid Range	1Axis	2Axis	3Axis																																					
	Speed Limit	1 to 600000000 [x10 ⁻⁵ mm/min] 1 to 600000000 [x10 ⁻³ inch/min] 1 to 600000000 [x10 ⁻³ deg/min] 0 to 1000000 [PLS/sec]	012345678	012345678	012345678																																					
	Accel.Time #0	1 to 65535 [msec]	01234	01234	01234																																					
	Decel.Time #0	1 to 65535 [msec]	01234	01234	01234																																					
		16	0010	166	00A6	316	013C																																			
	2)	17	0011	167	00A7	317	013D																																			
		18	0012	168	00A8	318	013E																																			
	3)	19	0013	169	00A9	319	013F																																			
		20	0014	170	00AA	320	0140																																			
	4)	21	0015	171	00AB	321	0141																																			
	24	0018	174	00AE	324	0144																																				
	-	---	---	---	---	---																																				
<p>AD75P Extended Parameter 2</p> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Valid Range</th> <th>Axis1</th> <th>Axis2</th> <th>Axis3</th> </tr> </thead> <tbody> <tr> <td>Accel.Time#1</td> <td>1 to 65535 /8388608 [msec]</td> <td>0123456</td> <td>0123456</td> <td>0123456</td> </tr> <tr> <td>Accel.Time#2</td> <td>1 to 65535 /8388608 [msec]</td> <td>0123456</td> <td>0123456</td> <td>0123456</td> </tr> <tr> <td>Accel.Time#3</td> <td>1 to 65535 /8388608 [msec]</td> <td>0123456</td> <td>0123456</td> <td>0123456</td> </tr> <tr> <td>Decel.Time#1</td> <td>1 to 65535 /8388608 [msec]</td> <td>0123456</td> <td>0123456</td> <td>0123456</td> </tr> <tr> <td>Decel.Time#2</td> <td>1 to 65535 /8388608 [msec]</td> <td>0123456</td> <td>0123456</td> <td>0123456</td> </tr> <tr> <td>Decel.Time#3</td> <td>1 to 65535 /8388608 [msec]</td> <td>0123456</td> <td>0123456</td> <td>0123456</td> </tr> </tbody> </table>	Parameter	Valid Range	Axis1	Axis2	Axis3	Accel.Time#1	1 to 65535 /8388608 [msec]	0123456	0123456	0123456	Accel.Time#2	1 to 65535 /8388608 [msec]	0123456	0123456	0123456	Accel.Time#3	1 to 65535 /8388608 [msec]	0123456	0123456	0123456	Decel.Time#1	1 to 65535 /8388608 [msec]	0123456	0123456	0123456	Decel.Time#2	1 to 65535 /8388608 [msec]	0123456	0123456	0123456	Decel.Time#3	1 to 65535 /8388608 [msec]	0123456	0123456	0123456	1)	36 to 41	0024 to 0029	186 to 191	00BA to 00BF	336 to 341	0150 to 0155
	Parameter	Valid Range	Axis1	Axis2	Axis3																																					
	Accel.Time#1	1 to 65535 /8388608 [msec]	0123456	0123456	0123456																																					
	Accel.Time#2	1 to 65535 /8388608 [msec]	0123456	0123456	0123456																																					
	Accel.Time#3	1 to 65535 /8388608 [msec]	0123456	0123456	0123456																																					
	Decel.Time#1	1 to 65535 /8388608 [msec]	0123456	0123456	0123456																																					
	Decel.Time#2	1 to 65535 /8388608 [msec]	0123456	0123456	0123456																																					
	Decel.Time#3	1 to 65535 /8388608 [msec]	0123456	0123456	0123456																																					
		2)	42 to 47	002A to 002F	192 to 197	00C0 to 00C5	342 to 347	0156 to 015B																																		
		-	---	---	---	---	---	---																																		

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image	No.	Buffer memory address					
		1		2		3	
		dec.	hex.	dec.	hex.	dec.	hex.

AD75P OPR Basic Parameter

Parameter	Valid Range	1Axis	2Axis	3Axis
Method	0:DOG 4:Count#1 1:Stopper#1 5:Count#2 2:Stopper#2 3:Stopper#3	0	0	0
Direction	0:Forward 1:Reverse -2147483648 to 2147483647	0	0	0
Address	[x10 ⁻¹ μm] [x10 ⁻⁵ inch] [PLS] 0 to 35999999	01234567890	01234567890	01234567890
Return Speed	1 to 10000000 [x10 ⁻² mm/min] to 6000000000 [x10 ⁻³ inch/min] [x10 ⁻³ deg/min] [PLS/sec]	012345678	012345678	012345678
Creep Speed	1 to 10000000 [x10 ⁻² mm/min] to 6000000000 [x10 ⁻³ inch/min] [x10 ⁻³ deg/min] [PLS/sec]	012345678	012345678	012345678
Return Retry	0:No Retry 1:retry	0	0	0

1)	70	0046	220	00D C	370	0172
2)	71	0047	221	00D D	371	0173
3)	72	0048	222	00D E	372	0174
	73	0049	223	00DF	373	0175
4)	74	004A	224	00E0	374	0176
	75	004B	225	00E1	375	0177
5)	76	004C	226	00E2	376	0178
	77	004D	227	00E3	377	0179
6)	78	004E	228	00E4	378	017A
-	---	---	---	---	---	---

AD75P OPR Extended Parameter

Parameter	Valid Range	1Axis	2Axis	3Axis
OPR Dwell Time	0 to 65535 [msec]	01234	01234	01234
OPR Torque Limit	1 to 300 [%]	012	012	012
Travel Distance After DOG	0 to 2147483647 [x10 ⁻¹ μm] [x10 ⁻⁵ inch] [PLS]	0123456789	0123456789	0123456789
OPR Accel. Time	0 to 3	0	0	0
OPR Decel. Time	0 to 3	0	0	0
OP Distance From Zero	-2147483648 to 2147483647 [x10 ⁻¹ μm] [x10 ⁻⁵ inch] [PLS] 0 to 35999999 [x10 ⁻⁵ deg]	01234567890	01234567890	01234567890

1)	79	004F	229	00E5	379	017B
2)	86	0056	236	00E C	386	0182
3)	80	0050	230	00E6	380	017C
	81	0051	231	00E7	381	017D
4)	82	0052	232	00E8	382	017E
5)	83	0053	233	00E9	383	017F
6)	84	0054	234	00EA	384	0180
	85	0055	235	00EB	385	0181
-	---	---	---	---	---	---

AD75P Error History . Warning History

[Error History]				[Warning History]			
No.	Ax.	Code	Time	No.	Ax.	Code	Time
1	○	012	00:00:00.00	1	○	012	00:00:00.00
2	○	012	00:00:00.00	2	○	012	00:00:00.00
3	○	012	00:00:00.00	3	○	012	00:00:00.00
4	○	012	00:00:00.00	4	○	012	00:00:00.00
5	○	012	00:00:00.00	5	○	012	00:00:00.00
6	○	012	00:00:00.00	6	○	012	00:00:00.00
7	○	012	00:00:00.00	7	○	012	00:00:00.00
8	○	012	00:00:00.00	8	○	012	00:00:00.00
9	○	012	00:00:00.00	9	○	012	00:00:00.00
10	○	012	00:00:00.00	10	○	012	00:00:00.00
11	○	012	00:00:00.00	11	○	012	00:00:00.00
12	○	012	00:00:00.00	12	○	012	00:00:00.00
13	○	012	00:00:00.00	13	○	012	00:00:00.00
14	○	012	00:00:00.00	14	○	012	00:00:00.00
15	○	012	00:00:00.00	15	○	012	00:00:00.00
16	○	012	00:00:00.00	16	○	012	00:00:00.00

1)	624 to 687	0270 to 02AF	624 to 687	0270 to 02AF	624 to 687	0270 to 02AF
2)	689 to 752	02B1 to 02F0	689 to 752	02B1 to 02F0	689 to 752	02B1 to 02F0
-	---	---	---	---	---	---

Screen Image	No.	Buffer memory address					
		1		2		3	
		dec.	hex.	dec.	hex.	dec.	hex.

AD75P Start Error. Start History

[Start Error History] [Start History]

No.Ax.	Start	Mode	Time	Res.	No.Ax.	Start	Mode	Time	Res.
1	01	Op0123	00:00:00.00	012	1	01	Op0123	00:00:00.00	012
2	01	Op0123	00:00:00.00	012	2	01	Op0123	00:00:00.00	012
3	01	Op0123	00:00:00.00	012	3	01	Op0123	00:00:00.00	012
4	01	Op0123	00:00:00.00	012	4	01	Op0123	00:00:00.00	012
5	01	Op0123	00:00:00.00	012	5	01	Op0123	00:00:00.00	012
6	01	Op0123	00:00:00.00	012	6	01	Op0123	00:00:00.00	012
7	01	Op0123	00:00:00.00	012	7	01	Op0123	00:00:00.00	012
8	01	Op0123	00:00:00.00	012	8	01	Op0123	00:00:00.00	012
9	01	Op0123	00:00:00.00	012	9	01	Op0123	00:00:00.00	012
10	01	Op0123	00:00:00.00	012	10	01	Op0123	00:00:00.00	012
11	01	Op0123	00:00:00.00	012	11	01	Op0123	00:00:00.00	012
12	01	Op0123	00:00:00.00	012	12	01	Op0123	00:00:00.00	012
13	01	Op0123	00:00:00.00	012	13	01	Op0123	00:00:00.00	012
14	01	Op0123	00:00:00.00	012	14	01	Op0123	00:00:00.00	012
15	01	Op0123	00:00:00.00	012	15	01	Op0123	00:00:00.00	012
16	01	Op0123	00:00:00.00	012	16	01	Op0123	00:00:00.00	012

1) 2)

1)	543 to 622	021F to 026E	543 to 622	021F to 026E	543 to 622	021F to 026E
2)	462 to 541	01C E to 021D	462 to 541	01C E to 021D	462 to 541	01CE to 021D
-	---	---	---	---	---	---

AD75P Speed Position Control

[SET/RESET] [Data chg.] [MONIT MENU] [END]

		Axis1	Axis2	Axis3
1)	Travel After Switch [x10 ⁻¹ μm] [x10 ⁻⁵ inch] [x10 ⁻⁵ deg] [PLS]	01234567890	01234567890	01234567890
2)	Travel Correction Register [x10 ⁻¹ μm] [x10 ⁻⁵ inch] [x10 ⁻⁵ deg] [PLS]	01234567890	01234567890	01234567890
3)	V/P Switch Latch	●	○	●
4)	Switch Enabled 0:Disable 1:Enable	0	0	0
5)	V-Control	○	●	●

1)	814 815	032E 032F	914 915	0392 0393	1014 1015	03F6 03F7
2)	1164 1165	048C 048D	1214 1215	04BE 04BF	1264 1265	04F0 04F1
3)	817	0331	917	0395	1017	03F9
4)	1163	048B	1213	04BD	1263	04EF
5)	817	0331	917	0395	1017	03F9
-	---	---	---	---	---	---

AD75P SP Start JOG MPG Drive

[Spacial Star]

#	Operation	Information	Parameter	Data No.
1)	#1	01	012	012
	#2	01	012	012
	#3	01	012	012

[JOG & MPG]

	Axis1	Axis2	Axis3	
1)	JOG Speed [x10 ⁻² mm/min] [x10 ⁻³ inch/min] [x10 ⁻³ deg/min] [PLS/sec]	012345678	012345678	012345678
2)	MPG Magnify	012	012	012
3)	MPG Enabled 0:Disable 1:Enable	0	0	0

1)	832 827 828 829	0340 033B 033C 033D	932 927 928 929	03A4 039F 03A0 03A1	1032 1027 1028 1029	0408 0403 0404 0405
2)	1160 1161	0488 0489	1210 1211	04BA 04BB	1260 1261	04EC 04ED
3)	1168 1169	0490 0491	1218 1219	04C2 04C3	1268 1269	04F4 04F5
4)	1167	048F	1217	04C1	1267	04F3
-	---	---	---	---	---	---

OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS

ERROR MESSAGES FOR SYSTEM MONITOR

OPERATING SP MODULE MONITOR

OPERATING SP MODULE MONITOR SCREEN

OPERATING I/O MODULE MONITOR SCREENS

ERROR MESSAGES FOR SP MODULE MONITOR

OPERATING NET-WORK MONITOR

SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address					
			1		2		3	
			dec.	hex.	dec.	hex.	dec.	hex.
	1)	822	0336	922	039A	1022	03FE	
		823	0337	923	039B	1023	03FF	
	2)	824	0338	924	039C	1024	0400	
		825	0339	925	039D	1025	0401	
	3)	826	033A	926	039E	1026	0402	
	4)							
	5) 6) 7)	816	0330	916	0394	1016	03F8	
	-	---	---	---	---	---	---	
	1)	1154	0482	1204	04B4	1254	04E6	
		1155	0483	1205	04B5	1255	04E7	
	2)	1156	0484	1206	04B6	1256	04E8	
		1157	0485	1207	04B7	1257	04E9	
	3)	1159	0487	1209	04B9	1259	04EB	
	4)	1172	0494	1222	04C6	1272	04F8	
	5) 6) 7)	1173	0495	1223	04C7	1273	04F9	
	-	---	---	---	---	---	---	
	1)	820	0334	920	0398	1020	03FC	
		821	0335	921	0399	1021	03FD	
	2)	810	032A	910	038E	1010	03F2	
		811	032B	911	038F	1011	03F3	
	3)	812	032C	912	0390	1012	03F4	
		813	032D	913	0391	1013	03F5	
		-	---	---	---	---	---	---

Screen Image	No.	Buffer memory address						
		1		2		3		
		dec.	hex.	dec.	hex.	dec.	hex.	
	1)	818	0332	918	0396	1018	03FA	
		819	0333	919	0397	1019	03FB	
	2)	802	0322	902	0386	1002	03EA	
		803	0323	903	0387	1003	03EB	
-	-	---	---	---	---	---	---	
	1)	816	0330	916	0394	1016	03F8	
	1)	817	0331	917	0395	1017	03F9	
		2)	-	---	---	---	---	---
	-	-	---	---	---	---	---	---
		1)	1300	0514	2300	08FC to 0CE3	3300 to 4299	0CE4 to 10CB
	2)	to	to	to	---	---	---	
		2299	08FB	3299	---	---	---	
		3)	-	---	---	---	---	---
	-	-	---	---	---	---	---	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.24 AJ71PT32-S3, A1SJ71PT32-S3 Module Monitor

Screen Image	No.	Buffer memory address																																																																					
		dec.	hex.																																																																				
<p>AJ71PT32-S3 I/O Monitor Scr. (I/O Dedicated Mode)</p> <table border="1"> <thead> <tr> <th>Inputs (X)</th> <th>Outputs (Y)</th> </tr> </thead> <tbody> <tr><td>00 Hardware Fault</td><td>10</td></tr> <tr><td>01 Link Working</td><td>11</td></tr> <tr><td>02</td><td>12</td></tr> <tr><td>03</td><td>13</td></tr> <tr><td>04</td><td>14</td></tr> <tr><td>05 Test Mode</td><td>15</td></tr> <tr><td>06 Link Error Detect</td><td>16</td></tr> <tr><td>07 Link Comms. Error</td><td>17</td></tr> <tr><td>08</td><td>18 Link Comms.Start</td></tr> <tr><td>09</td><td>19</td></tr> <tr><td>0A</td><td>1A FROM/TO Response</td></tr> <tr><td>0B</td><td>1B Faulty Sta.Clear</td></tr> <tr><td>0C</td><td>1C</td></tr> <tr><td>0D</td><td>1D Error Reset</td></tr> <tr><td>0E</td><td>1E</td></tr> <tr><td>0F</td><td>1F</td></tr> </tbody> </table>	Inputs (X)	Outputs (Y)	00 Hardware Fault	10	01 Link Working	11	02	12	03	13	04	14	05 Test Mode	15	06 Link Error Detect	16	07 Link Comms. Error	17	08	18 Link Comms.Start	09	19	0A	1A FROM/TO Response	0B	1B Faulty Sta.Clear	0C	1C	0D	1D Error Reset	0E	1E	0F	1F	1)	---	---																																		
Inputs (X)	Outputs (Y)																																																																						
00 Hardware Fault	10																																																																						
01 Link Working	11																																																																						
02	12																																																																						
03	13																																																																						
04	14																																																																						
05 Test Mode	15																																																																						
06 Link Error Detect	16																																																																						
07 Link Comms. Error	17																																																																						
08	18 Link Comms.Start																																																																						
09	19																																																																						
0A	1A FROM/TO Response																																																																						
0B	1B Faulty Sta.Clear																																																																						
0C	1C																																																																						
0D	1D Error Reset																																																																						
0E	1E																																																																						
0F	1F																																																																						
<p>AJ71PT32-S3 Link Data Monitor Screen</p> <table border="1"> <thead> <tr> <th>No. of Remote Stations</th> <th>01</th> <th>Communication Error Code</th> <th>01</th> </tr> </thead> <tbody> <tr> <td colspan="2">Remote I/O Units Card Data</td> <td colspan="2">Accumulative Faulty Station Detection</td> </tr> <tr> <td colspan="2">ST: 8 7 6 5 4 3 2 1</td> <td colspan="2">0: Normal 1: Error</td> </tr> <tr> <td>8 - 10110110110110110110</td> <td>FEDCBA9876543210</td> <td>16- 10110110110110110110</td> <td></td> </tr> <tr> <td>16 - 90110110110110110110</td> <td></td> <td>32-17011011011011011010</td> <td></td> </tr> <tr> <td>24 -17011011011011011010</td> <td></td> <td>48-33011011011011011010</td> <td></td> </tr> <tr> <td>32 -25011011011011011010</td> <td></td> <td>64-49011011011011011010</td> <td></td> </tr> <tr> <td>40 -33011011011011011010</td> <td></td> <td colspan="2">Faulty Station Detection</td> </tr> <tr> <td>48 -41011011011011011010</td> <td></td> <td colspan="2">FEDCBA9876543210</td> </tr> <tr> <td>56 -49011011011011011010</td> <td></td> <td>16- 10110110110110110110</td> <td></td> </tr> <tr> <td>64 -57011011011011011010</td> <td></td> <td>32-17011011011011011010</td> <td></td> </tr> <tr> <td colspan="2">Card Data: 00 No remote unit or no initial communication</td> <td colspan="2">Accumulative Input Error Detection for Partial Refresh</td> </tr> <tr> <td colspan="2">01 Input, partial refresh or remote terminal</td> <td colspan="2">FEDCBA9876543210</td> </tr> <tr> <td colspan="2">10 Output remote unit</td> <td colspan="2">0110110110110110110</td> </tr> <tr> <td colspan="2">Remote Terminal Unit Faulty Station No. FEDCBA9876543210</td> <td colspan="2">Input Faulty Error Detection for Partial Refresh</td> </tr> <tr> <td colspan="2">0110110110110110110</td> <td colspan="2">FEDCBA9876543210</td> </tr> <tr> <td colspan="2"></td> <td colspan="2">0110110110110110110</td> </tr> </tbody> </table>	No. of Remote Stations	01	Communication Error Code	01	Remote I/O Units Card Data		Accumulative Faulty Station Detection		ST: 8 7 6 5 4 3 2 1		0: Normal 1: Error		8 - 10110110110110110110	FEDCBA9876543210	16- 10110110110110110110		16 - 90110110110110110110		32-17011011011011011010		24 -17011011011011011010		48-33011011011011011010		32 -25011011011011011010		64-49011011011011011010		40 -33011011011011011010		Faulty Station Detection		48 -41011011011011011010		FEDCBA9876543210		56 -49011011011011011010		16- 10110110110110110110		64 -57011011011011011010		32-17011011011011011010		Card Data: 00 No remote unit or no initial communication		Accumulative Input Error Detection for Partial Refresh		01 Input, partial refresh or remote terminal		FEDCBA9876543210		10 Output remote unit		0110110110110110110		Remote Terminal Unit Faulty Station No. FEDCBA9876543210		Input Faulty Error Detection for Partial Refresh		0110110110110110110		FEDCBA9876543210				0110110110110110110		1)	0	0000
	No. of Remote Stations	01	Communication Error Code	01																																																																			
	Remote I/O Units Card Data		Accumulative Faulty Station Detection																																																																				
	ST: 8 7 6 5 4 3 2 1		0: Normal 1: Error																																																																				
	8 - 10110110110110110110	FEDCBA9876543210	16- 10110110110110110110																																																																				
	16 - 90110110110110110110		32-17011011011011011010																																																																				
	24 -17011011011011011010		48-33011011011011011010																																																																				
	32 -25011011011011011010		64-49011011011011011010																																																																				
40 -33011011011011011010		Faulty Station Detection																																																																					
48 -41011011011011011010		FEDCBA9876543210																																																																					
56 -49011011011011011010		16- 10110110110110110110																																																																					
64 -57011011011011011010		32-17011011011011011010																																																																					
Card Data: 00 No remote unit or no initial communication		Accumulative Input Error Detection for Partial Refresh																																																																					
01 Input, partial refresh or remote terminal		FEDCBA9876543210																																																																					
10 Output remote unit		0110110110110110110																																																																					
Remote Terminal Unit Faulty Station No. FEDCBA9876543210		Input Faulty Error Detection for Partial Refresh																																																																					
0110110110110110110		FEDCBA9876543210																																																																					
		0110110110110110110																																																																					
	2)	70 to 77	0046 to 004D																																																																				
	3)	195	00C3																																																																				
	4)	107	006B																																																																				
	5)	90 to 93	005A to 005D																																																																				
	6)	100 to 103	0064 to 0067																																																																				
	7)	598	0256																																																																				
	8)	599	0257																																																																				
	-	---	---																																																																				
<p>AJ71PT32-S3 Batch Refresh Data Monitor Screen</p> <table border="1"> <thead> <tr> <th>Station Number</th> <th>Transmission Data</th> <th>Receive Data</th> </tr> </thead> <tbody> <tr> <td>4 - 1</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>8 - 5</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>12 - 9</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>16 -13</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>20 -17</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>24 -21</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>28 -25</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>32 -29</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>36 -33</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>40 -37</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>44 -41</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>48 -45</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>52 -49</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>56 -53</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>60 -57</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> <tr> <td>64 -61</td> <td>01101101101101101101101101101101</td> <td>01101101101101101101101101101101</td> </tr> </tbody> </table>	Station Number	Transmission Data	Receive Data	4 - 1	01101101101101101101101101101101	01101101101101101101101101101101	8 - 5	01101101101101101101101101101101	01101101101101101101101101101101	12 - 9	01101101101101101101101101101101	01101101101101101101101101101101	16 -13	01101101101101101101101101101101	01101101101101101101101101101101	20 -17	01101101101101101101101101101101	01101101101101101101101101101101	24 -21	01101101101101101101101101101101	01101101101101101101101101101101	28 -25	01101101101101101101101101101101	01101101101101101101101101101101	32 -29	01101101101101101101101101101101	01101101101101101101101101101101	36 -33	01101101101101101101101101101101	01101101101101101101101101101101	40 -37	01101101101101101101101101101101	01101101101101101101101101101101	44 -41	01101101101101101101101101101101	01101101101101101101101101101101	48 -45	01101101101101101101101101101101	01101101101101101101101101101101	52 -49	01101101101101101101101101101101	01101101101101101101101101101101	56 -53	01101101101101101101101101101101	01101101101101101101101101101101	60 -57	01101101101101101101101101101101	01101101101101101101101101101101	64 -61	01101101101101101101101101101101	01101101101101101101101101101101	1)	10 to 41	000A to 0029																	
	Station Number	Transmission Data	Receive Data																																																																				
4 - 1	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
8 - 5	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
12 - 9	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
16 -13	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
20 -17	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
24 -21	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
28 -25	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
32 -29	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
36 -33	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
40 -37	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
44 -41	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
48 -45	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
52 -49	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
56 -53	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
60 -57	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
64 -61	01101101101101101101101101101101	01101101101101101101101101101101																																																																					
	2)	110 to 141	006E to 008D																																																																				

12.25 AJ71ID1(ID2) -R4, A1SJ71ID1(ID2) -R4 Module Monitor

Screen Image	No.	Buffer memory address																																																																																																																																											
		X		Y																																																																																																																																									
		dec.	hex.	dec.	hex.																																																																																																																																								
<p>AJ71ID Movement Monitor Screen CH1</p> <table border="1"> <thead> <tr> <th>Addr</th> <th>Data</th> <th>Addr</th> <th>Data</th> <th>Addr</th> <th>Data</th> <th>Addr</th> <th>Data</th> </tr> </thead> <tbody> <tr><td>K 100</td><td>H 0123</td><td>K 116</td><td>H 0123</td><td>K 132</td><td>H 0123</td><td>K 148</td><td>H 0123</td></tr> <tr><td>K 101</td><td>H 0123</td><td>K 117</td><td>H 0123</td><td>K 133</td><td>H 0123</td><td>K 149</td><td>H 0123</td></tr> <tr><td>K 102</td><td>H 0123</td><td>K 118</td><td>H 0123</td><td>K 134</td><td>H 0123</td><td>K 150</td><td>H 0123</td></tr> <tr><td>K 103</td><td>H 0123</td><td>K 119</td><td>H 0123</td><td>K 135</td><td>H 0123</td><td>K 151</td><td>H 0123</td></tr> <tr><td>K 104</td><td>H 0123</td><td>K 120</td><td>H 0123</td><td>K 136</td><td>H 0123</td><td>K 152</td><td>H 0123</td></tr> <tr><td>K 105</td><td>H 0123</td><td>K 121</td><td>H 0123</td><td>K 137</td><td>H 0123</td><td>K 153</td><td>H 0123</td></tr> <tr><td>K 106</td><td>H 0123</td><td>K 122</td><td>H 0123</td><td>K 138</td><td>H 0123</td><td>K 154</td><td>H 0123</td></tr> <tr><td>K 107</td><td>H 0123</td><td>K 123</td><td>H 0123</td><td>K 139</td><td>H 0123</td><td>K 155</td><td>H 0123</td></tr> <tr><td>K 108</td><td>H 0123</td><td>K 124</td><td>H 0123</td><td>K 140</td><td>H 0123</td><td>K 156</td><td>H 0123</td></tr> <tr><td>K 109</td><td>H 0123</td><td>K 125</td><td>H 0123</td><td>K 141</td><td>H 0123</td><td>K 157</td><td>H 0123</td></tr> <tr><td>K 110</td><td>H 0123</td><td>K 126</td><td>H 0123</td><td>K 142</td><td>H 0123</td><td>K 158</td><td>H 0123</td></tr> <tr><td>K 111</td><td>H 0123</td><td>K 127</td><td>H 0123</td><td>K 143</td><td>H 0123</td><td>K 159</td><td>H 0123</td></tr> <tr><td>K 112</td><td>H 0123</td><td>K 128</td><td>H 0123</td><td>K 144</td><td>H 0123</td><td>K 160</td><td>H 0123</td></tr> <tr><td>K 113</td><td>H 0123</td><td>K 129</td><td>H 0123</td><td>K 145</td><td>H 0123</td><td>K 161</td><td>H 0123</td></tr> <tr><td>K 114</td><td>H 0123</td><td>K 130</td><td>H 0123</td><td>K 146</td><td>H 0123</td><td>K 162</td><td>H 0123</td></tr> <tr><td>K 115</td><td>H 0123</td><td>K 131</td><td>H 0123</td><td>K 147</td><td>H 0123</td><td>K 163</td><td>H 0123</td></tr> </tbody> </table>	Addr	Data	Addr	Data	Addr	Data	Addr	Data	K 100	H 0123	K 116	H 0123	K 132	H 0123	K 148	H 0123	K 101	H 0123	K 117	H 0123	K 133	H 0123	K 149	H 0123	K 102	H 0123	K 118	H 0123	K 134	H 0123	K 150	H 0123	K 103	H 0123	K 119	H 0123	K 135	H 0123	K 151	H 0123	K 104	H 0123	K 120	H 0123	K 136	H 0123	K 152	H 0123	K 105	H 0123	K 121	H 0123	K 137	H 0123	K 153	H 0123	K 106	H 0123	K 122	H 0123	K 138	H 0123	K 154	H 0123	K 107	H 0123	K 123	H 0123	K 139	H 0123	K 155	H 0123	K 108	H 0123	K 124	H 0123	K 140	H 0123	K 156	H 0123	K 109	H 0123	K 125	H 0123	K 141	H 0123	K 157	H 0123	K 110	H 0123	K 126	H 0123	K 142	H 0123	K 158	H 0123	K 111	H 0123	K 127	H 0123	K 143	H 0123	K 159	H 0123	K 112	H 0123	K 128	H 0123	K 144	H 0123	K 160	H 0123	K 113	H 0123	K 129	H 0123	K 145	H 0123	K 161	H 0123	K 114	H 0123	K 130	H 0123	K 146	H 0123	K 162	H 0123	K 115	H 0123	K 131	H 0123	K 147	H 0123	K 163	H 0123	1)	100 to 163	0064 to 00A3	4100 to 4163	1004 to 1043
Addr	Data	Addr	Data	Addr	Data	Addr	Data																																																																																																																																						
K 100	H 0123	K 116	H 0123	K 132	H 0123	K 148	H 0123																																																																																																																																						
K 101	H 0123	K 117	H 0123	K 133	H 0123	K 149	H 0123																																																																																																																																						
K 102	H 0123	K 118	H 0123	K 134	H 0123	K 150	H 0123																																																																																																																																						
K 103	H 0123	K 119	H 0123	K 135	H 0123	K 151	H 0123																																																																																																																																						
K 104	H 0123	K 120	H 0123	K 136	H 0123	K 152	H 0123																																																																																																																																						
K 105	H 0123	K 121	H 0123	K 137	H 0123	K 153	H 0123																																																																																																																																						
K 106	H 0123	K 122	H 0123	K 138	H 0123	K 154	H 0123																																																																																																																																						
K 107	H 0123	K 123	H 0123	K 139	H 0123	K 155	H 0123																																																																																																																																						
K 108	H 0123	K 124	H 0123	K 140	H 0123	K 156	H 0123																																																																																																																																						
K 109	H 0123	K 125	H 0123	K 141	H 0123	K 157	H 0123																																																																																																																																						
K 110	H 0123	K 126	H 0123	K 142	H 0123	K 158	H 0123																																																																																																																																						
K 111	H 0123	K 127	H 0123	K 143	H 0123	K 159	H 0123																																																																																																																																						
K 112	H 0123	K 128	H 0123	K 144	H 0123	K 160	H 0123																																																																																																																																						
K 113	H 0123	K 129	H 0123	K 145	H 0123	K 161	H 0123																																																																																																																																						
K 114	H 0123	K 130	H 0123	K 146	H 0123	K 162	H 0123																																																																																																																																						
K 115	H 0123	K 131	H 0123	K 147	H 0123	K 163	H 0123																																																																																																																																						
<p>AJ71ID Input/Output Monitor Screen</p> <table border="1"> <thead> <tr> <th></th> <th>X</th> <th>Y</th> </tr> </thead> <tbody> <tr><td>00</td><td>MDT Error</td><td>10</td></tr> <tr><td>01</td><td></td><td>11</td></tr> <tr><td>02</td><td></td><td>12</td></tr> <tr><td>03</td><td>CH1 ID-BUSY</td><td>13</td></tr> <tr><td>04</td><td>ID-CommandComplete</td><td>14</td></tr> <tr><td>05</td><td>ID-Error</td><td>15</td></tr> <tr><td>06</td><td>ID-READY</td><td>16</td></tr> <tr><td>07</td><td></td><td>17</td></tr> <tr><td>08</td><td></td><td>18</td></tr> <tr><td>09</td><td></td><td>19</td></tr> <tr><td>0A</td><td></td><td>1A</td></tr> <tr><td>0B</td><td>CH2 ID-BUSY</td><td>1B</td></tr> <tr><td>0C</td><td>ID-CommandComplete</td><td>1C</td></tr> <tr><td>0D</td><td>ID-Error</td><td>1D</td></tr> <tr><td>0E</td><td></td><td>1E</td></tr> <tr><td>0F</td><td></td><td>1F</td></tr> </tbody> </table>		X	Y	00	MDT Error	10	01		11	02		12	03	CH1 ID-BUSY	13	04	ID-CommandComplete	14	05	ID-Error	15	06	ID-READY	16	07		17	08		18	09		19	0A		1A	0B	CH2 ID-BUSY	1B	0C	ID-CommandComplete	1C	0D	ID-Error	1D	0E		1E	0F		1F	1)	---	---	---	---																																																																																					
	X	Y																																																																																																																																											
00	MDT Error	10																																																																																																																																											
01		11																																																																																																																																											
02		12																																																																																																																																											
03	CH1 ID-BUSY	13																																																																																																																																											
04	ID-CommandComplete	14																																																																																																																																											
05	ID-Error	15																																																																																																																																											
06	ID-READY	16																																																																																																																																											
07		17																																																																																																																																											
08		18																																																																																																																																											
09		19																																																																																																																																											
0A		1A																																																																																																																																											
0B	CH2 ID-BUSY	1B																																																																																																																																											
0C	ID-CommandComplete	1C																																																																																																																																											
0D	ID-Error	1D																																																																																																																																											
0E		1E																																																																																																																																											
0F		1F																																																																																																																																											
<p>AJ71ID Set Up Information Monitor Screen</p> <table border="1"> <thead> <tr> <th></th> <th>Valid range</th> <th>CH1</th> <th>CH2</th> </tr> </thead> <tbody> <tr><td>1)</td><td>ID Command</td><td></td><td></td></tr> <tr><td>2)</td><td>Address. Data</td><td>0~4094/8189·1~3900</td><td>K 0123 · K 0123</td></tr> <tr><td>3)</td><td>Retry</td><td>0~32767</td><td>01234</td></tr> <tr><td>4)</td><td>Total Communica.</td><td></td><td>0123456789</td></tr> <tr><td>5)</td><td>Comparison</td><td>Disagreement OFF</td><td>Disagreement OFF</td></tr> <tr><td>6)</td><td>Copy direction</td><td>12: CH1 → CH2</td><td>CH1 → CH2</td></tr> <tr><td>7)</td><td>LED Status</td><td>DC24V IDERR ERR</td><td>DC24V IDERR ERR</td></tr> <tr><td>8)</td><td>Err Record Latst</td><td>Past1 Past2 Past3 Past4</td><td></td></tr> </tbody> </table>		Valid range	CH1	CH2	1)	ID Command			2)	Address. Data	0~4094/8189·1~3900	K 0123 · K 0123	3)	Retry	0~32767	01234	4)	Total Communica.		0123456789	5)	Comparison	Disagreement OFF	Disagreement OFF	6)	Copy direction	12: CH1 → CH2	CH1 → CH2	7)	LED Status	DC24V IDERR ERR	DC24V IDERR ERR	8)	Err Record Latst	Past1 Past2 Past3 Past4		1)	0	0000	4000	0FA0																																																																																																				
	Valid range	CH1	CH2																																																																																																																																										
1)	ID Command																																																																																																																																												
2)	Address. Data	0~4094/8189·1~3900	K 0123 · K 0123																																																																																																																																										
3)	Retry	0~32767	01234																																																																																																																																										
4)	Total Communica.		0123456789																																																																																																																																										
5)	Comparison	Disagreement OFF	Disagreement OFF																																																																																																																																										
6)	Copy direction	12: CH1 → CH2	CH1 → CH2																																																																																																																																										
7)	LED Status	DC24V IDERR ERR	DC24V IDERR ERR																																																																																																																																										
8)	Err Record Latst	Past1 Past2 Past3 Past4																																																																																																																																											
	2)	1	0001	4001	0FA1																																																																																																																																								
		2	0002	4002	0FA2																																																																																																																																								
	3)	8	0008	4008	0FA8																																																																																																																																								
	4)	22	0016	4022	0FB6																																																																																																																																								
		23	0017	4023	0FB7																																																																																																																																								
	5)	4	0004	4004	0FA4																																																																																																																																								
		5	0005	4005	0FA5																																																																																																																																								
	6)	---	---	4010	0FAA																																																																																																																																								
	7)	12	000C	4012	0FAC																																																																																																																																								
	8)	14 to 18	000E to 0012	4014 to 4018	0FAE to 0FB2																																																																																																																																								
	-	---	---	---	---																																																																																																																																								

12.26 A84AD Module Monitor

Screen Image	No.	Buffer memory address																																			
		dec.	hex.																																		
<p>A84AD Operation Monitor Screen</p> <table border="1"> <thead> <tr> <th>Input/Output Status [%]</th> <th>Temp. Value [C]</th> <th>Module Code</th> <th>O/P Over</th> <th>O/P Under</th> </tr> </thead> <tbody> <tr> <td>Channel 1 01234.6 1) 01234.6</td> <td>01234 2)</td> <td>01</td> <td>0</td> <td>0</td> </tr> <tr> <td>Channel 2 01234.6 01234.6</td> <td>01234</td> <td>01</td> <td>0</td> <td>0</td> </tr> <tr> <td>Channel 3 01234.6 01234.6</td> <td>01234</td> <td>01</td> <td>0</td> <td>0</td> </tr> <tr> <td>Channel 4 01234.6 01234.6</td> <td>01234</td> <td>01</td> <td>0</td> <td>0</td> </tr> </tbody> </table> <p>Loaded Module Code: 02,04,05,10,12,13,14,15,18,1A,1C,1E,1F</p> <p>Temp. Value: 06,07,16,17</p> <p>Module Code: 18,1A,1C,1E,1F</p> <p>Writing Data Error CH:0 Code:0</p> <p>Channel: 4321</p> <p>O/P Enable Valid: 0110110110110110</p> <p>O/P Enabled: 0000</p> <p>Legend: ■ WDT Error ■ Module 1 Fault ■ Module 2 Fault ■ Module 3 Fault ■ Module 4 Fault</p>	Input/Output Status [%]	Temp. Value [C]	Module Code	O/P Over	O/P Under	Channel 1 01234.6 1) 01234.6	01234 2)	01	0	0	Channel 2 01234.6 01234.6	01234	01	0	0	Channel 3 01234.6 01234.6	01234	01	0	0	Channel 4 01234.6 01234.6	01234	01	0	0	1)	10 to 13	000A to 000D									
	Input/Output Status [%]	Temp. Value [C]	Module Code	O/P Over	O/P Under																																
	Channel 1 01234.6 1) 01234.6	01234 2)	01	0	0																																
	Channel 2 01234.6 01234.6	01234	01	0	0																																
	Channel 3 01234.6 01234.6	01234	01	0	0																																
	Channel 4 01234.6 01234.6	01234	01	0	0																																
	2)	18 to 21	0012 to 0015																																		
	3)	28 to 31	001C to 001F																																		
	4)	22 to 25	0016 to 0019																																		
5)	22 to 25	0016 to 0019																																			
6)	26	001A																																			
7)	27	001B																																			
8)	---	---																																			
9)	---	---																																			
-	---	---	---																																		
<p>A84AD Setting Monitor Screen</p> <table border="1"> <thead> <tr> <th>Processing Mode</th> <th>Count/Time</th> <th>Offset [%]</th> <th>Gain [%]</th> </tr> </thead> <tbody> <tr> <td>Sample/Average</td> <td>Count/Time</td> <td></td> <td></td> </tr> <tr> <td>CH 4321</td> <td>4321</td> <td>Channel 1 3) 0123</td> <td>4) 01234 5) 01234</td> </tr> <tr> <td>0: Sampling</td> <td>0: Count Average</td> <td>Channel 2 0123</td> <td>01234</td> </tr> <tr> <td>1: Averaging</td> <td>1: Time Average</td> <td>Channel 3 0123</td> <td>01234</td> </tr> <tr> <td></td> <td></td> <td>Channel 4 0123</td> <td>01234</td> </tr> </tbody> </table>	Processing Mode	Count/Time	Offset [%]	Gain [%]	Sample/Average	Count/Time			CH 4321	4321	Channel 1 3) 0123	4) 01234 5) 01234	0: Sampling	0: Count Average	Channel 2 0123	01234	1: Averaging	1: Time Average	Channel 3 0123	01234			Channel 4 0123	01234	1)	1	0001										
	Processing Mode	Count/Time	Offset [%]	Gain [%]																																	
	Sample/Average	Count/Time																																			
	CH 4321	4321	Channel 1 3) 0123	4) 01234 5) 01234																																	
	0: Sampling	0: Count Average	Channel 2 0123	01234																																	
1: Averaging	1: Time Average	Channel 3 0123	01234																																		
		Channel 4 0123	01234																																		
2)	1	0001																																			
3)	2 to 5	0002 to 0005																																			
4)	32, 34, 36, 38	0020, 0022, 0024, 0026																																			
5)	33, 35, 37, 39	0021, 0023, 0025, 0027																																			
-	---	---	---																																		
<p>A84AD Input/Output Monitor Screen</p> <table border="1"> <thead> <tr> <th>Inputs (X)</th> <th>Outputs (Y)</th> </tr> </thead> <tbody> <tr> <td>00 10 WDT Error</td> <td>20 10 CH1 Enabled</td> </tr> <tr> <td>01 11 READY</td> <td>21 11 CH2 Enabled</td> </tr> <tr> <td>02 12 CH1 Mod. Fault</td> <td>22 12 CH3 Enabled</td> </tr> <tr> <td>03 13 CH2 Mod. Fault</td> <td>23 13 CH4 Enabled</td> </tr> <tr> <td>04 14 CH3 Mod. Fault</td> <td>24 14</td> </tr> <tr> <td>05 15 CH4 Mod. Fault</td> <td>25 15</td> </tr> <tr> <td>06 16</td> <td>26 16</td> </tr> <tr> <td>07 17</td> <td>27 17</td> </tr> <tr> <td>08 18</td> <td>28 18</td> </tr> <tr> <td>09 19</td> <td>29 19</td> </tr> <tr> <td>0A 1A</td> <td>2A 1A</td> </tr> <tr> <td>0B 1B</td> <td>2B 1B</td> </tr> <tr> <td>0C 1C</td> <td>2C 1C</td> </tr> <tr> <td>0D 1D</td> <td>2D 1D</td> </tr> <tr> <td>0E 1E</td> <td>2E 1E</td> </tr> <tr> <td>0F 1F</td> <td>2F 1F</td> </tr> </tbody> </table>	Inputs (X)	Outputs (Y)	00 10 WDT Error	20 10 CH1 Enabled	01 11 READY	21 11 CH2 Enabled	02 12 CH1 Mod. Fault	22 12 CH3 Enabled	03 13 CH2 Mod. Fault	23 13 CH4 Enabled	04 14 CH3 Mod. Fault	24 14	05 15 CH4 Mod. Fault	25 15	06 16	26 16	07 17	27 17	08 18	28 18	09 19	29 19	0A 1A	2A 1A	0B 1B	2B 1B	0C 1C	2C 1C	0D 1D	2D 1D	0E 1E	2E 1E	0F 1F	2F 1F	1)	---	---
Inputs (X)	Outputs (Y)																																				
00 10 WDT Error	20 10 CH1 Enabled																																				
01 11 READY	21 11 CH2 Enabled																																				
02 12 CH1 Mod. Fault	22 12 CH3 Enabled																																				
03 13 CH2 Mod. Fault	23 13 CH4 Enabled																																				
04 14 CH3 Mod. Fault	24 14																																				
05 15 CH4 Mod. Fault	25 15																																				
06 16	26 16																																				
07 17	27 17																																				
08 18	28 18																																				
09 19	29 19																																				
0A 1A	2A 1A																																				
0B 1B	2B 1B																																				
0C 1C	2C 1C																																				
0D 1D	2D 1D																																				
0E 1E	2E 1E																																				
0F 1F	2F 1F																																				

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>A84AD Graph Monitor Screen</p> <p>Input/Output [%] 0 50 100 75 100</p> <p>Temp. Value [C] 01234</p> <p>Module Code 01</p> <p>Channel 1, Channel 2, Channel 3, Channel 4</p> <p>Top Scale (0): For module codes 06, 07, 16 & 17. Bottom Scale (0): For all other module codes.</p> <p>Channel 4321</p> <p>O/P Enable Valid 0110110110110110</p> <p>O/P Enabled 0000</p> <p>0: Effective 1: Invalidity</p> <p>Legend: ■ WDT Error ■ Module 1 Fault ■ Module 2 Fault ■ Module 3 Fault ■ Module 4 Fault</p>	1)	10 to 13	000A to 000D
	2)	18 to 21	0012 to 0015
	3)	28 to 31	001C to 001F
	4)	27	001B
	5)	---	---
-	---	---	---

12.27 A1S64TCTT(BW)-S1, A1S64TCRT(BW)-S1 Module Monitor

Screen Image	No.	Buffer memory address																																																												
		CH1		CH2		CH3		CH4																																																						
		dec.	hex.	dec.	hex.	dec.	hex.	dec.	hex.																																																					
<p>A1S64TCTT/RT-S1 Operation Monitor Screen (ALL CH)</p> <table border="1"> <thead> <tr> <th></th> <th>CH1</th> <th>CH2</th> <th>CH3</th> <th>CH4</th> </tr> </thead> <tbody> <tr> <td>1) Input range</td> <td>R</td> <td>Wre5-26</td> <td>J</td> <td>JPt100</td> </tr> <tr> <td>2) Measurement unit</td> <td>°C</td> <td>°F</td> <td>°F</td> <td>°C</td> </tr> <tr> <td>3) Decimal point position</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td rowspan="2">4) Temp. process value (PV)</td> <td>Decimal point =0</td> <td>012345</td> <td>012345</td> <td>012345</td> </tr> <tr> <td>Decimal point =1</td> <td>0123.5</td> <td>0123.5</td> <td>0123.5</td> </tr> <tr> <td rowspan="2">5) Set value setting (SV)</td> <td>Decimal point =0</td> <td>012345</td> <td>012345</td> <td>012345</td> </tr> <tr> <td>Decimal point =1</td> <td>0123.5</td> <td>0123.5</td> <td>0123.5</td> </tr> <tr> <td>6) Manipulation value (MV) [%]</td> <td>0 100</td> <td>0 100</td> <td>0 100</td> <td>0 100</td> </tr> <tr> <td>7) Alert occurrence flag</td> <td>■</td> <td>■</td> <td>■</td> <td>■</td> </tr> <tr> <td>8) Write error flag</td> <td></td> <td></td> <td>■</td> <td></td> </tr> </tbody> </table>		CH1	CH2	CH3	CH4	1) Input range	R	Wre5-26	J	JPt100	2) Measurement unit	°C	°F	°F	°C	3) Decimal point position	0	0	0	0	4) Temp. process value (PV)	Decimal point =0	012345	012345	012345	Decimal point =1	0123.5	0123.5	0123.5	5) Set value setting (SV)	Decimal point =0	012345	012345	012345	Decimal point =1	0123.5	0123.5	0123.5	6) Manipulation value (MV) [%]	0 100	0 100	0 100	0 100	7) Alert occurrence flag	■	■	■	■	8) Write error flag			■		1)	32	0020	64	0040	96	0060	128	0080
		CH1	CH2	CH3	CH4																																																									
	1) Input range	R	Wre5-26	J	JPt100																																																									
	2) Measurement unit	°C	°F	°F	°C																																																									
	3) Decimal point position	0	0	0	0																																																									
	4) Temp. process value (PV)	Decimal point =0	012345	012345	012345																																																									
		Decimal point =1	0123.5	0123.5	0123.5																																																									
	5) Set value setting (SV)	Decimal point =0	012345	012345	012345																																																									
Decimal point =1		0123.5	0123.5	0123.5																																																										
6) Manipulation value (MV) [%]	0 100	0 100	0 100	0 100																																																										
7) Alert occurrence flag	■	■	■	■																																																										
8) Write error flag			■																																																											
2)	32	0020	64	0040	96	0060	128	0080																																																						
3)	1	0001	2	0002	3	0003	4	0004																																																						
4)	9	0009	10	000A	11	000B	12	000C																																																						
5)	34	0022	66	0042	98	0062	130	0082																																																						
6)	13	000D	14	000E	15	000F	16	0010																																																						
7)	---	---	---	---	---	---	---	---																																																						
8)	---	---	---	---	---	---	---	---																																																						
-	---	---	---	---	---	---	---	---																																																						

Screen Image

A1S64TCTT/RT-S1 Alert details

	CH1	CH2	CH3	CH4
PV exceeds the specified temperature measurement range in the input range.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
PV is below the specified temperature measurement range in the input range.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Hardware error occurs.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Alert alarm 1 is turned on.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Alert alarm 2 is turned on.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Alert alarm 3 is turned on.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Alert alarm 4 is turned on.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
The heater disconnection alarm is detected.	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
The loop disconnection is detected.	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
The "current error when the output is off" is detected.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

A1S64TCTT/RT-S1 Operation Monitor Screen (CH1)

	CH1	CH2	CH3	CH4
Input range R				
Measurement unit °C				
Dec. point position 0				
Pro.Val. Dec.P.P.=0 012345 (PV) Dec.P.P.=0 0123.5				
Set Val. Dec.P.P.=0 012345 (SV) Dec.P.P.=0 0123.5				
Man.Val.0 (MV) [%]				
Proportional s.(P) 0123.5 %				
Integral time(I) 0123 sec				
Derivative time(D) 0123sec				
Write error				
Error address 0123 Cause				
Default setting registration.				
Alert alarm No	1	2	3	4
Set.Val. Dec.P.P.=0 012345 (SV) Dec.P.P.=0 0123.5				
Mode setting	0 1	0 1	0 1	0 1
Heat.cur.pro.vl. Heat.val.com.set				
Output Limiter Upper 012.4 % Lower 012.4 %				
CT selection	0 012.4 A	1 01.34 A		
Expanded graph				
Normal Graph				

No.	Buffer memory address							
	CH1		CH2		CH3		CH4	
	dec.	hex.	dec.	hex.	dec.	hex.	dec.	hex.
1)	5	0005	6	0006	7	0007	8	0008
-	---	---	---	---	---	---	---	---
1)	32	0020	64	0040	96	0060	128	0080
2)	32	0020	64	0040	96	0060	128	0080
3)	1	0001	2	0002	3	0003	4	0004
4)	9	0009	10	000A	11	000B	12	000C
5)	34	0022	66	0042	98	0062	130	0082
6)	13	000D	14	000E	15	000F	16	0010
7)	35	0023	67	0043	99	0063	131	0083
8)	36	0024	68	0044	100	0064	132	0084
9)	37	0025	69	0045	101	0065	133	0085
10)	---	---	---	---	---	---	---	---
11)	0	0000	0	0000	0	0000	0	0000
12)	0	0000	0	0000	0	0000	0	0000
13)	38 to 41	0026 to 0029	70 to 73	0046 to 0049	102 to 105	0066 to 0069	134 to 137	0086 to 0089
14)	160 to 163	00A0 to 00A3	160 to 163	00A0 to 00A3	160 to 163	00A0 to 00A3	160 to 163	00A0 to 00A3
15)	57	0039	89	0059	121	0079	153	0099
16)	25	0019	26	001A	27	001B	28	001C
17)	171	00AB	172	00AC	173	00AD	174	00AE
18)	42	002A	74	004A	106	006A	138	008A
	43	002B	75	004B	107	006B	139	008B
19)	---	---	---	---	---	---	---	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS

10 ERROR MESSAGES FOR SYSTEM MONITOR

11 OPERATING SP MODULE MONITOR

12 OPERATING SP MODULE MONITOR SCREEN

13 OPERATING I/O MODULE MONITOR SCREENS

14 ERROR MESSAGES FOR SP MODULE MONITOR

15 OPERATING NET-WORK MONITOR

16 SWITCHING THE NETWORK MONITOR SCREENS

12.28 Q64AD,Q68ADV,Q68ADI Module Monitor

Screen Image	No.	Buffer memory address																																																	
		dec.	hex.																																																
<p>Q68ADV/Q68ADI/Q64AD Operation Monitor</p> <p>Channel: 8 7 6 5 4 3 2 1 ERROR: 012</p> <p>1) A/D conv 01101101 0:Used 1:OFF</p> <p>2) A/D conv complete 01101101 0:incomplet 1:completed</p> <p>3) Average process 01101101 0:sampling 1:averaging</p> <p>4) setting 01101101 0:number 1:time</p> <p>Setting range HEX 01230123</p> <p>0:4 to 20(mA)/1:0 to 20(mA)/2:1 to 5(V) 3:0 to 5(V) /4:-10 to +10(V) 5:0 to +10(V)/F:User range setting</p> <table border="1"> <thead> <tr> <th rowspan="2">Average</th> <th colspan="3">Digital value</th> </tr> <tr> <th>Time/Count</th> <th>Output</th> <th>Minimum</th> <th>Maximum</th> </tr> </thead> <tbody> <tr><td>CH1</td><td>01234</td><td>012345</td><td>012345</td><td>012345</td></tr> <tr><td>CH2</td><td>01234</td><td>012345</td><td>012345</td><td>012345</td></tr> <tr><td>CH3</td><td>01234</td><td>012345</td><td>012345</td><td>012345</td></tr> <tr><td>CH4</td><td>01234</td><td>012345</td><td>012345</td><td>012345</td></tr> <tr><td>CH5</td><td>01234</td><td>012345</td><td>012345</td><td>012345</td></tr> <tr><td>CH6</td><td>01234</td><td>012345</td><td>012345</td><td>012345</td></tr> <tr><td>CH7</td><td>01234</td><td>012345</td><td>012345</td><td>012345</td></tr> <tr><td>CH8</td><td>01234</td><td>012345</td><td>012345</td><td>012345</td></tr> </tbody> </table>	Average	Digital value			Time/Count	Output	Minimum	Maximum	CH1	01234	012345	012345	012345	CH2	01234	012345	012345	012345	CH3	01234	012345	012345	012345	CH4	01234	012345	012345	012345	CH5	01234	012345	012345	012345	CH6	01234	012345	012345	012345	CH7	01234	012345	012345	012345	CH8	01234	012345	012345	012345	1)	0	0000
		Average	Digital value																																																
	Time/Count		Output	Minimum	Maximum																																														
	CH1	01234	012345	012345	012345																																														
	CH2	01234	012345	012345	012345																																														
	CH3	01234	012345	012345	012345																																														
	CH4	01234	012345	012345	012345																																														
	CH5	01234	012345	012345	012345																																														
	CH6	01234	012345	012345	012345																																														
	CH7	01234	012345	012345	012345																																														
CH8	01234	012345	012345	012345																																															
	2)	10	000A																																																
	3)	9	0009																																																
	4)	9	0009																																																
	5)	20, 21	0014, 0015																																																
	6)	19	0013																																																
	7)	1 to 8	0001 to 0008																																																
	8)	11 to 18	000B to 0012																																																
	9)	30, 32, 34, 36, 38, 40, 42, 44	001E, 0020, 0022, 0024, 0026, 0028, 002A, 002C																																																
	10)	31, 33, 35, 37, 39, 41, 43, 45	001F, 0021, 0023, 0025, 0027, 0029, 002B, 002D																																																
	-	---	---																																																
<p>Q68ADV/Q68ADI/Q64AD Input/Output Monitor</p> <table border="1"> <tbody> <tr><td>00</td><td>Module READY</td><td>08</td><td>High resolution</td></tr> <tr><td>01</td><td>Temp. drift comp.</td><td>09</td><td>Operation set</td></tr> <tr><td>02</td><td>Offset/gain mode</td><td>0A</td><td>User range write</td></tr> <tr><td>03</td><td>Ch. change done</td><td>0B</td><td>Ch. change req.</td></tr> <tr><td>04</td><td></td><td>0C</td><td></td></tr> <tr><td>05</td><td></td><td>0D</td><td>Max/min val. RST</td></tr> <tr><td>06</td><td>A/D conv. done</td><td>0E</td><td></td></tr> <tr><td>07</td><td>Error flag</td><td>0F</td><td>Clear error</td></tr> </tbody> </table>	00	Module READY	08	High resolution	01	Temp. drift comp.	09	Operation set	02	Offset/gain mode	0A	User range write	03	Ch. change done	0B	Ch. change req.	04		0C		05		0D	Max/min val. RST	06	A/D conv. done	0E		07	Error flag	0F	Clear error	1)	---	---																
	00	Module READY	08	High resolution																																															
01	Temp. drift comp.	09	Operation set																																																
02	Offset/gain mode	0A	User range write																																																
03	Ch. change done	0B	Ch. change req.																																																
04		0C																																																	
05		0D	Max/min val. RST																																																
06	A/D conv. done	0E																																																	
07	Error flag	0F	Clear error																																																
	-	---	---																																																
<p>Q68ADV/Q68ADI/Q64AD Graph Monitor</p> <p>ERROR: 0</p> <p>CH1: [Bar chart]</p> <p>CH2: [Bar chart]</p> <p>CH3: [Bar chart]</p> <p>CH4: [Bar chart]</p> <p>CH5: [Bar chart]</p> <p>CH6: [Bar chart]</p> <p>CH7: [Bar chart]</p> <p>CH8: [Bar chart]</p>	1)	11 to 18	000B to 0012																																																
		2)	---	---																																															
	-	---	---																																																

12.29 Q62DA,Q64DA Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>Q62DA/Q64DA Operation Monitor</p> <p>Items: Channel 1 3 2 1 Error code 0123</p> <p>D/A Conv: 0110 Remarks: 0:enable 1:disable</p> <p>Setting range: 0123 0: 4 to 20(mA) 1: 0to20(mA) 2: 1 to 5(V) 3: 0 to 5(V) 4: -10to+10(V) F: User range setting</p> <p>Digital value: CH1 012345, CH2 012345, CH3 012345, CH4 012345</p> <p>Set value: Over, Under</p>	1)	0	0000
	2)	20	0014
	3)	1 to 4	0001 to 0004
	4)	11 to 14	000B to 000E
	5)	19	0013
	-	--	--
<p>Q62DA/Q64DA Input/Output Monitor</p> <p>00 Module READY 08</p> <p>01 Op.cond.set done 09</p> <p>02 Offset/gain mode 0A</p> <p>03 Ch. change done 0B</p> <p>04 Set val. change 0C</p> <p>05 Sync.output mode 0D</p> <p>06 Error flag 0E</p> <p>07 Error clear req. 0F</p>	1)	--	--
	-	--	--
<p>Q62DA/Q64DA Graph Monitor</p> <p>CH1: [Bar Chart]</p> <p>CH2: [Bar Chart]</p> <p>CH3: [Bar Chart]</p> <p>CH4: [Bar Chart]</p> <p>Minimum error: [Bar Chart]</p> <p>Maximum error: [Bar Chart]</p>	1)	11 to 14	000B to 000E
	2)	11 to 14	000B to 000E
	3)	1 to 4	0001 to 0004
	4)	--	--
	-	--	--

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.30 QD62,QD62D Module Monitor

Screen Image		No.	Buffer memory address																																																																								
			dec.	hex.																																																																							
<p>QD62D/QD62E/QD62 Operation Monitor</p> <table border="1"> <thead> <tr> <th>Item</th> <th>Channel 1</th> <th>Channel 2</th> <th>Overflow Detection</th> <th>Sampling Periodic</th> <th>Counter function</th> </tr> </thead> <tbody> <tr> <td>1) Set preset val</td> <td>01234567890</td> <td>01234567890</td> <td></td> <td></td> <td></td> </tr> <tr> <td>2) Present value</td> <td>01234567890</td> <td>01234567890</td> <td>CH1 No over</td> <td>Idling</td> <td>Count disable</td> </tr> <tr> <td>3) Equal O/P No.1</td> <td>01234567890</td> <td>01234567890</td> <td>CH2 No over</td> <td>Idling</td> <td>Count disable</td> </tr> <tr> <td>4) Equal O/P No.2</td> <td>01234567890</td> <td>01234567890</td> <td></td> <td></td> <td></td> </tr> <tr> <td>5) Samp/cyclic set</td> <td>012345*10ms</td> <td>012345*10ms</td> <td></td> <td></td> <td></td> </tr> <tr> <td>6) Latch count val</td> <td>01234567890</td> <td>01234567890</td> <td>12)</td> <td>13)</td> <td>14)</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Item</th> <th>Channel 1</th> <th>Channel 2</th> </tr> </thead> <tbody> <tr> <td>7) Samp.count val</td> <td>01234567890</td> <td>01234567890</td> </tr> <tr> <td>8) Cyclic pulse count</td> <td>Was 01234567890</td> <td>01234567890</td> </tr> <tr> <td>9) Ring count min</td> <td>01234567890</td> <td>01234567890</td> </tr> <tr> <td>11) Ring count max</td> <td>01234567890</td> <td>01234567890</td> </tr> </tbody> </table>	Item	Channel 1	Channel 2	Overflow Detection	Sampling Periodic	Counter function	1) Set preset val	01234567890	01234567890				2) Present value	01234567890	01234567890	CH1 No over	Idling	Count disable	3) Equal O/P No.1	01234567890	01234567890	CH2 No over	Idling	Count disable	4) Equal O/P No.2	01234567890	01234567890				5) Samp/cyclic set	012345*10ms	012345*10ms				6) Latch count val	01234567890	01234567890	12)	13)	14)	Item	Channel 1	Channel 2	7) Samp.count val	01234567890	01234567890	8) Cyclic pulse count	Was 01234567890	01234567890	9) Ring count min	01234567890	01234567890	11) Ring count max	01234567890	01234567890	1)	00 to 01	0000 to 0001															
	Item	Channel 1	Channel 2	Overflow Detection	Sampling Periodic	Counter function																																																																					
	1) Set preset val	01234567890	01234567890																																																																								
	2) Present value	01234567890	01234567890	CH1 No over	Idling	Count disable																																																																					
	3) Equal O/P No.1	01234567890	01234567890	CH2 No over	Idling	Count disable																																																																					
	4) Equal O/P No.2	01234567890	01234567890																																																																								
	5) Samp/cyclic set	012345*10ms	012345*10ms																																																																								
	6) Latch count val	01234567890	01234567890	12)	13)	14)																																																																					
	Item	Channel 1	Channel 2																																																																								
	7) Samp.count val	01234567890	01234567890																																																																								
	8) Cyclic pulse count	Was 01234567890	01234567890																																																																								
	9) Ring count min	01234567890	01234567890																																																																								
	11) Ring count max	01234567890	01234567890																																																																								
			32 to 33	0020 to 0021																																																																							
	2)	02 to 03	0002 to 0003																																																																								
		34 to 35	0022 to 0023																																																																								
	3)	04 to 05	0004 to 0005																																																																								
		36 to 37	0024 to 0025																																																																								
	4)	06 to 07	0006 to 0007																																																																								
		38 to 39	0026 to 0027																																																																								
	5)	10, 42	000A, 002A																																																																								
	6)	12 to 13	000C to 000D																																																																								
		44 to 45	002C to 002D																																																																								
	7)	14 to 15	000E to 000F																																																																								
		46 to 47	002E to 002F																																																																								
	8)	16 to 17	0010 to 0011																																																																								
		48 to 49	0030 to 0031																																																																								
	9)	18 to 19	0012 to 0013																																																																								
		50 to 51	0032 to 0033																																																																								
	10)	20 to 21	0014 to 0015																																																																								
		52 to 53	0034 to 0035																																																																								
	11)	22 to 23	0016 to 0017																																																																								
		54 to 55	0036 to 0037																																																																								
	12)	08, 40	0008, 0028																																																																								
	13)	11, 43	000B, 002B																																																																								
	14)	09, 41	0009, 0029																																																																								
<p>QD62D/QD62E/QD62 Input/Output Monitor</p> <table border="1"> <thead> <tr> <th colspan="2">X</th> <th colspan="2">Y</th> </tr> </thead> <tbody> <tr> <td>00 Module ready</td> <td></td> <td>00 CH1 Coincidence signal No.1 reset</td> <td></td> </tr> <tr> <td>01 CH1 Counter large(point No.1)</td> <td></td> <td>01 CH1 Preset command</td> <td></td> </tr> <tr> <td>02 CH1 Counter coincidence(point No.1)</td> <td></td> <td>02 CH1 Coincidence signal enable</td> <td></td> </tr> <tr> <td>03 CH1 Counter small(point No.1)</td> <td></td> <td>03 CH1 Down count command</td> <td></td> </tr> <tr> <td>04 CH1 External preset request find</td> <td></td> <td>04 CH1 Count enable command</td> <td></td> </tr> <tr> <td>05 CH1 Counter large(point No.2)</td> <td></td> <td>05 CH1 External preset detection reset</td> <td></td> </tr> <tr> <td>06 CH1 Counter coincidence(point No.2)</td> <td></td> <td>06 CH1 Counter function selection start</td> <td></td> </tr> <tr> <td>07 CH1 Counter small(point No.2)</td> <td></td> <td>07 CH1 Coincidence signal No.2 reset</td> <td></td> </tr> <tr> <td colspan="2">X</td> <td colspan="2">Y</td> </tr> <tr> <td>08 CH2 Counter large(point No.1)</td> <td></td> <td>08 CH2 Coincidence signal No.1 reset</td> <td></td> </tr> <tr> <td>09 CH2 Counter coincidence(point No.1)</td> <td></td> <td>09 CH2 Preset command</td> <td></td> </tr> <tr> <td>0A CH2 Counter small(point No.1)</td> <td></td> <td>0A CH2 Coincidence signal enable</td> <td></td> </tr> <tr> <td>0B CH2 External preset request find</td> <td></td> <td>0B CH2 Down count command</td> <td></td> </tr> <tr> <td>0C CH2 Counter large(point No.2)</td> <td></td> <td>0C CH2 Count enable command</td> <td></td> </tr> <tr> <td>0D CH2 Counter coincidence(point No.2)</td> <td></td> <td>0D CH2 External preset detection reset</td> <td></td> </tr> <tr> <td>0E CH2 Counter small(point No.2)</td> <td></td> <td>0E CH2 Counter function selection start</td> <td></td> </tr> <tr> <td>0F Fuse broken detection</td> <td></td> <td>0F CH2 Coincidence signal No.2 reset</td> <td></td> </tr> </tbody> </table>	X		Y		00 Module ready		00 CH1 Coincidence signal No.1 reset		01 CH1 Counter large(point No.1)		01 CH1 Preset command		02 CH1 Counter coincidence(point No.1)		02 CH1 Coincidence signal enable		03 CH1 Counter small(point No.1)		03 CH1 Down count command		04 CH1 External preset request find		04 CH1 Count enable command		05 CH1 Counter large(point No.2)		05 CH1 External preset detection reset		06 CH1 Counter coincidence(point No.2)		06 CH1 Counter function selection start		07 CH1 Counter small(point No.2)		07 CH1 Coincidence signal No.2 reset		X		Y		08 CH2 Counter large(point No.1)		08 CH2 Coincidence signal No.1 reset		09 CH2 Counter coincidence(point No.1)		09 CH2 Preset command		0A CH2 Counter small(point No.1)		0A CH2 Coincidence signal enable		0B CH2 External preset request find		0B CH2 Down count command		0C CH2 Counter large(point No.2)		0C CH2 Count enable command		0D CH2 Counter coincidence(point No.2)		0D CH2 External preset detection reset		0E CH2 Counter small(point No.2)		0E CH2 Counter function selection start		0F Fuse broken detection		0F CH2 Coincidence signal No.2 reset		1)	---	---
	X		Y																																																																								
00 Module ready		00 CH1 Coincidence signal No.1 reset																																																																									
01 CH1 Counter large(point No.1)		01 CH1 Preset command																																																																									
02 CH1 Counter coincidence(point No.1)		02 CH1 Coincidence signal enable																																																																									
03 CH1 Counter small(point No.1)		03 CH1 Down count command																																																																									
04 CH1 External preset request find		04 CH1 Count enable command																																																																									
05 CH1 Counter large(point No.2)		05 CH1 External preset detection reset																																																																									
06 CH1 Counter coincidence(point No.2)		06 CH1 Counter function selection start																																																																									
07 CH1 Counter small(point No.2)		07 CH1 Coincidence signal No.2 reset																																																																									
X		Y																																																																									
08 CH2 Counter large(point No.1)		08 CH2 Coincidence signal No.1 reset																																																																									
09 CH2 Counter coincidence(point No.1)		09 CH2 Preset command																																																																									
0A CH2 Counter small(point No.1)		0A CH2 Coincidence signal enable																																																																									
0B CH2 External preset request find		0B CH2 Down count command																																																																									
0C CH2 Counter large(point No.2)		0C CH2 Count enable command																																																																									
0D CH2 Counter coincidence(point No.2)		0D CH2 External preset detection reset																																																																									
0E CH2 Counter small(point No.2)		0E CH2 Counter function selection start																																																																									
0F Fuse broken detection		0F CH2 Coincidence signal No.2 reset																																																																									
	-	---	---																																																																								

12.31 QD75P,QD75D Module Monitor

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>1) 2) 3) 4) 5) 6) 7) 8) 9) 10) 11) 12)</p>	1)	800 to 801	0320 to 0321
		900 to 901	0384 to 0385
		1000 to 1001	03E8 to 03E9
		1100 to 1101	044C to 044D
	2)	812 to 813	032C to 032D
		912 to 913	0390 to 0391
		1012 to 1013	03F4 to 03F5
		1112 to 1113	0458 to 0459
	3)	809, 909, 1009, 1109	0329, 038D, 03F1, 0455
	4)	806, 906, 1006, 1106	0326, 038A, 03EE, 0452
	5)	807, 907, 1007, 1107	0327, 038B, 03EF, 0453
	6)	808, 908, 1008, 1108	0328, 038C, 03F0, 0454
7)	829, 929, 1029, 1129	033D, 03A1, 0405, 0469	
8) to 9)	838, 938, 1038, 1138	0346, 03AA, 040E, 0472	
	1)	---	---
<p>1)</p>	-	--	--

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image	No.	Buffer memory address	
		dec.	hex.

QD75P/QD75D Basic parameters 1									
Item	Axis1	Axis2	Axis3	Axis4	Item	Axis1	Axis2	Axis3	Axis4
Unit setting	0	0	0	0	Rotation direction setting	0	0	0	0
0:mm 1:inch 2:degree 3:pulse					0:Forward run pulse output 1:Reverse run pulse output				
Pulse output mode	0	0	0	0					
0:PLS/SIGN 1:CM/CCW 2:A p./B p.(multiple of 4) 3:A p./B p.(multiple of 1)									
Movement amount per pulse					Bias speed at start				
Item	Axis1	Axis2	Axis3	Axis4	Axis1	Axis2	Axis3	Axis4	Axis4
Pulse/rotation (Ap)	01234	01234	01234	01234	Axis1	0123456789	Axis2	0123456789	
1 to 65535(pulse)					Axis3	0123456789	Axis4	0123456789	
Movement amount per rotation(A1)	01234	01234	01234	01234	Setting range				
1 to *10 ⁻³ (μm) *10 ⁻⁴ (inch):*10 ⁻³ (deg) 65535 *1 (pul)					0 to 2000000000 (mm/min):*10 ⁻² (inch/min):*10 ⁻³ (degree/min):*10 ⁻³ 0 to 1000000 (pulse/sec):*1				
Unit (Am)	0123	0123	0123	0123					
magnification	1/10/100/1000/fold								

1)	0, 150, 300, 450	0000, 0096, 012C, 01C2
2)	4, 154, 304, 454	0004, 009A, 0130, 01C6
3)	1, 151, 301, 451	0001, 0097, 012D, 01C3
4)	2, 152, 302, 452	0002, 0098, 012E, 01C4
5)	3, 153, 303, 453	0003, 0099, 012F, 01C5
6)	5, 155, 305, 455	0005, 009B, 0131, 01C7
7)	6, 156, 306, 456	0006, 009C, 0132, 01C8

QD75P/QD75D Basic parameters 2									
Speed limit value					Deceleration time 0				
Axis1	Axis2	Axis3	Axis4	Axis4	Axis1	Axis2	Axis3	Axis4	Axis4
01234	01234	01234	01234	01234	01234567	01234567	01234567	01234567	
01234	01234	01234	01234	01234	01234567	01234567	01234567	01234567	
Setting range					Setting range				
1 to 2000000000 (mm/min):*10 ⁻² (inch/min):*10 ⁻³ (degree/min):*10 ⁻³ 1 to 1000000 (pulse/sec):*1					1 to 8388608(msec)				
Acceleration time 0									
Axis1	01234567	Axis2	01234567						
Axis3	01234567	Axis4	01234567						
Setting range					1 to 8388608(msec)				

1)	10 to 11	000A to 000B
	160 to 161	00A0 to 00A1
	310 to 311	0136 to 0137
	460 to 461	01CC to 01CD
2)	12 to 13	000C to 000D
	162 to 163	00A2 to 00A3
	312 to 313	0138 to 0139
	462 to 463	01CE to 01CF
3)	14 to 15	000E to 000F
	164 to 165	00A4 to 00A5
	314 to 315	013A to 013B
	464 to 465	01D0 to 01D1
-	---	---

QD75P/QD75D Detailed parameters 1-1										
Backlash compensation amount					Manual pulse generator input selection					
Axis1	Axis2	Axis3	Axis4	Axis4	Axis1	Axis2	Axis3	Axis4	Axis4	
01234	01234	01234	01234	01234	0	-	-	-		
Setting range					Setting range					
0 to 65535 (μm):*10 ⁻³ (inch):*10 ⁻⁴ (degree):*10 ⁻³ (pulse):*1					0:A-phase/B-phase:multiplied by 4 1:A-phase/B-phase:multiplied by 2 2:A-phase/B-phase:multiplied by 1 3:PLS/SIGN					
Software stroke upper limit value					S/W stroke limit select					
High Lmt	Ax.1	01234567890	Ax.2	01234567890	0	0	0	0	0	
	Ax.3	01234567890	Ax.4	01234567890	0:Cr feed 1:Mc feed					
Low Lmt	Ax.1	01234567890	Ax.2	01234567890	0	0	0	0	0	
	Ax.3	01234567890	Ax.4	01234567890	0: valid 1: invalid					
Setting range	-2147483648 (μm):*10 ³ (inch):*10 ³ to 2147483647 (pulse):*1				Torque limit set value	012	012	012	012	1~500 [%]

1)	17, 167, 317, 467	0011, 00A7, 013D, 01D3
	18 to 19	0012 to 0013
	168 to 169	00A8 to 00A9
	318 to 319	013E to 013F
2)	468 to 469	01D4 to 01D5
	20 to 21	0014 to 0015
	170 to 171	00AA to 00AB
	320 to 321	0140 to 0141
	470 to 471	01D6 to 01D7
3)	33, 183, 333, 483	0021, 00B7, 014D, 01E3
4)	22, 172, 322, 472	0016, 00AC, 0142, 01D8
5)	23, 173, 323, 473	0017, 00AD, 0143, 01D9
6)	26, 176, 326, 476	001A, 00B0, 0146, 01DC

Screen Image	No.	Buffer memory address	
		dec.	hex.
	1)	27, 177, 327, 477	001B, 00B1, 0147, 01DD
	2)	28, 178, 328, 478	001C, 00B2, 0148, 01DE
	3)	29, 179, 329, 479	001D, 00B3, 0149, 01DF
	4)	24 to 25	0018 to 0019
		174 to 175	00AE to 00AF
		324 to 325	0144 to 0145
	474 to 475	01DA to 01DB	
5)	30, 180, 330, 480	001E, 00B4, 014A, 01E0	
6)	32, 182,	0020, 00B6,	
7)	332, 482	014C, 01E2	
	1)	36 to 41	0024 to 0029
		186 to 191	00BA to 00BF
		336 to 341	0150 to 0155
		486 to 491	01E6 to 01EB
		42 to 47	002A to 002F
	2)	192 to 197	00C0 to 00C5
		342 to 347	0156 to 015B
		492 to 496	01EC to 01F0
	3)	48 to 49	0030 to 0031
		198 to 199	00C6 to 00C7
		348 to 349	015C to 015D
	498 to 499	01F2 to 01F3	
	4)	50, 200, 350, 500	0032, 00C8, 015E, 01F4
	5)	51, 501, 351, 501	0033, 01F5, 015F, 01F5

9
OPERATION OF THE
VARIOUS SYSTEM
MONITOR SCREENS

10
ERROR MESSAGES
FOR SYSTEM MONI-
TOR

11
OPERATING SP
MODULE MONITOR

12
OPERATING SP
MODULE MONITOR
SCREEN

13
OPERATING I/O
MODULE MONITOR
SCREENS

14
ERROR MESSAGES
FOR SP MODULE
MONITOR

15
OPERATING NET-
WORK MONI-
TOR

16
SWITCHING THE
NETWORK MONI-
TOR SCREENS

Screen Image		No.	Buffer memory address	
			dec.	hex.
QD75P/QD75D Detailed parameters 2-2				
	1)	52, 202, 352, 502	0034, 00CA, 0160, 01F6	
	2)	53, 203, 353, 503	0035, 00CB, 0161, 01F7	
	3)	56, 206, 356, 506	0038, 00CE, 0164, 01FA	
	4)	57, 207, 357, 507	0039, 00CF, 0165, 01FB	
	5)	58, 208, 358, 508	003A, 00D0, 0166, 01FC	
	6)	54, 204, 354, 504	0036, 00CC, 0162, 01F8	
	7)	59, 209, 359, 509	003B, 00D1, 0167, 01FD	
	8)	60 to 61	003C to 003D	
		210 to 211	00D2 to 00D3	
		360 to 361	0168 to 0169	
		510 to 511	01FE to 01FF	
	9)	62, 212, 362, 512	003E, 00D4, 016A, 0200	
QD75P/QD75D OPR detailed parameters				
	1)	79, 229, 379, 529	004F, 00E5, 017B, 0211	
	2)	82, 232, 382, 532	0052, 00E8, 017E, 0214	
	3)	83, 233, 383, 533	0053, 00E9, 017F, 0215	
	4)	86, 236, 386, 536	0056, 00EC, 0182, 0218	
	5)	80 to 81	0050 to 0051	
	6)	230 to 231	00E6 to 00E7	
		380 to 381	017C to 017D	
		530 to 531	0212 to 0213	
	7)	84 to 85	0054 to 0055	
		234 to 235	00EA to 00EB	
		384 to 385	0180 to 0181	
	8)	534 to 535	0216 to 0217	
		87, 237, 387, 537	0057, 00ED, 0183, 0219	
		88, 238, 388, 538	0058, 00EE, 0184, 021A	
	9)	89, 239, 389, 539	0059, 00EF, 0185, 021B	

Screen Image		No.	Buffer memory address	
			dec.	hex.
		1)	70, 220, 370, 520	0046, 00DC, 0172, 0208
		2)	71, 221, 371, 521	0047, 00DD, 0173, 0209
		3)	78, 228, 378, 528	004E, 00E4, 017A, 0210
		4)	72 to 73	0048 to 0049
			222 to 223	00DE to 00DF
			372 to 373	0174 to 0175
			522 to 523	020A to 020B
		5)	74 to 75	004A to 004B
			224 to 225	00E0 to 00E1
			374 to 375	0176 to 0177
		6)	524 to 525	020C to 020D
			76 to 77	004C to 004D
			226 to 227	00E2 to 00E3
		376 to 377	0178 to 0179	
		526 to 527	020E to 020F	
		1)	816, 916, 1016, 1116	0330, 0394, 03F8, 045C
		2)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
		-	---	---

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address																																																																																										
			dec.	hex.																																																																																									
<p>QD75P/QD75D Axis monitor data-1</p> <table border="1"> <thead> <tr> <th></th> <th>Target value</th> <th>Machine feed val</th> <th>Item</th> <th>ax.1</th> <th>ax.2</th> <th>ax.3</th> <th>ax.4</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>Axis1</td> <td>01234567890</td> <td>01234567890</td> <td>In speed cont. flag</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0:Not in 1:In</td> </tr> <tr> <td>Axis2</td> <td>01234567890</td> <td>01234567890</td> <td rowspan="2">In speed chg.proc.</td> <td rowspan="2">0</td> <td rowspan="2">0</td> <td rowspan="2">0</td> <td rowspan="2">0</td> <td rowspan="2">0:Not in 1:In</td> </tr> <tr> <td>Axis3</td> <td>01234567890</td> <td>01234567890</td> </tr> <tr> <td>Axis4</td> <td>01234567890</td> <td>01234567890</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>(μm):$\times 10^{-4}$ (degree):$\times 10^{-6}$ (inch):$\times 10^{-8}$ (pulse):$\times 1$</p> <table border="1"> <thead> <tr> <th></th> <th>Target spd</th> <th>Current spd</th> <th>Feedrate</th> </tr> </thead> <tbody> <tr> <td>Axis1</td> <td>0123456789</td> <td>0123456789</td> <td>0123456789</td> </tr> <tr> <td>Axis2</td> <td>0123456789</td> <td>0123456789</td> <td>0123456789</td> </tr> <tr> <td>Axis3</td> <td>0123456789</td> <td>0123456789</td> <td>0123456789</td> </tr> <tr> <td>Axis4</td> <td>0123456789</td> <td>0123456789</td> <td>0123456789</td> </tr> </tbody> </table> <p>(mm/min):$\times 10^{-2}$ (degree/min):$\times 10^{-4}$ (inch/min):$\times 10^{-4}$ (pulse/sec):$\times 1$</p>		Target value	Machine feed val	Item	ax.1	ax.2	ax.3	ax.4	Note	Axis1	01234567890	01234567890	In speed cont. flag	0	0	0	0	0:Not in 1:In	Axis2	01234567890	01234567890	In speed chg.proc.	0	0	0	0	0:Not in 1:In	Axis3	01234567890	01234567890	Axis4	01234567890	01234567890								Target spd	Current spd	Feedrate	Axis1	0123456789	0123456789	0123456789	Axis2	0123456789	0123456789	0123456789	Axis3	0123456789	0123456789	0123456789	Axis4	0123456789	0123456789	0123456789	1)	818 to 819	0332 to 0333																															
		Target value	Machine feed val	Item	ax.1	ax.2	ax.3	ax.4	Note																																																																																				
	Axis1	01234567890	01234567890	In speed cont. flag	0	0	0	0	0:Not in 1:In																																																																																				
	Axis2	01234567890	01234567890	In speed chg.proc.	0	0	0	0	0:Not in 1:In																																																																																				
	Axis3	01234567890	01234567890																																																																																										
	Axis4	01234567890	01234567890																																																																																										
		Target spd	Current spd	Feedrate																																																																																									
	Axis1	0123456789	0123456789	0123456789																																																																																									
	Axis2	0123456789	0123456789	0123456789																																																																																									
	Axis3	0123456789	0123456789	0123456789																																																																																									
	Axis4	0123456789	0123456789	0123456789																																																																																									
			918 to 919	0396 to 0397																																																																																									
			1018 to 1019	03FA to 03FB																																																																																									
			1118 to 1119	045E to 045F																																																																																									
		2)	802 to 803	0322 to 0323																																																																																									
			902 to 903	0386 to 0387																																																																																									
			1002 to 1003	03EA to 03EB																																																																																									
			1102 to 1103	044E to 044F																																																																																									
		3)	820 to 821	0334 to 0335																																																																																									
			920 to 921	0398 to 0399																																																																																									
			1020 to 1021	03FC to 03FD																																																																																									
		1120 to 1121	0460 to 0461																																																																																										
	4)	810 to 811	032A to 032B																																																																																										
		910 to 911	038E to 038F																																																																																										
		1010 to 1011	03F2 to 03F3																																																																																										
		1110 to 1111	0456 to 0457																																																																																										
	5)	812 to 813	032C to 032D																																																																																										
		912 to 913	0390 to 0391																																																																																										
		1012 to 1013	03F4 to 03F5																																																																																										
		1112 to 1113	0458 to 0459																																																																																										
	6)	830, 930, 1030, 1130	033E, 03A2, 0406, 046A																																																																																										
	7)	831, 931, 1031, 1131	033F, 03A3, 0407, 046B																																																																																										
<p>QD75P/QD75D Axis monitor data-2</p> <table border="1"> <thead> <tr> <th colspan="4">Special start data</th> <th colspan="4">Special start repetition counter</th> </tr> <tr> <th>Axis</th> <th>Instr. code</th> <th>Instr. para</th> <th>Data No.</th> <th>Axis1</th> <th>Axis2</th> <th>Axis3</th> <th>Axis4</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>01</td> <td>012</td> <td>012</td> <td>012</td> <td>012</td> <td>012</td> <td>012</td> </tr> <tr> <td>2</td> <td>01</td> <td>012</td> <td>012</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>3</td> <td>01</td> <td>012</td> <td>012</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td>01</td> <td>012</td> <td>012</td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="4">Control system repetition counter</th> </tr> <tr> <th>Axis1</th> <th>Axis2</th> <th>Axis3</th> <th>Axis4</th> </tr> </thead> <tbody> <tr> <td>0123</td> <td>0123</td> <td>0123</td> <td>0123</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="4">Data being executed</th> <th>Previous position</th> </tr> <tr> <th>Axis</th> <th>Instr. code</th> <th>Pos. data number</th> <th>Block No.</th> <th>Position</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>012</td> <td>0123</td> <td>012</td> <td>0123</td> </tr> <tr> <td>2</td> <td>012</td> <td>0123</td> <td>012</td> <td>0123</td> </tr> <tr> <td>3</td> <td>012</td> <td>0123</td> <td>012</td> <td>0123</td> </tr> <tr> <td>4</td> <td>012</td> <td>0123</td> <td>012</td> <td>0123</td> </tr> </tbody> </table>	Special start data				Special start repetition counter				Axis	Instr. code	Instr. para	Data No.	Axis1	Axis2	Axis3	Axis4	1	01	012	012	012	012	012	012	2	01	012	012					3	01	012	012					4	01	012	012					Control system repetition counter				Axis1	Axis2	Axis3	Axis4	0123	0123	0123	0123	Data being executed				Previous position	Axis	Instr. code	Pos. data number	Block No.	Position	1	012	0123	012	0123	2	012	0123	012	0123	3	012	0123	012	0123	4	012	0123	012	0123	1)	827, 927, 1027, 1127	033B, 039F, 0403, 0467
	Special start data				Special start repetition counter																																																																																								
	Axis	Instr. code	Instr. para	Data No.	Axis1	Axis2	Axis3	Axis4																																																																																					
	1	01	012	012	012	012	012	012																																																																																					
	2	01	012	012																																																																																									
	3	01	012	012																																																																																									
	4	01	012	012																																																																																									
	Control system repetition counter																																																																																												
	Axis1	Axis2	Axis3	Axis4																																																																																									
	0123	0123	0123	0123																																																																																									
Data being executed				Previous position																																																																																									
Axis	Instr. code	Pos. data number	Block No.	Position																																																																																									
1	012	0123	012	0123																																																																																									
2	012	0123	012	0123																																																																																									
3	012	0123	012	0123																																																																																									
4	012	0123	012	0123																																																																																									
	2)	828, 928, 1028, 1128	033C, 03A0, 0404, 0468																																																																																										
	3)	829, 929, 1029, 1129	033D, 03A1, 0405, 0469																																																																																										
	4)	834, 934, 1034, 1134	0342, 03A6, 040A, 046E																																																																																										
	5)	835, 936, 1036, 1135	0343, 03A8, 040C, 046F																																																																																										
	6)	836, 936, 1036, 1136	0344, 03A8, 040C, 0470																																																																																										
	7)	837, 937, 1037, 1137	0345, 03A9, 040D, 0471																																																																																										
	8)	832, 932, 1032, 1132	0340, 03A4, 0408, 046C																																																																																										
	9)	833, 933, 1033, 1133	0341, 03A5, 0409, 046D																																																																																										
	-	---	---																																																																																										

Screen Image	No.	Buffer memory address																																							
		dec.	hex.																																						
<p>QD75P/QD75D OPR</p> <p>Axis Travel after NFD DN</p> <table border="1"> <tr><td>1</td><td>01234567890</td></tr> <tr><td>2</td><td>01234567890</td></tr> <tr><td>3</td><td>01234567890</td></tr> <tr><td>4</td><td>01234567890</td></tr> </table> <p>($\mu\text{m}:\times 10^{-1}$) (inch:$\times 10^{-4}$) (degree:$\times 10^{-2}$) (pulse:$\times 1$)</p> <table border="1"> <tr><th>Axis</th><th>Torque limit</th><th>Zero</th><th>Near</th><th>Upper</th><th>Lower</th></tr> <tr><td>1</td><td>012 (%)</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>2</td><td>012 (%)</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>3</td><td>012 (%)</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>4</td><td>012 (%)</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> </table>	1	01234567890	2	01234567890	3	01234567890	4	01234567890	Axis	Torque limit	Zero	Near	Upper	Lower	1	012 (%)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	2	012 (%)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	3	012 (%)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	4	012 (%)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	1)	824 to 825	0338 to 0339
	1	01234567890																																							
	2	01234567890																																							
	3	01234567890																																							
	4	01234567890																																							
	Axis	Torque limit	Zero	Near	Upper	Lower																																			
1	012 (%)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																				
2	012 (%)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																				
3	012 (%)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																				
4	012 (%)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																				
		924 to 925	039C to 039D																																						
		1024 to 1025	0400 to 0401																																						
		1124 to 1125	0464 to 0465																																						
	2)	826, 926, 1026, 1126	033A, 039E, 0402, 0466																																						
	3)																																								
	4)	816, 916,	0330, 0394,																																						
	5)	1016, 1116	03F8, 045C																																						
	6)																																								
	-	---	---																																						
<p>QD75P/QD75D Speed-position control</p> <p>SPSC positioning amount</p> <table border="1"> <tr><th>Axis</th><th>Item</th><th>AX.1</th><th>AX.2</th><th>AX.3</th><th>AX.4</th></tr> <tr><td>Axis1</td><td>Speed-position switching latch</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>Axis2</td><td>In speed control</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>Axis3</td><td>Speed-position switching enable</td><td>0</td><td>0</td><td>0</td><td>0</td></tr> <tr><td>Axis4</td><td></td><td>0:Disable 1:Enable</td><td></td><td></td><td></td></tr> </table> <p>($\mu\text{m}:\times 10^{-1}$) (degree):$\times 10^{-5}$ (inch):$\times 10^{-5}$ (pulse):$\times 1$)</p> <p>SPSC movement amount change register</p> <table border="1"> <tr><td>Axis1</td><td>0123456789</td><td>Axis2</td><td>0123456789</td></tr> <tr><td>Axis3</td><td>0123456789</td><td>Axis4</td><td>0123456789</td></tr> </table> <p>Setting range 0 to 2147483647 ($\mu\text{m}:\times 10^{-1}$) (inch):$\times 10^{-5}$ (degree):$\times 10^{-5}$ (pulse):$\times 1$)</p>	Axis	Item	AX.1	AX.2	AX.3	AX.4	Axis1	Speed-position switching latch	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Axis2	In speed control	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Axis3	Speed-position switching enable	0	0	0	0	Axis4		0:Disable 1:Enable				Axis1	0123456789	Axis2	0123456789	Axis3	0123456789	Axis4	0123456789	1)	814 to 815	032E to 032F
	Axis	Item	AX.1	AX.2	AX.3	AX.4																																			
	Axis1	Speed-position switching latch	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																			
	Axis2	In speed control	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																			
	Axis3	Speed-position switching enable	0	0	0	0																																			
	Axis4		0:Disable 1:Enable																																						
	Axis1	0123456789	Axis2	0123456789																																					
	Axis3	0123456789	Axis4	0123456789																																					
			914 to 915	0392 to 0393																																					
			1014 to 1015	03F6 to 03F7																																					
			1114 to 1115	045A to 045B																																					
		2)	1526 to 1527	05F6 to 05F7																																					
		1626 to 1627	065A to 065B																																						
		1726 to 1727	06BE to 06BF																																						
	3)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D																																						
	4)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D																																						
	5)	1528, 1628, 1728, 1828	05F8, 065C, 06C0, 0724																																						
<p>QD75P/QD75D Position-speed control</p> <p>PSSC speed change register</p> <table border="1"> <tr><td>Axis1</td><td>0123456789</td><td>Axis2</td><td>0123456789</td></tr> <tr><td>Axis3</td><td>0123456789</td><td>Axis4</td><td>0123456789</td></tr> </table> <p>Setting range 0 to 2000000000 (mm/min):$\times 10^{-6}$ (inch/min):$\times 10^{-8}$ (degree/min):$\times 10^{-8}$ 0 to 1000000 (pulse/sec):$\times 1$)</p> <table border="1"> <tr><th>Item</th><th>AX.1</th><th>AX.2</th><th>AX.3</th><th>AX.4</th></tr> <tr><td>Position-speed switching latch</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>In speed control</td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td><td><input type="checkbox"/></td></tr> <tr><td>Position-speed switching enable</td><td>0</td><td>0</td><td>0</td><td>0</td></tr> <tr><td></td><td>0:Disable 1:Enable</td><td></td><td></td><td></td></tr> </table>	Axis1	0123456789	Axis2	0123456789	Axis3	0123456789	Axis4	0123456789	Item	AX.1	AX.2	AX.3	AX.4	Position-speed switching latch	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	In speed control	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Position-speed switching enable	0	0	0	0		0:Disable 1:Enable				1)	1530 to 1531	05FA to 05FB					
	Axis1	0123456789	Axis2	0123456789																																					
	Axis3	0123456789	Axis4	0123456789																																					
	Item	AX.1	AX.2	AX.3	AX.4																																				
	Position-speed switching latch	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																				
	In speed control	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>																																				
	Position-speed switching enable	0	0	0	0																																				
		0:Disable 1:Enable																																							
			1630 to 1631	065E to 065F																																					
			1730 to 1731	06C2 to 06C3																																					
			1830 to 1831	0726 to 0727																																					
		2)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D																																					
	3)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D																																						
	4)	1532, 1632, 1732, 1832	05FC, 0660, 06C4, 0728																																						
	-	---	---																																						

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS

10 ERROR MESSAGES FOR SYSTEM MONITOR

11 OPERATING SP MODULE MONITOR

12 OPERATING SP MODULE MONITOR SCREEN

13 OPERATING I/O MODULE MONITOR SCREENS

14 ERROR MESSAGES FOR SP MODULE MONITOR

15 OPERATING NET-WORK MONITOR

16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address	
			dec.	hex.
<p>The screenshot shows two main sections: 'New current value' and 'New speed value'. Each section has a table for axis parameters (Axis1-4) and a table for step mode settings. The 'New current value' section includes settings for Torq.boost, Step mode, Step valid flag, and Step start information. The 'New speed value' section includes settings for Skip command and Use ext. command. Brackets on the left indicate that the first four rows of the screenshot correspond to rows 1-4 of the table, and the next four rows correspond to rows 5-8.</p>		1)	1506 to 1507	05E2 to 05E3
			1606 to 1607	0646 to 0647
			1706 to 1707	06AA to 06AB
			1806 to 1807	070E to 070F
		2)	1514 to 1515	05EA to 05EB
			1614 to 1615	064E to 064F
			1714 to 1715	06B2 to 06B3
			1814 to 1815	0716 to 0717
3)	1513, 1613, 1713, 1813	05E9, 064D, 06B1, 0715		
4)	1544, 1644, 1744, 1844	0608, 066C, 06D0, 0734		
5)	1545, 1645, 1745, 1845	0609, 066D, 06D1, 0735		
6)	1546, 1646, 1746, 1846	060A, 066E, 06D2, 0736		
7)	1547, 1647, 1747, 1847	060B, 066F, 06D3, 0737		
8)	1505, 1605, 1705, 1805	05E1, 0645, 06A9, 070D		

Screen Image	No.	Buffer memory address	
		dec.	hex.

QD75P/QD75D Axis control data-2									
Item	Axis1	Axis2	Axis3	Axis4	Item	Axis1	Axis2	Axis3	Axis4
1) Start No.	0123	0123	0123	0123	New acc time	0123456	0123456	0123456	0123456
2) Starting point No.	01	01	01	01	New dec time	0123456	0123456	0123456	0123456
3) Axis error reset	0	0	0	0	IRQ in locus OP	0	0	0	0
4) Restart command	0	0	0	0	DPR req flag OFF	0	0	0	0
5) M code OFF request	0	0	0	0	MPG 1/P mag.	0123	0123	0123	0123
6) A/D time chg in SPD chg, ON/OFF	0	0	0	0	MPG enable	0	0	0	0
7) Speed change request	0	0	0	0	New Torq value	0123	0123	0123	0123

1)	1500, 1600, 1700, 1800	05DC, 0640, 06A4, 0708
2)	1501, 1601, 1701, 1801	05DD, 0641, 06A5, 0709
3)	1502, 1602, 1702, 1802	05DE, 0642, 6A6, 070A
4)	1503, 1603, 1703, 1803	05DF, 0643, 06A7, 070B
5)	1504, 1604, 1704, 1804	05E0, 0644, 06A8, 070C
6)	1512, 1612, 1712, 1812	05E8, 064C, 06B0, 0714
7)	1516, 1616, 1716, 1816	05EC, 0650, 06B4, 0718
8)	1508 to 1509	05E4 to 05E5
	1608 to 1609	0648 to 0649
	1708 to 1709	06AC to 06AD
9)	1808 to 1809	0710 to 0711
	1510 to 1511	05E6 to 05E7
	1610 to 1611	064A to 064B
10)	1710 to 1711	06AE to 06AF
	1810 to 1811	0712 to 0713
11)	1520, 1620, 1720, 1820	05F0, 0654, 06B8, 071C
12)	1521, 1621, 1721, 1821	05F1, 0655, 06B9, 071D
12)	1522 to 1523	05F2 to 05F3
	1622 to 1623	0656 to 0657
	1722 to 1723	06BA to 06BB
	1822 to 1823	071E to 071F
13)	1524, 1624, 1724, 1824	05F4, 0658, 06BC, 0720
14)	1525, 1625, 1725, 1825	05F5, 0659, 06BD, 0721
1)	1538, 1638, 1738, 1838	0602, 0666, 06CA, 072E
2)	1548, 1648, 1748, 1848	060C, 0670, 06D4, 0738
3)	1549, 1649, 1749, 1849	060D, 0671, 06D5, 0739
4)	1550, 1650, 1750, 1850	060E, 0672, 06D6, 073A
5)	1540, 1640, 1740, 1840, 1541, 1641, 1741, 1841, 1542, 1642, 1742, 1842, 1543, 1643, 1743, 1843	0604, 0668, 06CC, 0730, 0605, 0669, 06CD, 0731, 0606, 066A, 06CE, 0732, 0607, 066B, 06CF, 0733

QD75P/QD75D Axis control data-3									
Item	Axis1	Axis2	Axis3	Axis4	Simultaneous starting axis start data				
1) Pos. change	0	0	0	0	Data No.	Axis1	Axis2	Axis3	Axis4
2) Teaching data selection	0	0	0	0	Axis1	012	012	012	012
3) Teaching positioning data No.	012	012	012	012	Axis2	012	012	012	012
4) ABS direction in degrees	0	0	0	0	Axis3	012	012	012	012
					Axis4	012	012	012	012

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address			
			dec.	hex.		
		1)	1517, 1617, 1717, 1817	05ED, 0651, 06B5, 0719		
		2)	1518 to 1519	05EE to 05EF		
			1618 to 1619	0652 to 0653		
			1718 to 1719	06B6 to 06B7		
		3)	1818 to 1819	071A to 071B		
			1534 to 1535	05FE to 05FF		
			1634 to 1635	0662 to 0663		
		4)	1734 to 1735	06C6 to 06C7		
			1834 to 1835	072A to 072B		
			1536 to 1537	0600 to 0601		
		4)	1636 to 1637	0664 to 0665		
			1736 to 1737	06C8 to 06C9		
			1836 to 1837	072C to 072D		
				1)	1212 to 1292	04BC to 050C
				-	---	---
						1)
2)	1358 to 1421					054E to 058D
-	---					---

Screen Image	No.	Buffer memory address																																																																																																																																																																																																																																																																																																																																																																																	
		dec.	hex.																																																																																																																																																																																																																																																																																																																																																																																
<div style="border: 1px solid black; padding: 5px;"> <p>QD75P/QD75D Positioning data</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="12">Axis1</th> <th colspan="12">Axis3</th> </tr> <tr> <th>No.</th><th>Part</th><th>Int</th><th>Cont</th><th>Acc</th><th>Dec.</th><th>Dwell</th><th>Mcode</th> <th>No.</th><th>Part</th><th>Int</th><th>Cont</th><th>Acc</th><th>Dec.</th><th>Dwell</th><th>Mcode</th> </tr> <tr> <th colspan="4">address</th><th colspan="4">Arc address</th><th colspan="4">Instr. speed</th> <th colspan="4">address</th><th colspan="4">Arc address</th><th colspan="4">Instr. speed</th> </tr> </thead> <tbody> <tr> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> </tr> <tr> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> </tr> <tr> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> </tr> <tr> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> </tr> <tr> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> </tr> <tr> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="12">Axis2</th> <th colspan="12">Axis4</th> </tr> <tr> <th>No.</th><th>Part</th><th>Int</th><th>Cont</th><th>Acc</th><th>Dec.</th><th>Dwell</th><th>Mcode</th> <th>No.</th><th>Part</th><th>Int</th><th>Cont</th><th>Acc</th><th>Dec.</th><th>Dwell</th><th>Mcode</th> </tr> <tr> <th colspan="4">address</th><th colspan="4">Arc address</th><th colspan="4">Instr. speed</th> <th colspan="4">address</th><th colspan="4">Arc address</th><th colspan="4">Instr. speed</th> </tr> </thead> <tbody> <tr> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> </tr> <tr> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> </tr> <tr> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> </tr> <tr> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> </tr> <tr> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> <td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01</td><td>01234</td><td>01234</td> </tr> <tr> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> <td colspan="4">01234567890</td><td colspan="4">01234567890</td><td colspan="4">0123456789</td> </tr> </tbody> </table> </div>	Axis1												Axis3												No.	Part	Int	Cont	Acc	Dec.	Dwell	Mcode	No.	Part	Int	Cont	Acc	Dec.	Dwell	Mcode	address				Arc address				Instr. speed				address				Arc address				Instr. speed				01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234	01234567890				01234567890				0123456789				01234567890				01234567890				0123456789				01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234	01234567890				01234567890				0123456789				01234567890				01234567890				0123456789				01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234	01234567890				01234567890				0123456789				01234567890				01234567890				0123456789				Axis2												Axis4												No.	Part	Int	Cont	Acc	Dec.	Dwell	Mcode	No.	Part	Int	Cont	Acc	Dec.	Dwell	Mcode	address				Arc address				Instr. speed				address				Arc address				Instr. speed				01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234	01234567890				01234567890				0123456789				01234567890				01234567890				0123456789				01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234	01234567890				01234567890				0123456789				01234567890				01234567890				0123456789				01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234	01234567890				01234567890				0123456789				01234567890				01234567890				0123456789				1)	2000 to 25999	07D0 to 658F
	Axis1												Axis3																																																																																																																																																																																																																																																																																																																																																																						
No.	Part	Int	Cont	Acc	Dec.	Dwell	Mcode	No.	Part	Int	Cont	Acc	Dec.	Dwell	Mcode																																																																																																																																																																																																																																																																																																																																																																				
address				Arc address				Instr. speed				address				Arc address				Instr. speed																																																																																																																																																																																																																																																																																																																																																															
01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234																																																																																																																																																																																																																																																																																																																																																																				
01234567890				01234567890				0123456789				01234567890				01234567890				0123456789																																																																																																																																																																																																																																																																																																																																																															
01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234																																																																																																																																																																																																																																																																																																																																																																				
01234567890				01234567890				0123456789				01234567890				01234567890				0123456789																																																																																																																																																																																																																																																																																																																																																															
01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234																																																																																																																																																																																																																																																																																																																																																																				
01234567890				01234567890				0123456789				01234567890				01234567890				0123456789																																																																																																																																																																																																																																																																																																																																																															
Axis2												Axis4																																																																																																																																																																																																																																																																																																																																																																							
No.	Part	Int	Cont	Acc	Dec.	Dwell	Mcode	No.	Part	Int	Cont	Acc	Dec.	Dwell	Mcode																																																																																																																																																																																																																																																																																																																																																																				
address				Arc address				Instr. speed				address				Arc address				Instr. speed																																																																																																																																																																																																																																																																																																																																																															
01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234																																																																																																																																																																																																																																																																																																																																																																				
01234567890				01234567890				0123456789				01234567890				01234567890				0123456789																																																																																																																																																																																																																																																																																																																																																															
01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234																																																																																																																																																																																																																																																																																																																																																																				
01234567890				01234567890				0123456789				01234567890				01234567890				0123456789																																																																																																																																																																																																																																																																																																																																																															
01	01	01	01	01	01	01234	01234	01	01	01	01	01	01	01234	01234																																																																																																																																																																																																																																																																																																																																																																				
01234567890				01234567890				0123456789				01234567890				01234567890				0123456789																																																																																																																																																																																																																																																																																																																																																															
	-	---	---																																																																																																																																																																																																																																																																																																																																																																																

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

12.32 QD75M Module Monitor

Screen Image		No.	Buffer memory address	
			dec.	hex.
<p>The screenshot shows the 'QD75M Operation Monitor' interface. It is divided into several sections: <ul style="list-style-type: none"> Axis Current feed rate: A table with 4 rows (Axis 1-4) showing current feed rate and feed rate values. unit: A table showing units for each axis, such as (mm):*10⁻³, (degree):*10⁻⁵, (inch):*10⁻⁵, and (pulse):*1. Axis Status: A table showing status for each axis, including 'Unconnection/Amp. power OFF', 'Speed cont. in speed-pos.', and 'Absolute position restore'. Control system: A table with columns for 'Control system', 'Int. Axis', 'Acc. time', and 'Per. time'. Rows include ABS2, FEED4, LOOP, and LEND. Numbered callouts 1) through 8) point to various data points in the interface. </p>	1)	800 to 801	0320 to 0321	
	900 to 901	0384 to 0385		
	1000 to 1001	03E8 to 03E9		
	1100 to 1101	044C to 044D		
	2)	812 to 813	032C to 032D	
	912 to 913	0390 to 0391		
	1012 to 1013	03F4 to 03F5		
	1112 to 1113	0458 to 0459		
	3)	809, 909, 1009, 1109	0329, 038D, 03F1, 0455	
	4)	806, 906, 1006, 1106	0326, 038A, 03EE, 0452	
	5)	807, 907, 1007, 1107	0327, 038B, 03EF, 0453	
	6)	808, 908, 1008, 1108	0328, 038C, 03F0, 0454	
7)	829, 929, 1029, 1129	033D, 03A1, 0405, 0469		
8) to 12)	838, 938, 1038, 1138	0346, 03AA, 040E, 0472		
1)	---	---		
<p>The screenshot shows the 'QD75M Input/Output Monitor' interface. It is divided into two main sections, Z and Y, each with two columns of status indicators: <ul style="list-style-type: none"> Z Section: <ul style="list-style-type: none"> 00 QD75 READY (08 Axis1 Error) 01 Synchronization (09 Axis2 Error) 02 (0A Axis3 Error) 03 (0B Axis4 Error) 04 Axis1 M code DN (0C Axis1 BUSY) 05 Axis2 M code DN (0D Axis2 BUSY) 06 Axis3 M code DN (0E Axis3 BUSY) 07 Axis4 M code DN (0F Axis4 BUSY) 10 Axis1 Started (18) 11 Axis2 Started (19) 12 Axis3 Started (1A) 13 Axis4 Started (1B) 14 Axis1 Pos. done (1C) 15 Axis2 Pos. done (1D) 16 Axis3 Pos. done (1E) 17 Axis4 Pos. done (1F) Y Section: <ul style="list-style-type: none"> 00 PLC READY (08 Axis1 FWD JOG) 01 All Axis Servo ON (09 Axis1 RVS JOG) 02 (0A Axis2 FWD JOG) 03 (0B Axis2 RVS JOG) 04 Axis1 stop (0C Axis3 FWD JOG) 05 Axis2 stop (0D Axis3 RVS JOG) 06 Axis3 stop (0E Axis4 FWD JOG) 07 Axis4 stop (0F Axis4 RVS JOG) 10 Axis1 Pos. start (18) 11 Axis2 Pos. start (19) 12 Axis3 Pos. start (1A) 13 Axis4 Pos. start (1B) 14 Ax1 Exe prohibit (1C) 15 Ax2 Exe prohibit (1D) 16 Ax3 Exe prohibit (1E) 17 Ax4 Exe prohibit (1F) A callout 1) points to the Z section. </p>	-	---	---	

Screen Image		No.	Buffer memory address			
			dec.	hex.		
	<p>1) Unit setting</p> <p>2) Movement amount per pulse</p> <p>3) Unit magnification</p>	1)	0, 150, 300, 450	0000, 0096, 012C, 01C2		
		2)	2 to 3, 152 to 153, 302 to 303, 452 to 453	0002 to 0003, 0098 to 0099, 012E to 012F, 01C4 to 01C7		
		3)	1, 151, 301, 451	0001, 0097, 0012D, 01C3		
		4)	4 to 5, 154 to 155, 304 to 305, 454 to 455	0004 to 0005, 009A to 009B, 0130 to 0131, 01C6 to 01C7		
	<p>1) Speed limit value</p> <p>2) Acceleration time</p>	1)	10 to 11, 160 to 161, 310 to 311, 460 to 461	000A to 000B, 00A0 to 00A1, 0136 to 0137, 01CC to 01CD		
		2)	12 to 13, 162 to 163, 312 to 313, 462 to 463	000C to 000D, 00A2 to 00A3, 0138 to 0139, 01CE to 01CF		
		3)	14 to 15, 164 to 165, 314 to 315, 464 to 465	000E to 000F, 00A4 to 00A5, 013A to 013B, 01D0 to 01D1		
		-	---	---		
			<p>1) Backlash compensation amount</p> <p>2) Software stroke upper limit value</p>	1)	17, 167, 317, 467	0011, 00A7, 013D, 01D3
				2)	18 to 19, 168 to 169, 318 to 319, 468 to 469	0012 to 0013, 00A8 to 00A9, 013E to 013F, 01D4 to 01D5
3)	20 to 21, 170 to 171, 320 to 321, 470 to 471			0014 to 0015, 00AA to 00AB, 0140 to 0141, 01D6 to 01D7		
4)	22, 172, 322, 472			0016, 00AC, 0142, 01D8		
5)	23, 173, 323, 473			0017, 00AD, 0143, 01D9		
6)	26, 176, 326, 476			001A, 00B0, 0146, 01DC		

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS

10 ERROR MESSAGES FOR SYSTEM MONITOR

11 OPERATING SP MODULE MONITOR

12 OPERATING SP MODULE MONITOR SCREEN

13 OPERATING I/O MODULE MONITOR SCREENS

14 ERROR MESSAGES FOR SP MODULE MONITOR

15 OPERATING NET-WORK MONITOR

16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address	
			dec.	hex.
		1)	27, 177, 327, 477	001B, 00B1, 0147, 01DD
		2)	28, 178, 328, 478	001C, 00B2, 0148, 01DE
		3)	29, 179, 329, 479	001D, 00B3, 0149, 01DF
		4)	24 to 25	0018 to 0019
			174 to 175	00AE to 00AF
			324 to 325	0144 to 0145
		5)	30, 180, 330, 480	001E, 00B4, 014A, 01E0
6)	34, 184, 334, 484	0022, 00B8, 014E, 01E4		
7)	31, 181, 331, 481	001F, 00B5, 014B, 01E1		
		1)	36 to 41	0024 to 0029
			186 to 191	00BA to 00BF
			336 to 341	0150 to 0155
		2)	486 to 491	01E6 to 01EB
			42 to 47	002A to 002F
			192 to 197	00C0 to 00C5
		3)	342 to 347	0156 to 015B
			492 to 496	01EC to 01F0
			48 to 49	0030 to 0031
		4)	198 to 199	00C6 to 00C7
348 to 349	015C to 015D			
5)	498 to 499	01F2 to 01F3		
	50, 200, 350, 500	0032, 00C8, 015E, 01F4		
5)	51, 501, 351, 501	0033, 01F5, 015F, 01F5		

Screen Image	No.	Buffer memory address	
		dec.	hex.
	1)	52, 202, 352, 502	0034, 00CA, 0160, 01F6
	2)	53, 203, 353, 503	0035, 00CB, 0161, 01F7
	3)	56, 206, 356, 506	0038, 00CE, 0164, 01FA
	4)	57, 207, 357, 507	0039, 00CF, 0165, 01FB
	5)	58, 208, 358, 508	003A, 00D0, 0166, 01FC
	6)	54 to 55, 204 to 205, 354 to 355, 504 to 505	0036 to 0037, 00CC to 00CD, 0162 to 0163, 01F8 to 01F9
	7)	59, 209, 359, 509	003B, 00D1, 0167, 01FD
	8)	60 to 61, 210 to 211, 360 to 361	003C to 003D, 00D2 to 00D3, 0168 to 0169
	9)	62, 212, 362, 512	003E, 00D4, 016A, 0200
	10)	64 to 65, 214 to 215, 364 to 365, 514 to 515	0040 to 0041, 00D6 to 00D7, 016C to 016D, 0202 to 0203
	1)	79, 229, 379, 529	004F, 00E5, 017B, 0211
	2)	82, 232, 382, 532	0052, 00E8, 017E, 0214
	3)	83, 233, 383, 533	0053, 00E9, 017F, 0215
	4)	86, 236, 386, 536	0056, 00EC, 0182, 0218
	5)	80 to 81, 230 to 231	0050 to 0051, 00E6 to 00E7
	6)	84 to 85, 234 to 235, 384 to 385	0054 to 0055, 00EA to 00EB, 0180 to 0181
	7)	88, 238, 388, 538	0058, 00EE, 0184, 021A
	8)	89, 239, 389, 539	0059, 00EF, 0185, 021B

OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS

ERROR MESSAGES FOR SYSTEM MONITOR

OPERATING SP MODULE MONITOR

OPERATING SP MODULE MONITOR SCREEN

OPERATING I/O MODULE MONITOR SCREENS

ERROR MESSAGES FOR SP MODULE MONITOR

OPERATING NET-WORK MONITOR

SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address			
			dec.	hex.		
		1)	70, 220, 370, 520	0046, 00DC, 0172, 0208		
		2)	71, 221, 371, 521	0047, 00DD, 0173, 0209		
		3)	78, 228, 378, 528	004E, 00E4, 017A, 0210		
		4)	72 to 73	0048 to 0049		
			222 to 223	00DE to 00DF		
			372 to 373	0174 to 0175		
		5)	522 to 523	020A to 020B		
			74 to 75	004A to 004B		
			224 to 225	00E0 to 00E1		
		6)	374 to 375	0176 to 0177		
			524 to 525	020C to 020D		
			76 to 77	004C to 004D		
			226 to 227	00E2 to 00E3		
		6)	376 to 377	0178 to 0179		
			526 to 527	020E to 020F		
			-	---	---	
				1)	816, 916, 1016, 1116	0330, 0394, 03F8, 045C
				2)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
-	---			---		
-	---			---		

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>1) 2) 6) 7)</p> <p>3) 4) 5)</p>	1)	818 to 819	0332 to 0333
		918 to 919	0396 to 0397
		1018 to 1019	03FA to 03FB
		1118 to 1119	045E to 045F
	2)	802 to 803	0322 to 0323
		902 to 903	0386 to 0387
		1002 to 1003	03EA to 03EB
		1102 to 1103	044E to 044F
	3)	820 to 821	0334 to 0335
		920 to 921	0398 to 0399
		1020 to 1021	03FC to 03FD
		1120 to 1121	0460 to 0461
	4)	810 to 811	032A to 032B
		910 to 911	038E to 038F
	1010 to 1011	03F2 to 03F3	
	1110 to 1111	0456 to 0457	
5)	812 to 813	032C to 032D	
	912 to 913	0390 to 0391	
	1012 to 1013	03F4 to 03F5	
	1112 to 1113	0458 to 0459	
6)	830, 930, 1030, 1130	033E, 03A2, 0406, 046A	
7)	831, 931, 1031, 1131	033F, 03A3, 0407, 046B	
<p>8) 9)</p> <p>1) 4) 5) 2) 6) 7) 3)</p>	1)	827, 927, 1027, 1127	033B, 039F, 0403, 0467
	2)	828, 928, 1028, 1128	033C, 03A0, 0404, 0468
	3)	829, 929, 1029, 1129	033D, 03A1, 0405, 0469
	4)	834, 934, 1034, 1134	0342, 03A6, 040A, 046E
	5)	835, 936, 1036, 1135	0343, 03A8, 040C, 046F
	6)	836, 936, 1036, 1136	0344, 03A8, 040C, 0470
	7)	837, 937, 1037, 1137	0345, 03A9, 040D, 0471
	8)	832, 932, 1032, 1132	0340, 03A4, 0408, 046C
	9)	833, 933, 1033, 1133	0341, 03A5, 0409, 046D
	-	---	---

9
OPERATION OF THE
VARIOUS SYSTEM
MONITOR SCREENS

10
ERROR MESSAGES
FOR SYSTEM MONI-
TOR

11
OPERATING SP
MODULE MONITOR

12
OPERATING SP
MODULE MONITOR
SCREEN

13
OPERATING I/O
MODULE MONITOR
SCREENS

14
ERROR MESSAGES
FOR SP MODULE
MONITOR

15
OPERATING NET-
WORK MONITOR

16
SWITCHING THE
NETWORK MONI-
TOR SCREENS

Screen Image			No.	Buffer memory address	
				dec.	hex.
			1)	848 to 849, 948 to 949, 1048 to 1049, 1148 to 1149	0350 to 0351, 03B4 to 03B5, 0418 to 0419, 047C to 047D
			2)	850 to 851, 950 to 951, 1050 to 1051, 1150 to 1151	0352 to 0353, 03B6 to 03B7, 041A to 041B, 047E to 047F
			3)	852 to 853, 952 to 953, 1052 to 1053, 1152 to 1153	0354 to 0355, 03B8 to 03B9, 041C to 041D, 0480 to 0481
			4)	854 to 855, 954 to 955, 1054 to 1055, 1154 to 1155	0356 to 0357, 03BA to 03BB, 041E to 041F, 0482 to 0483
			5)	856, 956, 1056, 1156	0358, 03BC, 0420, 0484
			6)	857, 957, 1057, 1157	0359, 03BD, 0421, 0485
				858, 958, 1058, 1158	035A, 03BE, 0422, 0486
859, 959, 1059, 1159	035B, 03BF, 0423, 0487				
860, 960, 1060, 1160	035C, 03C0, 0424, 0488				
7)	861, 961, 1061, 1161	035D, 03C1, 0425, 0489			
	862, 962, 1062, 1162	035E, 03C2, 0426, 048A			
	863, 963, 1063, 1163	035F, 03C2, 0427, 048B			
864 to 869, 964 to 969, 1064 to 1069, 1164 to 1169	0360 to 0365, 03C4 to 03C9, 0428 to 042D, 048C to 0491				

Screen Image	No.	Buffer memory address																																																																																												
		dec.	hex.																																																																																											
<p>QD75M Axis monitor data-4</p> <p>Parameter error No. (BIT 0:OK 1:ERROR)</p> <table border="1"> <thead> <tr> <th>Axis1</th> <th>Axis2</th> </tr> </thead> <tbody> <tr> <td>0110110110110110</td> <td>0110110110110110</td> </tr> </tbody> </table> <p>[Servo Status]</p> <table border="1"> <thead> <tr> <th>Item</th> <th>AX1</th> <th>AX2</th> <th>AX3</th> <th>AX4</th> </tr> </thead> <tbody> <tr> <td>Ready ON</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>Servo ON</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>Zero point passed</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>In-position</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>Zero speed</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>Torque limit</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>Servo alarm</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>Servo warning</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> </tbody> </table> <p>Parameter error No. (BIT 0:OK 1:ERROR)</p> <table border="1"> <thead> <tr> <th>Axis1</th> <th>Axis2</th> </tr> </thead> <tbody> <tr> <td>0110110110110110</td> <td>0110110110110110</td> </tr> </tbody> </table> <p>Item</p> <table border="1"> <thead> <tr> <th>Item</th> <th>Axis1</th> <th>Axis2</th> <th>Axis3</th> <th>Axis4</th> </tr> </thead> <tbody> <tr> <td>Regenerative load ratio</td> <td>012</td> <td>012</td> <td>012</td> <td>012</td> </tr> <tr> <td>Actual load ratio</td> <td>012</td> <td>012</td> <td>012</td> <td>012</td> </tr> <tr> <td>Peak load ratio</td> <td>012</td> <td>012</td> <td>012</td> <td>012</td> </tr> </tbody> </table>	Axis1	Axis2	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	Item	AX1	AX2	AX3	AX4	Ready ON	●	●	●	●	Servo ON	●	●	●	●	Zero point passed	●	●	●	●	In-position	●	●	●	●	Zero speed	●	●	●	●	Torque limit	●	●	●	●	Servo alarm	●	●	●	●	Servo warning	●	●	●	●	Axis1	Axis2	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	0110110110110110	Item	Axis1	Axis2	Axis3	Axis4	Regenerative load ratio	012	012	012	012	Actual load ratio	012	012	012	012	Peak load ratio	012	012	012	012	1)	870, 970, 1070, 1170	0366, 03CA, 042E, 0492
	Axis1	Axis2																																																																																												
	0110110110110110	0110110110110110																																																																																												
	0110110110110110	0110110110110110																																																																																												
	0110110110110110	0110110110110110																																																																																												
0110110110110110	0110110110110110																																																																																													
0110110110110110	0110110110110110																																																																																													
Item	AX1	AX2	AX3	AX4																																																																																										
Ready ON	●	●	●	●																																																																																										
Servo ON	●	●	●	●																																																																																										
Zero point passed	●	●	●	●																																																																																										
In-position	●	●	●	●																																																																																										
Zero speed	●	●	●	●																																																																																										
Torque limit	●	●	●	●																																																																																										
Servo alarm	●	●	●	●																																																																																										
Servo warning	●	●	●	●																																																																																										
Axis1	Axis2																																																																																													
0110110110110110	0110110110110110																																																																																													
0110110110110110	0110110110110110																																																																																													
0110110110110110	0110110110110110																																																																																													
0110110110110110	0110110110110110																																																																																													
0110110110110110	0110110110110110																																																																																													
0110110110110110	0110110110110110																																																																																													
Item	Axis1	Axis2	Axis3	Axis4																																																																																										
Regenerative load ratio	012	012	012	012																																																																																										
Actual load ratio	012	012	012	012																																																																																										
Peak load ratio	012	012	012	012																																																																																										
		871, 971, 1071, 1171	0367, 03CB, 042F, 0493																																																																																											
		872, 972, 1072, 1172	0368, 03CC, 0430, 0494																																																																																											
		873, 973, 1073, 1173	0369, 03CD, 0431, 0495																																																																																											
		874, 974, 1074, 1174	036A, 03CE, 0432, 0496																																																																																											
2)		877, 977, 1077, 1177	036D, 03D1, 0435, 0499																																																																																											
3)		878, 978, 1078, 1178	036E, 03D2, 0436, 049A																																																																																											
4)		879, 979, 1079, 1179	036F, 03D3, 0437, 049B																																																																																											
5)		880, 980, 1080, 1180	0370, 03D4, 0438, 049C																																																																																											
<p>QD75M DPR</p> <p>Axis Travel after NPO ON</p> <table border="1"> <thead> <tr> <th>Axis</th> <th>Travel after NPO ON</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>01234567890</td> </tr> <tr> <td>2</td> <td>01234567890</td> </tr> <tr> <td>3</td> <td>01234567890</td> </tr> <tr> <td>4</td> <td>01234567890</td> </tr> </tbody> </table> <p>($\mu\text{m}:\times 10^{-3}$) (inch:$\times 10^{-5}$) (degree:$\times 10^{-5}$) (pulse:$\times 1$)</p> <table border="1"> <thead> <tr> <th>Axis</th> <th>Torque limit stored value</th> <th>near alarm</th> <th>upper limit</th> <th>lower limit</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>012 (%)</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>2</td> <td>012 (%)</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>3</td> <td>012 (%)</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>4</td> <td>012 (%)</td> <td>●</td> <td>●</td> <td>●</td> </tr> </tbody> </table>	Axis	Travel after NPO ON	1	01234567890	2	01234567890	3	01234567890	4	01234567890	Axis	Torque limit stored value	near alarm	upper limit	lower limit	1	012 (%)	●	●	●	2	012 (%)	●	●	●	3	012 (%)	●	●	●	4	012 (%)	●	●	●	1)	824 to 825	0338 to 0339																																																								
	Axis	Travel after NPO ON																																																																																												
	1	01234567890																																																																																												
	2	01234567890																																																																																												
	3	01234567890																																																																																												
4	01234567890																																																																																													
Axis	Torque limit stored value	near alarm	upper limit	lower limit																																																																																										
1	012 (%)	●	●	●																																																																																										
2	012 (%)	●	●	●																																																																																										
3	012 (%)	●	●	●																																																																																										
4	012 (%)	●	●	●																																																																																										
		924 to 925	039C to 039D																																																																																											
		1024 to 1025	0400 to 0401																																																																																											
		1124 to 1125	0464 to 0465																																																																																											
2)		826, 926, 1026, 1126	033A, 039E, 0402, 0466																																																																																											
3)		816, 916, 1016, 1116	0330, 0394, 03F8, 045C																																																																																											
4)																																																																																														
5)																																																																																														
-		---	---																																																																																											
<p>QD75M Speed-position control</p> <p>SPSC positioning amount</p> <table border="1"> <thead> <tr> <th>Axis1</th> <th>Axis2</th> <th>Axis3</th> <th>Axis4</th> </tr> </thead> <tbody> <tr> <td>01234567890</td> <td>01234567890</td> <td>01234567890</td> <td>01234567890</td> </tr> </tbody> </table> <p>($\mu\text{m}:\times 10^{-3}$) (degree:$\times 10^{-5}$) (inch:$\times 10^{-5}$) (pulse):*1</p> <p>Item</p> <table border="1"> <thead> <tr> <th>Item</th> <th>AX1</th> <th>AX2</th> <th>AX3</th> <th>AX4</th> </tr> </thead> <tbody> <tr> <td>Speed-position switching latch</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>In speed control</td> <td>●</td> <td>●</td> <td>●</td> <td>●</td> </tr> <tr> <td>Speed-position switching enable</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table> <p>SPSC movement amount change register</p> <table border="1"> <thead> <tr> <th>Axis1</th> <th>Axis2</th> <th>Axis3</th> <th>Axis4</th> </tr> </thead> <tbody> <tr> <td>0123456789</td> <td>0123456789</td> <td>0123456789</td> <td>0123456789</td> </tr> </tbody> </table> <p>Setting range 0 to 2147483647 ($\mu\text{m}:\times 10^{-3}$) (inch:$\times 10^{-5}$) (degree:$\times 10^{-5}$) (pulse):*1</p>	Axis1	Axis2	Axis3	Axis4	01234567890	01234567890	01234567890	01234567890	Item	AX1	AX2	AX3	AX4	Speed-position switching latch	●	●	●	●	In speed control	●	●	●	●	Speed-position switching enable	0	0	0	0	Axis1	Axis2	Axis3	Axis4	0123456789	0123456789	0123456789	0123456789	1)	814 to 815	032E to 032F																																																							
	Axis1	Axis2	Axis3	Axis4																																																																																										
	01234567890	01234567890	01234567890	01234567890																																																																																										
	Item	AX1	AX2	AX3	AX4																																																																																									
	Speed-position switching latch	●	●	●	●																																																																																									
	In speed control	●	●	●	●																																																																																									
	Speed-position switching enable	0	0	0	0																																																																																									
	Axis1	Axis2	Axis3	Axis4																																																																																										
	0123456789	0123456789	0123456789	0123456789																																																																																										
			914 to 915	0392 to 0393																																																																																										
			1014 to 1015	03F6 to 03F7																																																																																										
			1114 to 1115	045A to 045B																																																																																										
	2)		1526 to 1527	05F6 to 05F7																																																																																										
			1626 to 1627	065A to 065B																																																																																										
			1726 to 1727	06BE to 06BF																																																																																										
		1826 to 1827	0722 to 0723																																																																																											
3)		817, 917, 1017, 1117	0331, 0395, 03F9, 045D																																																																																											
4)		817, 917, 1017, 1117	0331, 0395, 03F9, 045D																																																																																											
5)		1528, 1628, 1728, 1828	05F8, 065C, 06C0, 0724																																																																																											

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address	
			dec.	hex.
1)		1)	1530 to 1531	05FA to 05FB
		2)	1630 to 1631	065E to 065F
		3)	1730 to 1731	06C2 to 06C3
		4)	1830 to 1831	0726 to 0727
2)		1)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
		2)	817, 917, 1017, 1117	0331, 0395, 03F9, 045D
		3)	1532, 1632, 1732, 1832	05FC, 0660, 06C4, 0728
		4)	---	---
1)		1)	1506 to 1507	05E2 to 05E3
		2)	1606 to 1607	0646 to 0647
		3)	1706 to 1707	06AA to 06AB
		4)	1806 to 1807	070E to 070F
		5)	1514 to 1515	05EA to 05EB
		6)	1614 to 1615	064E to 064F
		7)	1714 to 1715	06B2 to 06B3
		8)	1814 to 1815	0716 to 0717
		9)	1513, 1613, 1713, 1813	05E9, 064D, 06B1, 0715
		10)	1544, 1644, 1744, 1844	0608, 066C, 06D0, 0734
		11)	1545, 1645, 1745, 1845	0609, 066D, 06D1, 0735
		12)	1546, 1646, 1746, 1846	060A, 066E, 06D2, 0736
		13)	1547, 1647, 1747, 1847	060B, 066F, 06D3, 0737
		14)	1505, 1605, 1705, 1805	05E1, 0645, 06A9, 070D

Screen Image		No.	Buffer memory address	
			dec.	hex.
		1)	1500, 1600, 1700, 1800	05DC, 0640, 06A4, 0708
		2)	1501, 1601, 1701, 1801	05DD, 0641, 06A5, 0709
		3)	1502, 1602, 1702, 1802	05DE, 0642, 06A6, 070A
		4)	1503, 1603, 1703, 1803	05DF, 0643, 06A7, 070B
		5)	1504, 1604, 1704, 1804	05E0, 0644, 06A8, 070C
		6)	1512, 1612, 1712, 1812	05E8, 064C, 06B0, 0714
		7)	1516, 1616, 1716, 1816	05EC, 0650, 06B4, 0718
		8)	1508 to 1509	05E4 to 05E5
			1608 to 1609	0648 to 0649
			1708 to 1709	06AC to 06AD
		9)	1510 to 1511	05E6 to 05E7
			1610 to 1611	064A to 064B
			1710 to 1711	06AE to 06AF
		10)	1810 to 1811	0712 to 0713
			1520, 1620, 1720, 1820	05F0, 0654, 06B8, 071C
			1521, 1621, 1721, 1821	05F1, 0655, 06B9, 071D
		12)	1522 to 1523	05F2 to 05F3
			1622 to 1623	0656 to 0657
			1722 to 1723	06BA to 06BB
			1822 to 1823	071E to 071F
		13)	1524, 1624, 1724, 1824	05F4, 0658, 06BC, 0720
		14)	1525, 1625, 1725, 1825	05F5, 0659, 06BD, 0721
		1)	1538, 1638, 1738, 1838	0602, 0666, 06CA, 072E
		2)	1548, 1648, 1748, 1848	060C, 0670, 06D4, 0738
		3)	1549, 1649, 1749, 1849	060D, 0671, 06D5, 0739
		4)	1550, 1650, 1750, 1850	060E, 0672, 06D6, 073A
		5)	1540, 1640, 1740, 1840, 1541, 1641, 1741, 1841, 1542, 1642, 1742, 1842, 1543, 1643, 1743, 1843	0604, 0668, 06CC, 0730, 0605, 0669, 06CD, 0731, 0606, 066A, 06CE, 0732, 0607, 066B, 06CF, 0733

OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS

ERROR MESSAGES FOR SYSTEM MONITOR

OPERATING SP MODULE MONITOR

OPERATING SP MODULE MONITOR SCREEN

OPERATING I/O MODULE MONITOR SCREENS

ERROR MESSAGES FOR SP MODULE MONITOR

OPERATING NET-WORK MONITOR

SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address																																																																																																																																																
			dec.	hex.																																																																																																																																															
<p>QD75M Axis control data-4</p> <p>Inching movement amount</p> <table border="1"> <tr><td>Axis1</td><td>01234</td><td>Axis2</td><td>01234</td></tr> <tr><td>Axis3</td><td>01234</td><td>Axis4</td><td>01234</td></tr> </table> <p>Setting range: 1 to 65535 (μm):*10⁻⁴ [inch]:*10⁻⁴ (degree):*10⁻⁴ [pulse]:*1 0:JOG operation</p> <p>Target position change value (Address)</p> <table border="1"> <tr><td>Axis1</td><td>0123456789</td><td>Axis2</td><td>0123456789</td></tr> <tr><td>Axis3</td><td>0123456789</td><td>Axis4</td><td>0123456789</td></tr> </table> <p>Setting range: ABS-INC -2147483648 to 2147483647 (μm):*10⁻⁴ (inch):*10⁻⁴ (degree):*10⁻⁴ (pulse):*1 (*ABS 0to3599999(degree):*10⁻⁴)</p> <p>JOG speed</p> <table border="1"> <tr><td>Axis1</td><td>0123456789</td><td>Axis2</td><td>0123456789</td></tr> <tr><td>Axis3</td><td>0123456789</td><td>Axis4</td><td>0123456789</td></tr> </table> <p>Setting range: 0 to 200000000 (mm/min):*10⁻² (inch/min):*10⁻³ (degree/min):*10⁻³ 0 to 10000000(pulse/sec):*1</p> <p>Target position change value (Speed)</p> <table border="1"> <tr><td>Axis1</td><td>0123456789</td><td>Axis2</td><td>0123456789</td></tr> <tr><td>Axis3</td><td>0123456789</td><td>Axis4</td><td>0123456789</td></tr> </table> <p>Setting range: 0 to 200000000 (mm/min):*10⁻² (inch/min):*10⁻³ (degree/min):*10⁻³ 0 to 10000000 (pulse/sec):*1</p>	Axis1	01234	Axis2	01234	Axis3	01234	Axis4	01234	Axis1	0123456789	Axis2	0123456789	Axis3	0123456789	Axis4	0123456789	Axis1	0123456789	Axis2	0123456789	Axis3	0123456789	Axis4	0123456789	Axis1	0123456789	Axis2	0123456789	Axis3	0123456789	Axis4	0123456789	1)	1517, 1617, 1717, 1817	05ED, 0651, 06B5, 0719																																																																																																																
	Axis1	01234	Axis2	01234																																																																																																																																															
	Axis3	01234	Axis4	01234																																																																																																																																															
	Axis1	0123456789	Axis2	0123456789																																																																																																																																															
	Axis3	0123456789	Axis4	0123456789																																																																																																																																															
	Axis1	0123456789	Axis2	0123456789																																																																																																																																															
	Axis3	0123456789	Axis4	0123456789																																																																																																																																															
	Axis1	0123456789	Axis2	0123456789																																																																																																																																															
	Axis3	0123456789	Axis4	0123456789																																																																																																																																															
	2)	1518 to 1519	05EE to 05EF																																																																																																																																																
		1618 to 1619	0652 to 0653																																																																																																																																																
		1718 to 1719	06B6 to 06B7																																																																																																																																																
1818 to 1819		071A to 071B																																																																																																																																																	
3)	1534 to 1535	05FE to 05FF																																																																																																																																																	
	1634 to 1635	0662 to 0663																																																																																																																																																	
	1734 to 1735	06C6 to 06C7																																																																																																																																																	
4)	1834 to 1835	072A to 072B																																																																																																																																																	
	1536 to 1537	0600 to 0601																																																																																																																																																	
	1636 to 1637	0664 to 0665																																																																																																																																																	
	1736 to 1737	06C8 to 06C9																																																																																																																																																	
		1836 to 1837	072C to 072D																																																																																																																																																
<p>QD75M Start History</p> <p>Start History (0 to 7)</p> <table border="1"> <tr><th>No.</th><th>ax</th><th>Start</th><th>Y.ind</th><th>Time</th><th>Judge</th></tr> <tr><td>0</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>1</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>2</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>3</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>4</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>5</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>6</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>7</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> </table> <p>Start History (8 to 15)</p> <table border="1"> <tr><th>No.</th><th>ax</th><th>Start</th><th>Y.ind</th><th>Time</th><th>Judge</th></tr> <tr><td>8</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>9</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>10</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>11</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>12</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>13</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>14</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> <tr><td>15</td><td>01</td><td>Re</td><td>0123</td><td>00:00:00</td><td>0123</td></tr> </table>	No.	ax	Start	Y.ind	Time	Judge	0	01	Re	0123	00:00:00	0123	1	01	Re	0123	00:00:00	0123	2	01	Re	0123	00:00:00	0123	3	01	Re	0123	00:00:00	0123	4	01	Re	0123	00:00:00	0123	5	01	Re	0123	00:00:00	0123	6	01	Re	0123	00:00:00	0123	7	01	Re	0123	00:00:00	0123	No.	ax	Start	Y.ind	Time	Judge	8	01	Re	0123	00:00:00	0123	9	01	Re	0123	00:00:00	0123	10	01	Re	0123	00:00:00	0123	11	01	Re	0123	00:00:00	0123	12	01	Re	0123	00:00:00	0123	13	01	Re	0123	00:00:00	0123	14	01	Re	0123	00:00:00	0123	15	01	Re	0123	00:00:00	0123	1)	1212 to 1292	04BC to 050C																																				
	No.	ax	Start	Y.ind	Time	Judge																																																																																																																																													
0	01	Re	0123	00:00:00	0123																																																																																																																																														
1	01	Re	0123	00:00:00	0123																																																																																																																																														
2	01	Re	0123	00:00:00	0123																																																																																																																																														
3	01	Re	0123	00:00:00	0123																																																																																																																																														
4	01	Re	0123	00:00:00	0123																																																																																																																																														
5	01	Re	0123	00:00:00	0123																																																																																																																																														
6	01	Re	0123	00:00:00	0123																																																																																																																																														
7	01	Re	0123	00:00:00	0123																																																																																																																																														
No.	ax	Start	Y.ind	Time	Judge																																																																																																																																														
8	01	Re	0123	00:00:00	0123																																																																																																																																														
9	01	Re	0123	00:00:00	0123																																																																																																																																														
10	01	Re	0123	00:00:00	0123																																																																																																																																														
11	01	Re	0123	00:00:00	0123																																																																																																																																														
12	01	Re	0123	00:00:00	0123																																																																																																																																														
13	01	Re	0123	00:00:00	0123																																																																																																																																														
14	01	Re	0123	00:00:00	0123																																																																																																																																														
15	01	Re	0123	00:00:00	0123																																																																																																																																														
<p>QD75M Error & Warning History</p> <p>Error History (0 to 7)</p> <table border="1"> <tr><th>No.</th><th>axis</th><th>Code</th><th>Time</th></tr> <tr><td>0</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>1</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>2</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>3</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>4</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>5</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>6</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>7</td><td>0123</td><td></td><td>00:00:00</td></tr> </table> <p>Error History (8 to 15)</p> <table border="1"> <tr><th>No.</th><th>axis</th><th>Code</th><th>Time</th></tr> <tr><td>8</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>9</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>10</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>11</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>12</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>13</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>14</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>15</td><td>0123</td><td></td><td>00:00:00</td></tr> </table> <p>Warning History (0 to 7)</p> <table border="1"> <tr><th>No.</th><th>axis</th><th>Code</th><th>Time</th></tr> <tr><td>0</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>1</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>2</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>3</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>4</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>5</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>6</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>7</td><td>0123</td><td></td><td>00:00:00</td></tr> </table> <p>Warning History (8 to 15)</p> <table border="1"> <tr><th>No.</th><th>axis</th><th>Code</th><th>Time</th></tr> <tr><td>8</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>9</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>10</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>11</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>12</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>13</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>14</td><td>0123</td><td></td><td>00:00:00</td></tr> <tr><td>15</td><td>0123</td><td></td><td>00:00:00</td></tr> </table>	No.	axis	Code	Time	0	0123		00:00:00	1	0123		00:00:00	2	0123		00:00:00	3	0123		00:00:00	4	0123		00:00:00	5	0123		00:00:00	6	0123		00:00:00	7	0123		00:00:00	No.	axis	Code	Time	8	0123		00:00:00	9	0123		00:00:00	10	0123		00:00:00	11	0123		00:00:00	12	0123		00:00:00	13	0123		00:00:00	14	0123		00:00:00	15	0123		00:00:00	No.	axis	Code	Time	0	0123		00:00:00	1	0123		00:00:00	2	0123		00:00:00	3	0123		00:00:00	4	0123		00:00:00	5	0123		00:00:00	6	0123		00:00:00	7	0123		00:00:00	No.	axis	Code	Time	8	0123		00:00:00	9	0123		00:00:00	10	0123		00:00:00	11	0123		00:00:00	12	0123		00:00:00	13	0123		00:00:00	14	0123		00:00:00	15	0123		00:00:00	1)	1293 to 1356	050D to 054C
	No.	axis	Code	Time																																																																																																																																															
	0	0123		00:00:00																																																																																																																																															
	1	0123		00:00:00																																																																																																																																															
2	0123		00:00:00																																																																																																																																																
3	0123		00:00:00																																																																																																																																																
4	0123		00:00:00																																																																																																																																																
5	0123		00:00:00																																																																																																																																																
6	0123		00:00:00																																																																																																																																																
7	0123		00:00:00																																																																																																																																																
No.	axis	Code	Time																																																																																																																																																
8	0123		00:00:00																																																																																																																																																
9	0123		00:00:00																																																																																																																																																
10	0123		00:00:00																																																																																																																																																
11	0123		00:00:00																																																																																																																																																
12	0123		00:00:00																																																																																																																																																
13	0123		00:00:00																																																																																																																																																
14	0123		00:00:00																																																																																																																																																
15	0123		00:00:00																																																																																																																																																
No.	axis	Code	Time																																																																																																																																																
0	0123		00:00:00																																																																																																																																																
1	0123		00:00:00																																																																																																																																																
2	0123		00:00:00																																																																																																																																																
3	0123		00:00:00																																																																																																																																																
4	0123		00:00:00																																																																																																																																																
5	0123		00:00:00																																																																																																																																																
6	0123		00:00:00																																																																																																																																																
7	0123		00:00:00																																																																																																																																																
No.	axis	Code	Time																																																																																																																																																
8	0123		00:00:00																																																																																																																																																
9	0123		00:00:00																																																																																																																																																
10	0123		00:00:00																																																																																																																																																
11	0123		00:00:00																																																																																																																																																
12	0123		00:00:00																																																																																																																																																
13	0123		00:00:00																																																																																																																																																
14	0123		00:00:00																																																																																																																																																
15	0123		00:00:00																																																																																																																																																
	2)	1358 to 1421	054E to 058D																																																																																																																																																
	-	---	---																																																																																																																																																

Screen Image	No.	Buffer memory address	
		dec.	hex.

1) QD75M Positioning data

Axis1								Axis3							
No.	Para.	Int.	Cont.	App.	Dec.	Unit	Mcode	No.	Para.	Int.	Cont.	App.	Dec.	Unit	Mcode
	Address		Address		Address		Address		Address		Address		Address		Address
	01	01	01	01	01	01234	01234		01	01	01	01	01	01234	01234
	01234567890		01234567890		01234567890		01234567890		01234567890		01234567890		01234567890		01234567890
	01	01	01	01	01	01234	01234		01	01	01	01	01	01234	01234
	01234567890		01234567890		01234567890		01234567890		01234567890		01234567890		01234567890		01234567890
	01	01	01	01	01	01234	01234		01	01	01	01	01	01234	01234
	01234567890		01234567890		01234567890		01234567890		01234567890		01234567890		01234567890		01234567890

1)	2000 to 25999	07D0 to 658F
-	---	---

1) QD75M Servo basic parameter

1) Servo series	0:MR-HN 1:MR-HN4 2:MR-J2-B 3:MR-J2S-B 4:MR-J2-B	Rotation direction	0:Forward(incr) with increase of address 1:Reverse(incr) with increase of address
2) Axis1 0 Axis2 0 Axis3 0 Axis4 0		Auto tuning	MR-H-BN, MR-H-BN4, MR-J2-B, MR-J2-B, MR-J2S-B, MR-J2S-B 0:Interpolation mode (valid) 1:Normal mode (valid) 2:No auto tuning (invalid)
3) Amplifier setting	0:Used in incremental system 1:Used in absolute position detection system	MR-J2S-B, MR-J2M-B	0:Interpolation mode 1:Auto tuning mode 1 2:Manual mode 2 3:Auto tuning mode 2 4:Manual mode 2
4) Regenerative brake option	0:No 1:Yes	Servo response	<MR-H-BN, MR-H-BN4, MR-J2-B, MR-J2-B, MR-J2S-B, MR-J2M-B> 1-5:Standard 8-C:Friction load remedy
5) External dynamic brake	0:No 1:Yes	1:Low(15Hz) 2:Low(20Hz) 3:Low(25Hz)	
6) Axis1 0 Axis2 0 Axis3 0 Axis4 0		4:Low(30Hz) 5:Low(35Hz) 6:Low(45Hz)	
7) Motor type	0:Standard 1:Low inertia 2:Flat	7:Low(55Hz) 8:Middle(70Hz) 9:High(85Hz)	
8) Axis1 0 Axis2 0 Axis3 0 Axis4 0		A:High(105Hz) B:High(130Hz) C:High(160Hz)	
9) Motor capacity	0000 - FFFF	D:High(200Hz) E:High(240Hz) F:High(300Hz)	
10) Servo motor speed	1:1000(r/min) 2:2000(r/min) 3:3000(r/min)		
11) Feedback pulse	00016884(pulse) 00018192(pulse) 00019500(pulse) 255:Depending on the motor resolution pulses		
Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123			

1)	30100, 30200, 30300, 30400	07594, 075F8 0765C, 076C0
2)	30101, 30201, 30301, 30401	07595, 075F9 0765D, 076C1
3)	30102, 30202, 30302, 30402	07596, 075FA 0765E, 076C2
4)	30103, 30203, 30303, 30403	07597, 075FB 0765F, 076C3
5)	30104, 30204, 30304, 30404	07598, 075FC 07660, 076C4
6)	30105, 30205, 30305, 30405	07599, 075FD 07661, 076C5
7)	30106, 30206, 30306, 30406	0759A, 075FE 07662, 076C6
8)	30107, 30207, 30307, 30407	0759B, 075FF 07663, 076C7
9)	30108, 30208, 30308, 30408	0759C, 07600 07664, 076C8
10)	30109, 30209, 30309, 30409	0759D, 07601 07665, 076C9

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NET-WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

Screen Image		No.	Buffer memory address	
			dec.	hex.
<p>QD75M Servo regulation parameter(Part1)</p> <p>1) Position loop gain1 4 - 2000[rad/s] Load inertia *10⁻¹ Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>2) Speed loop gain1 20 - 8000[rad/s] Speed integral compensation1 - 1000[ms] Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>3) Position loop gain2 1 - 1000[rad/s] Feed forward gain 0 - 100[%] Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>4) Speed loop gain2 20 - 20000[rad/s] In-position range 0 - 50000[PLS] E-brake sequence Axis1 01234 Axis2 01234 Ax.1 01234 Ax.2 01234 Ax.3 01234 Ax.4 01234</p> <p>5) Notch filter MON. output</p> <p>6) Notch filter Axis1 01 Axis2 01 Axis3 01 Axis4 01</p> <p>7) Notch depth Axis1 0 Axis2 0 Axis3 0 Axis4 0</p>		1)	30113, 30213, 30313, 30413	075A1, 07605 07669, 076CD
		2)	30114, 30214, 30314, 30414	075A2, 07606 0766A, 076CE
		3)	30115, 30215, 30315, 30415	075A3, 07607 0766B, 076CF
		4)	30116, 30216, 30316, 30416	075A4, 07608 0766C, 076D0
		5)	30112, 30212, 30312, 30412	075A0, 07604 07668, 076CC
		6)	30117, 30217, 30317, 30417	075A5, 07609 0766D, 076D1
		7)	30119, 30219, 30319, 30419	075A7, 0760B 0766F, 076D3
		8)	30120, 30220, 30320, 30420	075A8, 0760C 07670, 076D4
		9)	30121, 30221, 30321, 30421	075A9, 0760D 07671, 076D5
		10)	30118, 30218, 30318, 30418	075A6, 0760A 0766E, 076D2
		11)	30122, 30222, 30322, 30422	075AA, 0760E 07672, 076D6
<p>QD75M Servo regulation parameter(Part2)</p> <p>1) Servo forced stop 0:Valid 1:Invalid Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>2) Low acoustic noise mode 0:2.5KHz 1:---- 2:6.375KHz 3:9KHz Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>3) Serial encoder cable 0: 2 line method 1: 4 line method Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>4) Slight vibration suppression control 0:Invalid 1:Valid Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>5) Motor-less operation 0:Invalid 1:Valid Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>6) Electro magnetic brake interlock output 0:No relation to servo motor speed. 1:Output in any statuses when the motor speed is less than Zero speed. Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>7) Low pass filter 0:Automatic control 1:Manual Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>8) Adaptive vibration control 0:Invalid 1:Valid 2:Maintenance Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>9) Adaptive vibration control sensitivity 0:Normal 1:Very sensitive Axis1 0 Axis2 0 Axis3 0 Axis4 0</p>		1)	30123, 30223, 30323, 30423	075AB, 0760F 07673, 076D7
		2)		
		3)		
		4)	30124, 30224, 30324, 30424	075AC, 07610 07674, 076D8
		5)		
		6)		
		7)	30125, 30225, 30325, 30425	075AD, 07611 07675, 076D9
		8)		
		9)		
		-	---	---
<p>QD75M Servo extended parameter(Part1)</p> <p>1) Analog monitor offset -9999 - 9999 Analog monitor 1 Axis1 01234 Axis2 01234 offset Axis1 01234 Axis2 01234 Analog monitor 2 Axis1 01234 Axis2 01234 offset Axis1 01234 Axis2 01234</p> <p>2) Alarm data sampling time 0:1.77[ms] 1:3.55[ms] 2:7.11[ms] 3:14.22[ms] 4:28.44[ms] Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>3) Pre-alarm data 0:Speed 1:Torque 2:Speed 3:Torque 4:Command current output 5:Command F delta T 6:Droop pulses/1 7:Droop pulses/4 8:Droop pulses/16 9:Droop pulses/32 A:Droop pulses/64 data 1 Axis1 0 Axis2 0 Axis3 0 Axis4 0 data 2 Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>4) Zero speed 0 - 10000[r/min] Axis1 01234 Axis2 01234 Axis3 01234 Axis4 01234</p> <p>5) Error excessive alarm level 1 - 1000[Kpls], 0.1 - 100.0[0.25rev] (MR-J2S-B,MR-J2M-B) Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>6) PI-PID control switch-over 0:Invalid 1:Droop-based switching is valid in position control 2:PID control is always valid Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>7) Servo retrieve character 0:Japanese 1:English Axis1 0 Axis2 0 Axis3 0 Axis4 0</p>		1)	30127, 30227, 30327, 30427	075AF, 07613 07677, 076DB
		2)	30128, 30228, 30328, 30428	075B0, 07614 07678, 076DC
		3)	30129, 30229, 30329, 30429	075B1, 07615 07679, 076DD
		4)		
		5)	30130, 30230, 30330, 30430	075B2, 07616 0767A, 076DE
		6)	30131, 30231, 30331, 30431	075B3, 07617 0767B, 076DF
		7)	30132, 30232, 30332, 30432	075B4, 07618 0767C, 076E0
		8)		

Screen Image	No.	Buffer memory address	
		dec.	hex.
<p>QD75M Servo extended parameter(Part2)</p> <p>Serial communication baudrate 0: 9600[bps] 1:19200[bps] 2:38400[bps] 3:57600[bps] Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>Serial communication response delay 0:Invalid 1:Valid Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>Encoder output pulse setting 0:Output pulse setting 1:Division ratio setting Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>DPR set condition selection 0: It is necessary to pass through the 2 phase after the power on. 1: It is not necessary to pass through the 2 phase after the power on. Axis1 0 Axis2 0 Axis3 0 Axis4 0</p>	1)	30133, 30233,	075B5, 07619
	2)	30333, 30433	0767D, 076E1
	3)		
	4)	30134, 30234, 30334, 30434	075B6, 0761A 0767E, 076E2
	5)	30136, 30236, 30336, 30436	075B8, 0761C 07680, 076E4
	6)	30138, 30238, 30338, 30438	075BA, 0761E 07682, 076E6
	-	---	---
<p>QD75M Servo extended parameter 2</p> <p>Slight vibration control selection 1 Act times 1:0.75times 2:0.5times 3:0.25times Ax.1 Ax.2 Ax.3 Ax.4 Position gain 2 shift amount 0 0 0 0 Speed gain 2 shift amount 0 0 0 0 Speed integral compensation shift amount 0 0 0 0</p> <p>Slight vibration control selection 2 0 - 1000 [ms] Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>Voltage compensation 0 - 100 [%] Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>Gain changing 0:Invalid 1:NT, signal from controller 2:Command frequency 3:loop pulses 4:Model speed Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>Gain changing condition 0 - 9999 Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>Gain changing time constant 0 - 100 [ms] Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>Load moment of inertia ratio 0 - 3000 *10⁻⁴ Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>Position loop gain 2 changing ratio 10-2004 Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>Speed loop gain 2 changing ratio 10-2004 Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>VEL. INTGRAL.COMPS.gain 2 changing ratio 50 - 1000 [%] Axis1 0123 Axis2 0123 Axis3 0123 Axis4 0123</p> <p>Encoder output pulses direction 0:Advance 90 A with CW 1:Advance 90 A with CW Axis1 0 Axis2 0 Axis3 0 Axis4 0</p> <p>Notch filter MR-J2S-B, MR-J2M-B Frequency 0c: 01:4500 [Hz] 02:2250 [Hz] 03:1500 [Hz] 04:1125 [Hz] 05: 900 [Hz] 06: 750 [Hz] 07:642.9 [Hz] 08:562.5 [Hz] 09: 500 [Hz] 08: 450 [Hz] 08:409.1 [Hz] 09: 375 [Hz] 09:342.9 [Hz] 09:321.4 [Hz] 0F: 300 [Hz] 10:281.3 [Hz] 11:264.7 [Hz] 12: 250 [Hz] 13:236.8 [Hz] 14: 225 [Hz] 15:214.3 [Hz] 16:204.5 [Hz] 17:195.7 [Hz] 18:187.5 [Hz] 19: 180 [Hz] 1A:173.1 [Hz] 1B:166.7 [Hz] 1C:160.1 [Hz] 1D:155.2 [Hz] 1E: 150 [Hz] 1F:145.2 [Hz] Notch depth 0: -4db 1: -14db 2: -8db 3: -4db Frequency Axis1 01 Axis2 01 Axis3 01 Axis4 01 Notch depth Axis1 0 Axis2 0 Axis3 0 Axis4 0</p>	1)	30143, 30243, 30343, 30443	075BF, 07623 07687, 076EB
	2)	30144, 30244, 30344, 30444	075C0, 07624 07688, 076EC
	3)	30145, 30245, 30345, 30445	075C1, 07605 07689, 076ED
	4)	30149, 30249, 30349, 30449	075C5, 07629 0768D, 076F1
	5)	30150, 30250, 30350, 30450	075C6, 0762A 0768E, 076F2
	6)	30151, 30251, 30351, 30451	075C7, 0762B 0768F, 076F3
	7)	30152, 30252, 30352, 30452	075C8, 0762C 07690, 076F4
	8)	30153, 30253, 30353, 30453	075C9, 0762D 07691, 076F5
	9)	30154, 30254, 30354, 30454	075CA, 0762E 07692, 076F5
	10)	30155, 30255, 30355, 30455	075CB, 0762F 07693, 076F6
	11)	30160, 30260, 30360, 30460	075D0, 07634 07698, 076FC
	12)	30161, 30261, 30361, 30461	075D1, 07635 07699, 076FD

OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS

ERROR MESSAGES FOR SYSTEM MONITOR

OPERATING SP MODULE MONITOR

OPERATING SP MODULE MONITOR SCREEN

OPERATING I/O MODULE MONITOR SCREENS

ERROR MESSAGES FOR SP MODULE MONITOR

OPERATING NET-WORK MONITOR

SWITCHING THE NETWORK MONITOR SCREENS

13 OPERATING I/O MODULE MONITOR SCREENS

This section explains how the various screens are operated in the special module monitor function, when monitoring input or output modules.

13.1 Specifying the module to be monitored

This describes how to start monitoring an optional special input or output module.

[Operation procedure]

Display the System Configuration screen. (See Section 12.1.1.)

Specify the module to be monitored (Touch the position at which the module is displayed.)

(1) From among the modules installed in the corresponding base unit, specify the module whose "Input" or "Output" is displayed. Refer to Section 12.1.3 for the way to specify the special function module.

Display the monitor screen for the specified module.

(2) For information on confirming the displayed contents and subsequent operation, please see Section 13.2.

* Tests cannot be conducted on input or output modules.


X MODULE				sys. conf.	END
	X	i			
00	○	10	○	20	○
01	●	11	○	21	○
02	○	12	○	22	○
03	○	13	○	23	○
04	○	14	○	24	○
05	○	15	○	25	○
06	○	16	○	26	○
07	○	17	○	27	○
08	○	18	○	28	○
09	○	19	○	29	○
0A	○	1A	○	2A	○
0B	○	1B	○	2B	○
0C	○	1C	○	2C	○
0D	○	1D	○	2D	○
0E	○	1E	○	2E	○
0F	○	1F	○	2F	○

To Section 13.2

13.2 Monitor screen configuration and key functions

This section describes the configuration of monitor screens displayed by specifying the input module on the system configuration screen, and explains the functions of the keys displayed on the screen.

(1) Display (for an input module)



4)

Displays the statuses of input and output signals after being read out from the corresponding module. (OS executes it automatically.)

Statuses for up to 64 can be displayed.

Signal statuses:

- : ON
- : OFF

1)	Displays the type of the object module (input or output module).
2)	Displays the name of the signal being monitored (X or Y).
3)	Displays the number and status of the input or output signal.
4)	Displays keys that are used with the operation of the monitor screen shown in (2) (Touch input).

(2) Key functions

The chart below shows the functions of the keys that are used with the Monitor Screen operation.

Key	Function
END	Monitoring ends; and display returns to the screen where the special module monitor function was begun.
sys. conf.	The current monitoring ends; and returns to the system configuration screen.

9 OPERATION OF THE VARIOUS SYSTEM MONITOR SCREENS
 10 ERROR MESSAGES FOR SYSTEM MONITOR
 11 OPERATING SP MODULE MONITOR
 12 OPERATING SP MODULE MONITOR SCREEN
 13 OPERATING I/O MODULE MONITOR SCREENS
 14 ERROR MESSAGES FOR SP MODULE MONITOR
 15 OPERATING NETWORK WORK MONITOR
 16 SWITCHING THE NETWORK MONITOR SCREENS

14 ERROR MESSAGES FOR SPECIAL MODULE MONITOR

The following chart shows the error messages that may be displayed when operating the special module monitor and the method of handling them.


Error message	Description	Method of Handling
Can not Communication	Communication could not be established with the PLC CPU.	(1) To try the operation again, touch "Retry". When the operation is retried, the error message disappears and monitoring resumes automatically, so no action is required. If monitoring is not resumed for a long period of time, however, check the following: 1) Connections between the PLC CPU and the GOT (disconnected or cut cables). 2) Has an error occurred in the PLC CPU? Etc.

15 OPERATING NETWORK MONITOR

This chapter describes how to operate the network monitor function.


15.1 Steps in getting started with the network monitor function

The following flowchart outlines how to transmit and install an operating system (OS) for the network monitor function in the GOT internal memory using the Personal computer. For further information on screen displays and key operations, see the online the GT Designer2 Version2 Operating Manual.



15.2 Steps in starting the network monitor function from the user-created monitor screen


The following flowchart outlines how to start the network monitor function after the operating system (OS) for the network monitor has been installed in the GOT built-in internal memory.



*1 Touch the key assigned to the network monitor function (set in the touch switch expanded function of the GT Designer2). In the Utility Menu screen, touch **NET.MON.** to start the network monitor function.

16 SWITCHING THE NETWORK MONITOR SCREENS

The following flowchart outlines the steps involved in switching the network monitor screens.



17 USING THE NETWORK MONITOR SCREENS

This chapter describes how to use various monitor screens when you execute the network monitor function.

17.1 Own station monitor














This section describes the structure of the monitor screen and the common operations used when executing the own station monitor.

17.1.1 Display contents and keys functions: own station monitor

This section describes the own station monitor screen and the function of on-screen keys, all of which are displayed and used when executing the network monitor function.


(1) Display contents

When the A985/97*/960GOT is used		When the A95*/956WGOT is used
		<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>Touch button to change the display.</p> <p>(Display example)</p>
No.	Contents of Display	
1)	(1) This shows the action mode of the own station: On-line, Off-line, loop test. (2) This shows the status of the F-loop (primary loop): OK, NG. (3) This shows the status of the R-loop (secondary loop): OK, NG. (4) This shows whether the loopback was executed or not: Executed, Not executed. (5) This shows link scan time required for the control station and the ordinary station, for the remote master station and the remote I/O station, and for the mater station and all the sub-stations. (a) Maximum (the maximum value of link scan time) (b) Minimum (the minimum value of link scan time) (c) Current (the current value of link scan time)	
2)	This shows the network category, network number, and station number.	

No.	Contents of Display
3)	<p>This shows the loop status of a network system as follows: (Primary loop: F, Secondary loop: R)</p> <div style="display: flex; flex-wrap: wrap;"> <div style="width: 33%;"> <p>(a) Primary loop : OK Secondary loop : OK</p>  </div> <div style="width: 33%;"> <p>(b) Primary loop : OK Secondary loop : NG</p>  </div> <div style="width: 33%;"> <p>(c) Primary loop : NG Secondary loop : OK</p>  </div> </div> <div style="display: flex; flex-wrap: wrap; margin-top: 10px;"> <div style="width: 33%;"> <p>(d) Executing loopback</p>  </div> <div style="width: 33%;"> <p>(e) Primary loop : NG Secondary loop : NG</p>  </div> <div style="width: 33%;"> <p>(f) MELSECNET/10 coaxial bus (OK)</p>  </div> <div style="width: 33%;"> <p>(g) MELSECNET/10 coaxial bus (NG)</p>  </div> </div>
4)	<p>The following loop status in the data link system is displayed. (Primary loop: F, Sub- loop: R)</p> <div style="display: flex; flex-wrap: wrap;"> <div style="width: 33%;"> <p>(a) Data is linked in the Primary loop.</p>  </div> <div style="width: 33%;"> <p>(b) Data is linked in the sub-loop.</p>  </div> <div style="width: 33%;"> <p>(c) Loop-back is performed in the Primary/sub loop direction.</p>  </div> </div> <div style="display: flex; flex-wrap: wrap; margin-top: 10px;"> <div style="width: 33%;"> <p>(d) Loop-back is performed in the Primary loop direction only.</p>  </div> <div style="width: 33%;"> <p>(e) Loop-back is performed in the sub-loop direction only.</p>  </div> <div style="width: 33%;"> <p>(f) Data link is not available.</p>  </div> </div>

(2) Key functions

This section describes the function of keys to be used on the own station monitor screen.

Key	Function
	Exits the own station monitor screen and returns to the previous monitor screen where the network monitor function was executed.
	Switches to the detailed monitor screen that corresponds to the module displayed on the current monitor screen. This key is effective for each screen.
	Switches to the other station monitor menu that corresponds to the network displayed on the current monitor screen. This key is effective for each screen.
	Changes the details on the window. (only for A95*GOT)
	Changes the monitoring destination CPU using the CPU No. (For multi-PLC system connection only) The CPU No. is displayed according to the number of CPUs loaded.

17.2 Detailed own station monitor

This section describes the structure of the monitor screen and the common operations used when executing the detailed own station monitor.

17.2.1 MELSECNET/B, MELSECNET (II) master station

This section describes the detailed own station monitor screen and the function of on-screen keys, all of which are displayed and used when the own station acts as the master station on the MELSECNET/B or MELSECNET (II).

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>Touch button to change the display.</p> <p>(Display example)</p>

No.	Section	Contents of Display
1)	TsSt's Info	<ul style="list-style-type: none"> This Station's # Indicates the station number of the own station. This Station's: Indicates the category of the own station.
2)	D-Link Info	<ul style="list-style-type: none"> Total of L-Sta: Indicates the maximum number of the stations to be linked. The maximum number is defined by common parameters.
3)	LoopBK Info	<ul style="list-style-type: none"> FLoop: Shows the status of the primary loop lines of the own station. (Normal/NG) RLoop: Shows the status of the secondary loop lines of the own station. (Normal/NG) Floop Back Station: Indicates the station number of a station that executes the loopback along the primary loop. Rloop Back Station: Indicates the station number of a station that executes the loopback along the secondary loop. # of Loop Switching: Indicates the cumulative number of times for which loops have been switched.

(2) Key functions

The table below shows the function of keys that are used on the detailed own station monitor screen.

Key	Function
	Returns to the own station monitor screen.
	Exits the detailed own station monitor screen and returns to the previous monitor screen where the network monitor function was executed.
	Changes the details on the window. (only for A95*GOT)

17 USING THE NETWORK MONITOR SCREENS
 18 ERROR MESSAGES FOR NETWORK MONITOR
 19 OPERATING LIST EDITOR
 20 OPERATION OF EDITING SCREEN FOR EACH LIST
 21 ERROR MESSAGES FOR LIST EDITOR
 22 OPERATING MOTION MONITOR
 23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24 ERROR MESSAGES FOR MOTION MONITOR

17.2.2 MELSECNET/B, MELSECNET (II) local station

This section describes the detailed own station monitor screen and the function of on-screen keys, all of which are displayed and used when the own station acts as the local station on the MELSECNET/B or MELSECNET (II).

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>Touch button to change the display.</p> <p>(Display example)</p>

No.	Section	Contents of Display
1)	TsSt' Info	<ul style="list-style-type: none"> This Station's # Indicates the station number of the own station. This Station's: Indicates the category of the own station.
2)	D-Link Info	<ul style="list-style-type: none"> Total of L-Sta: Indicates the maximum number of the stations to be linked. The maximum number is defined by common parameters.
3)	Com Status	<ul style="list-style-type: none"> Com Status: Displays the communications status of the own station. (Parameter wait, Cyclic comm, NG)
4)	BWY From Master	<ul style="list-style-type: none"> This shows the status of receiving Device BWY from the master station. OK: Data is being received by cyclic receiving. NG: The own station cannot receive data because of column reading.
5)	BW From Hostmaster	<ul style="list-style-type: none"> This shows the status of receiving Device BW from the master station of a dual-layer system. OK: Data is being received by cyclic receiving. NG: The own station cannot receive data due to column reading.
6)	LoopBK Info	<ul style="list-style-type: none"> FLoop: Shows the status of the primary loop lines of the own station. (Normal/NG) RLoop: Shows the status of the secondary loop lines of the own station. (Normal/NG)

(2) Key functions

The table below shows the functions of keys that are used on the detailed own station monitor screen.

Key	Function
	Returns to the own station monitor screen.
	Exits the detailed own station monitor screen and returns to the previous monitor screen where the network monitor function was executed.
	Changes the details on the window. (only for A95*GOT)

17.2.3 MELSECNET/10 Control station/ordinary Station

This section describes the contents of the detailed own station monitor screen and the function of on-screen keys. All these are displayed and used when the own station acts as the control station/ordinary station on the MELSECNET/10, MELSECNET/H.

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>Touch button to change the display.</p> <p>(Display example)</p>

No.	Section	Contents of Display
1)	TsSt' Info	<ul style="list-style-type: none"> • This Station's #: Indicates the station number of the own station. • Network #: Indicates the network number. • Group #: Indicates the group number.
2)	Ctrl St Info	<ul style="list-style-type: none"> • Spc Ctrl Sta: Indicates the station number of a station that is specified as a control station. • Curr Ctrl Sta: Indicates the station number of a station that is currently acting as the control station. • Com Info: Indicates whether the own station is communicating with the control station or the sub control station. • SubCtrl Sta Com: Indicates the availability of a sub control station. (Available/None) • Rmt I/O Mst Sta: *1 Indicates the station number of a remote I/O master station in Block 1 or Block 2. If the master station is not available, this indicates "None" instead.

*1 Not displayed when the CPU type of the GOT connection target is the AnNCPU or AnACPU.

No.	Section	Contents of Display
3)	D-Link Info	<ul style="list-style-type: none"> • Total of L-Sta: Indicates the maximum number of the stations to be linked. The maximum number is defined by common parameters. • Largest Nrm Sta: Indicates the station number of the largest station that is connected in a normal condition. • Largest DL-Sta: Indicates the station number of the largest station that is data-linked. • Com Status: Show the current communications status of the own station. (D-Link in prog, D-Link Stop (A), D-Link Stop (H), B-Pass excut, Disconnection, Testing, Reset. in prgr.) • Causes of Ssp: Indicates the causes why the communications were interrupted. This indicates "OK" if communications is in a normal condition. (Normal, Offline, Offline Test, Others (error codes)) • Causes of Stop: Indicates the causes why the data link was stopped. This indicate "OK" if the data link is in a normal condition. (No common para, Host Para error, Instructed by Other Station (n station), Essential Parameter Not Matched, Instructed by Host Station, Improper I/O Allocation, Instructed by All Stations (n stations), Others (error codes))
4)	Constant LS	<ul style="list-style-type: none"> • Constant LS: Indicates the predetermined time of constant link scans.
5)	LoopBK Info	<ul style="list-style-type: none"> • FLoop: Shows the status of the primary loop lines of the own station. (Normal/LoopBK Trans/D-Link Impo) • RLoop: Shows the status of the secondary loop lines of the own station. (Normal/LoopBK Trans/D-Link Impo) • FLoop Back Station: Indicates the station number of a station that executes the loopback along the primary loop. • RLoop Back Station: Indicates the station number of a station that executes the loopback along the secondary loop. • # of Loop Switching: Indicates the cumulative number of times for which loops have been switched. * "---" is displayed when coaxial bus connections are established.

No.	Section	Contents of Display
6)	TsSt' Sta	<ul style="list-style-type: none"> • Parameter Setting: Common Param, Common + Spec if, Default Param, Default + Specif • Reserved Sta: Indicates the availability of a reserved station. (Have/None) • Communication Mode: Indicates either of "Normal mode" or "Constant LS." • Transmission Mode: Indicates either of "Normal Trans" or "Multipl Trans." * • Transmission Stat: Indicates either of "Normal Trans" or Multipl Trans." *

* "----" is displayed when coaxial bus connections are established.

(2) Key functions

The table below shows the function of keys that are used on the detailed own station monitor screen.

Key	Function
	Returns to the own station monitor screen.
	Exits the detailed own station monitor screen and returns to the previous monitor screen where the network monitor function was executed.
	Changes the details on the window. (only for A95*GOT)

17 USING THE NETWORK MONITOR SCREENS
 18 ERROR MESSAGES FOR NETWORK MONITOR
 19 OPERATING LIST EDITOR
 20 OPERATION OF EDITING SCREEN FOR EACH LIST
 21 ERROR MESSAGES FOR LIST EDITOR
 22 OPERATING MOTION MONITOR
 23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24 ERROR MESSAGES FOR MOTION MONITOR

17.2.4 MELSECNET/10, MELSECNET/H remote master station

This section describes the detailed own station monitor screen and the function of on-screen keys, all of which are displayed and used when the own station acts as the remote master station on the MELSECNET/10, MELSECNET/H.

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>Touch button to change the display. (Display example)</p>

No.	Section	Contents of Display
1)	TsSt' Info	<ul style="list-style-type: none"> • This Stations #: Indicates the station number of the own station. • Network #: Indicates the network number. • Group #: Not displayed.
2)	Ctrl St Info	<ul style="list-style-type: none"> • Spc Ctrl Sta: Not displayed • Curr Ctrl Sta: Not displayed • Com Info: Not displayed • SubCtrl-Sta Com: Not displayed

No.	Section	Contents of Display
3)	D-Link Info	<ul style="list-style-type: none"> • Total of L-Sta: Indicates the maximum number of the stations to be linked. The maximum number is defined by common parameters. • Largest Nrm Sta: Indicates the station number of the largest station that is connected in a normal condition. • Largest DL-Sta: Indicates the station number of the largest station that is data-linked. • Com Status: Show the current communications status of the own station. (D-Link in prog, D-Link Stop (A), D-Link Stop (H), B-Pass excut, Disconnection, Testing, Reset. in prgr.) • Causes of Ssp: Indicates the reason why the communications were interrupted. This indicates "OK" if communications is in a normal condition. (Normal, Offline, Offline Test, Others (error codes)) • Causes of Stop: Indicates the causes why the data link was stopped. This indicates "OK" if the data link is in a normal condition. (No common para, Host Para error, Instructed by Other Station (n station), Essential Parameter Not Matched, Instructed by Host Station, Improper I/O Allocation, Instructed by All Stations (n stations), Others (error codes))
4)	Constant LS	<ul style="list-style-type: none"> • Constant LS: Indicates the predetermined time of constant link scans.
5)	LoopBK Info	<ul style="list-style-type: none"> • FLoop: Shows the status of the primary loop lines of the own station. (Normal/LoopBK Trans/D-Link Impo) • RLoop: Shows the status of the secondary loop lines of the own station. (Normal/LoopBK Trans/D-Link Impo) • FLoop Back Station: Indicates the station number of a station that executes the loopback along the primary loop. • RLoop Back Station: Indicates the station number of a station that executes the loopback along the secondary loop. • # of Loop Switching: Indicates the cumulative number of times for which loops have been switched. • * "----" is displayed when coaxial bus connections are established.

17
 USING THE NETWORK MONITOR SCREENS
 18
 ERROR MESSAGES FOR NETWORK MONITOR
 19
 OPERATING LIST EDITOR
 20
 OPERATION OF EDITING SCREEN FOR EACH LIST
 21
 ERROR MESSAGES FOR LIST EDITOR
 22
 OPERATING MOTION MONITOR
 23
 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24
 ERROR MESSAGES FOR MOTION MONITOR

No.	Section	Contents of Display
6)	TsSt' Sta	<ul style="list-style-type: none"> • Parameter Setting: Not displayed. • Reserved Sta: Indicates the availability of a reserved station. (Have/None) • Communication Mode: Indicates either of "Normal mode" or "Constant LS." • Transmission Mode: Indicates either of " Normal Trans " or " Multipl trans." * • Transmission Stat: Indicates either of " Normal Trans " or Multipl trans." *

* "---" is displayed when coaxial bus connections are established.

(2) Key functions

The table below shows the function of keys that are used on the detailed own station monitor screen.

Key	Function
	Returns to the own station monitor screen.
	Exits the detailed own station monitor screen and returns to the previous monitor screen where the network monitor function was executed.
	Changes the details on the window. (only for A95*GOT)

17.3 Other station monitor

This section describes the structure of the monitor screen and the common operations used when executing the other station monitor.

17.3.1 Other station monitor menu

This section describes the other station monitor menu screen and the function of on-screen keys. The menu screen for the other station monitor is displayed by touching a module number displayed on the own station monitor screen. The menu screen provides many options for the other station monitor.

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97* /960GOT.</p> <p>(Display example)</p>

No.	Touch Key	Contents of Display
1)	Communications Status	Switches to a monitor screen that shows the communications status of other stations. *
2)	Data Link	Switches to a monitor screen that shows the data link status of other stations. *
3)	Parameters	Switches to a monitor screen that shows the parameter status of other stations. *
4)	CPU Action	Switches to a monitor screen that shows the CPU action status of other stations.
5)	CPU RUN	Switches to a monitor screen that shows the CPU RUN status of other stations.
6)	Loop	Switches to a monitor screen that shows the loop status of other stations.

* This is not selectable when connected to a MELSECNET/B or MELSECNET (II) local station.

(2) Key Functions

The table below shows the function of keys that are used on the other station monitor screen.

Key	Function
	Switches to the other station monitor screen.
RET	Returns to the own station monitor screen.
END	Exits the other station monitor screen and returns to the previous monitor screen where the network monitor function was executed.

17 USING THE NETWORK MONITOR SCREENS
 18 ERROR MESSAGES FOR NETWORK MONITOR
 19 OPERATING LIST EDITOR
 20 OPERATION OF EDITING SCREEN FOR EACH LIST
 21 ERROR MESSAGES FOR LIST EDITOR
 22 OPERATING MOTION MONITOR
 23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24 ERROR MESSAGES FOR MOTION MONITOR

17.3.2 Other station communication status monitor

This section describes the other station communications status monitor screen and the function of on-screen keys.

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>(Display example)</p>

No.	Contents of Display
1)	Station numbers are shown up to the maximum number of linked stations.
2)	Any station in an abnormal condition is highlighted on-screen.
3)	Any station specified as a reserved station is treated as a station that stays in a normal condition.

(2) Key Functions

The table below shows the function of keys that are used on the other station communications status monitor screen.

Key	Function
RET	Returns to the own station monitor screen.
END	Exits the other station communications status monitor screen and returns to the previous monitor screen where the network monitor function was executed.

17.3.3 Other station data link status monitor

This section describes the other station data link status monitor screen and the function of on-screen keys.

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>(Display example)</p>

No.	Contents of Display
1)	Station numbers are shown up to the maximum number of linked stations.
2)	Any station that is not data-linked is highlighted on-screen.
3)	Any station specified as a reserved station is treated as a station that stays in a normal condition.

(2) Key Functions

The table below shows the function of keys that are used on the other station data link status monitor screen.

Key	Function
RET	Returns to the own station monitor screen.
END	Exits the other station data link status monitor screen and returns to the previous monitor screen where the network monitor function was executed.

17 USING THE NETWORK MONITOR SCREENS
 18 ERROR MESSAGES FOR NETWORK MONITOR
 19 OPERATING LIST EDITOR
 20 OPERATION OF EDITING SCREEN FOR EACH LIST
 21 ERROR MESSAGES FOR LIST EDITOR
 22 OPERATING MOTION MONITOR
 23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24 ERROR MESSAGES FOR MOTION MONITOR

17.3.4 Other station parameter status monitor

This section describes the other station parameter status monitor screen and the function of on-screen keys.

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>(Display example)</p>

No.	Contents of Display
1)	Station numbers are shown up to the maximum number of linked stations.
2)	Any station whose parameters are monitored is highlighted on-screen. *
3)	Any station that stays in an abnormal condition is highlighted on-screen.
4)	A station specified as a reserved station is treated as a station that stays in a normal condition.

* Not highlighted when connected to a MELSECNET/B or MELSECNET (II) master station.

(2) Key Functions

The table below shows the function of keys that are used on the other station parameter status monitor screen.

Key	Function
RET	Returns to the own station monitor screen.
END	Exits the other station parameter status monitor screen and returns to the previous monitor screen where the network monitor function was executed.

17.3.5 Other station CPU action status monitor

This section describes the other station CPU action status monitor screen and the function of on-screen keys.

This option is not selectable when connecting to a remote I/O network system.

(1) (1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>(Display example)</p>

No.	Contents of Display
1)	Station numbers are shown up to the maximum number of linked stations.
2)	Any station that stays in an abnormal condition or out of action is highlighted on-screen.
3)	A station specified as a reserved station is treated as a station that stays in a normal condition.

(2) Key Functions

The table below shows the function of keys that are used on the other station CPU action status monitor screen.

Key	Function
RET	Returns to the own station monitor screen.
END	Exits the other station CPU action status monitor screen and returns to the previous monitor screen where the network monitor function was executed.

17
 USING THE NETWORK MONITOR SCREENS
 18
 ERROR MESSAGES FOR NETWORK MONITOR
 19
 OPERATING LIST EDITOR
 20
 OPERATION OF EDITING SCREEN FOR EACH LIST
 21
 ERROR MESSAGES FOR LIST EDITOR
 22
 OPERATING MOTION MONITOR
 23
 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24
 ERROR MESSAGES FOR MOTION MONITOR

17.3.6 Other station CPU RUN status monitor

This section describes the other station CPU RUN status monitor screen and the function of on-screen keys. This option is not selectable when connecting to a remote I/O network system.

(1) (1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97* /960GOT.</p> <p>(Display example)</p>

No.	Contents of Display
1)	Up to 64 station numbers are shown.
2)	Any station in an abnormal condition is highlighted on-screen.

(2) Key Functions

The table below shows the function of keys that are used on the other station CPU RUN status monitor screen.

Key	Function
RET	Returns to the own station monitor screen.
END	Exits the other station CPU RUN status monitor screen and returns to the previous monitor screen where the network monitor function was executed.

17.3.7 Other station loop status monitor

This section describes the other station loop status monitor screen and the function of on-screen keys.

* This option is not selectable when connecting to a MELSECNET/B or MELSECNET (II) local station or establishing MELSECNET/10 coaxial bus connections.

(1) Display contents

When the A985/97*/960GOT is used	When the A95*/956WGOT is used
	<p>The display details are the same as the ones on the A985/97*/960GOT.</p> <p>(Display example)</p>

No.	Contents of Display
1)	The F-loop (primary loop) status and the R-loop (secondary loop status) are displayed.
2)	Station numbers are shown up to the maximum number of linked stations.
3)	Any station that stays in an abnormal condition is highlighted on-screen.
4)	A station specified as a reserved station is treated as a station that stays in a normal condition.

(2) Key Functions

The table below shows the function of keys that are used on the other station loop status monitor screen.

Key	Function
RET	Returns to the own station monitor screen.
END	Exits the other station loop status monitor screen and returns to the previous monitor screen where the network monitor function was executed.

18 ERROR MESSAGES FOR NETWORK MONITOR

The following chart shows the error messages that are displayed during the network monitor operation and how to handle them.

Error message	Contents of error	Action to take
Can not Communication	Communication could not established with the PLC CPU.	<ul style="list-style-type: none">• Check the connections between the PLC CPU and the GOT for disconnected connectors and cables.• Check if an error has occurred in the PLC CPU.
Key Word error	The PLC CPU to be connected is keyword-protected by the QnA.	<ul style="list-style-type: none">• Release the keyword.


19 OPERATING LIST EDITOR

This section describes the operation procedures for use of list editor function.

19.1 Operation procedures before starting the list edit


Procedures for transferring the operating system (OS) for the list editor function from the personal computer to the GOT and for installing the system into the memory.

For details, refer to the GT Designer2 Version2 Operating Manual. Detailed information including displays and key operations is provided.



19.2 Operation procedures from user-created monitor screen display to starting list editing


This section explains how you should operate the GOT to access the list editor function after having installed the list editor function operating system (OS) to the GOT internal memory.




19.2.1 Operation of keyword input

If a keyword is registered in the ACPU when the connected ACPU or the ACPU PLC No. corresponding to the operation is changed, the GOT requests for input of the registered keyword. Input the keyword registered in the ACPU and press the **GO** key. If a keyword is not registered in the ACPU, this operation is not required.

(The operation automatically changes to Selection of Function and Mode in 19.2.2.)



*1 When the input keyword does not match with the registered keyword, only the following operations in Chapter 20 can be allowed.



Point

- For operations not shown in other modes, clear (delete) the registered keyword with the "PLC memory all clear" in the following page if you do not remember the keyword registered in the ACPU. When "PLC memory all clear" is performed, the user data including sequence program is also cleared.
- The keyword registered in the ACPU can be changed or a new keyword can be registered as shown in Chapter 20.

When input of a keyword is requested, all parameters and sequence programs can be cleared together with the keyword registered in the ACPU using the operation below.

(Step 1) Display the keyword input request.

```
KEYWORD= [      ]
```

(Step 2) Stop operation of ACPU


(Step 3) Operation of PC memory all clear

Input "ALLCLR" and press the key.

→ → → → → →

(Step 4) Display of P3C memory all clear process

When the GOT starts clearing the process, the display in the left appears. "*" column and the total number of bytes change sequentially.



(Step 5) Completion of PC memory all clear process

When the GOT completes the clearing process, the screen in the left appears. (status before the mode selection)

```
** MODE SELECTION **
(READ) (INS) (PARAM)

PRESS MODE KEY
```

(Step 6) Select the mode as in 19.2.2 and start the following operation.

19.2.2 Selection and operation of mode

After the keyword input, select the mode in the list editor function for operations in Chapter 20.

(1) Selection and change of mode with mode key

Select the mode with the mode key (Refer to Section 3.5.5.) so that operation corresponding to the mode in Chapter 20 may be performed.

The mode can be freely changed when operations in Chapter 20 are performed. Various operations can be continued while changing modes. *1

<input type="checkbox"/> Read	-----	Read mode
<input type="checkbox"/> WRITE	-----	Write mode
<input type="checkbox"/> INSERT	-----	Insert mode
<input type="checkbox"/> DELETE	-----	Delete mode
<input type="checkbox"/> PARAM	-----	Parameter mode
<input type="checkbox"/> OTHER	-----	Other mode

*1 Mode key input is always valid.

Input of the mode key clears the input data except for the step numbers. The display returns to the initial status of the mode selection.

(2) Operation in each mode

The mode selected in (1) allows for operation corresponding to the mode in Chapter 20. Operation procedures of each mode are described in Chapter 20. Operate the GOT according to the description.

If an error message appears during operation, take action according to Chapter 21.

20 OPERATION OF EDITING SCREEN FOR EACH LIST

This section describes the operation procedures of the list edit screen.

20.1 Basic operation of key input

After starting the list editor function, basic operations of key input are described.

20.1.1 Switching of valid key (function indicated at the upper/lower part of the key)

When the list edit has started, whether the upper or the lower key available for two purposes is valid is displayed on the second line at the left end of the display. The GOT controls and displays the valid key. A user may switch the valid key with the following keys.

SHIFT *: Upper character key is valid.

Set Up : Lower character key is valid.

* The following keys can be input if the valid key is at the lower character.

(Input of **SHIFT** key is not required.)

- Comparison symbol key at the command input of comparison operation instruction.

<, **<**, **=**

- Minus key at the source data of command.

-

The valid key after setting each mode switches as follows:

Read mode, Write mode, Insert mode	:Upper character key (When the cursor position is at the setting value and the device step is in the Write mode, the "lower character" key is valid.)
Parameter mode and other modes	:Always lower character key
Help of each mode	:Always lower character key (When "Command Read" is selected from the Help in the Read mode, the upper character key is valid.)

When **SHIFT** key is input and the valid key is switched, the switched side is valid until the mode key and the control key are input.

For details of each key, refer to Section 3.5.4.

20.1.2 Command input procedures

Command input procedures can be classified as follows:

- 1) Input the command key to use the command on the key.
- 2) Input the alphanumeric keys corresponding to each character of command sequentially.
- 3) Select and input the command to be used from the Help function.

Command input procedures for 1) and 2) above are as follows.

For command input procedure 3) from the Help function, refer to Section 20.2.5.




When the command is input, the input details are displayed at the 4th line (the bottom line) on the display. In the following description, the input of key may be omitted when a blank space between the input command and the cursor position is automatically inserted. Refer to the example in each description.

(1) For command code only

1) When the command available on the keyboard is input


Command → GO

(Ex) When END is input



2) When the command not available on the keyboard is input


(Ex) When FOR K5 is input



(2) For command code and device (1)

Command → → DEVICE → DEVICE No. →


(Ex) When LD X0 is input




(3) For commands other than above

Input the key between the command and the device, the source data, and the destination data.


(Ex 1) When FMOV K-2 DO K5 is input




(Ex 2) When OUT T1 K10 is input




(Ex 3) When MC N3 M5 is input



(Ex 4) When LD = K10 D10 is input



(Ex 5) When ANDD<=H7FFFF D20 is input



(4) Handling of devices M, L and S

Devices M, L and S in the Test, Monitor, Write and Insert modes change the display depending on the set parameters.

If LD L0 is input for the parameter setting of M0 to 999 and L1000 to L2047, the result is LD M0.

- (5) For extension timer/extension counter of AnA and AnUCPU
 When the extension timer (T256 to T2047) and the extension counter (C256 to C1023) are input as the first device of the command, input the first device and the device number.
 (Ex) When OUT T256 D500 is input

```

W      9 9 0 U T      M 1 0
▲
1 0 0  L D
1 0 1  ► N O P
1 0 2  N O P
  
```



```

W      1 0 1 0 U T      T 2 5 6
▲
1 0 2  D 5 0 0
1 0 3  ► N O P
1 0 4  N O P
  
```

← The device (D500) for the T256 setting value on the parameter is automatically displayed.

Point 

When the extension timer and the extension counter are used, be sure to set the 257 points or more and the setting value device (D, W, R) on the parameter for both the timer and the counter.

20.1.3 Action if an incorrect key is input

- (1) Input the key before the key. Then input the correct key.

Input of the key clears the command and the device number that have been input immediately. The display returns to the status (status before change in the Write mode) when the mode is selected.

- (2) When the key is input, repeat the intended operation.

Command input procedures can be classified as follows:

Remark

When the key is input in the parameter mode, the GOT stops the process.

To continue the operation, carry on the key input.

20.2 Basic operation of list edit

This section describes basic operations of list edit with simple operation examples.

20.2.1 Reading sequence program

The sequence program is read to check its content.

[Operation example]


1) <input type="button" value="Read"/>	<pre>R 7 D20 ^ 14 END 15▶NCP 16 NCP</pre>	Select the "Read" mode.
2) <input type="button" value="SET"/> → <input type="button" value="0"/> → <input type="button" value="GO"/>	<pre>R 0▶LD X0000 ^ 1 OR Y0010 2 ANI X0001 3 OUT Y0010</pre>	Read the 0th step.
3) <input type="button" value="GO"/>	<pre>R 3 OUT Y0010 ^ 4▶OUT T0 4 K10 5 LD T0</pre>	

↓


Scroll the screen with the key.

20.2.2 Changing (overwriting) command

The following example shows the changing procedure of the sequence program.




[Operation example]



20.2.3 Adding (inserting) command

The following example shows the procedure of adding the command to the sequence program.



[Operation example]

- 1) **INSERT**

```

| 4 OUT T0
^ 4 K100
5▶ LD T0
6 ANI M0

```

Select the "Insert" mode.

- 2) **SET** → 1 → 4 → **GO**

```

| 7 D20
^ 14▶ END
15 NOP
16 NOP

```

Read the 14th step to insert the command.

- 3) **MOV** → **D** → 2 → 0 → **SP** → **K**

```

| 14 D20
^ 14 K2Y0018
19▶ END
20 NOP


```

↓

The command of "MOV D20 K2Y0018" was added to Step 14.

20.2.4 Deleting command

The following example shows the procedure of deleting the command from the sequence program.



[Operation example]

- 1) SHIFT → DELETE

D	14	D20
▲	14	K2Y0018
	19	END
	20	NOP

Select the "Delete" mode

- 2) SET → 6 → GO

D	5	LD	T0
▲	6	ANI	MO
	7	+P	
	7	K80	

Read the 6th step

- 3) GO

D	5	LD	T0
▲	6	+P	
	6	K80	
	6	K5	

The GO key deletes the command at the cursor position.
The step number is brought forward.

⇩

The "ANI MO" command was deleted.

20.2.5 Using Help function

[HELP] is input to use the Help function.

Input of [HELP] displays the Help function menus in each mode. Select the corresponding item for execution.

- (1) Reading the command in the sequence program
 Example of reading the area using the "MOV" command in the sequence program.

[Operation example]

1) [Read] → [HELP]	<pre>***HELP MENU*** 1: READ 2: COMMENT DISPLAY CLEAR:END</pre>	Input the [HELP] key in the Read mode.
2) [1]	<pre>*** READ *** 1/2 1: STEP 2: INSTRUCTION CLEAR:END HELP:MENU</pre>	Select "Read".
3) [2]	<pre>*** READ *** KEY IN STEP NO. [] CLEAR:END HELP:MENU</pre>	2: Select "Command".
4) [MOV]	<pre>*** READ *** KEY IN STEP NO. [MOV] CLEAR:END HELP:MENU</pre>	Set the "MOV" command.
5) [GO]	<pre>R 6 D20 ^ 13▶MOV 13 D20 13 K2Y0018</pre>	Reading "MOV D20 K2Y0018" of the 13th step.
6) [GO]	<pre>R 6 D20 ^ 13▶MOV 13 D20 NOT FOUND</pre>	Message when the "MOV" command is not present after the 13th step.
<p>↓</p> <p>Now, reading the command with the Help function command specification is completed.</p>		

(2) Displaying Kana comment

The following example shows the procedure of displaying the Kana comment in the Read mode.

[Operation example]

1) <input type="text" value="HELP"/>	<pre>***HELP MENU*** 1: READ 2: COMMENT DISPLAY CLEAR:END</pre>	Input the <input type="text" value="HELP"/> key in the Read mode.
2) <input type="text" value="2"/>	<pre>***COMMENT DISP.*** 1: YES 2: NO CLEAR:END HELP:MENU</pre>	2: Select the Kana comment display.
3) <input type="text" value="1"/>	<pre>R 0 LD X0000 ^ 1 OUT Y0020 2 LD X0000 Motor start limit</pre>	Select "1: Kana comment display". Display the Kana comment of the device at the cursor position.
4) <input type="text" value="↓"/>	<pre>R 0 LD X0000 ^ 1 OUT Y0020 2 LD X0000 Motor start check</pre>	

20.3 Operation procedure list of list edit

20.3.1 Common operation

Details		Purpose	Procedures (key input sequence)
Basic operation	Input of keyword at start-up	Input when the keyword is registered in the ACPU.	Keyword → GO
	Mode selection	Select the mode.	Mode key (READ , INSERT , PARAM) SHIFT → Mode key (WRITE , DELETE , OTHERS)
	Switching of valid key	Switch the valid key (function indicated at the upper/lower part of the key) by a user.	SHIFT or SET
	Action for incorrect input	Perform the operation for incorrect key input.	CLEAR , Mode key or SHIFT → Mode key
	Operation of command help function	Perform operation with the Help function command specification.	Perform program display → HELP → 1 → 1 → 1 → Input the capital letter of the command.
	Display of Comment	Display the comment stored in the ACPU.	Perform program display operation → HELP → 2 → 1
Command input operation	Command code only	Input the command code only.	Command → GO
	Command code and 1 device	Input the command code and 1 device.	Command → SP → Device → Device No. → GO
	Other than above command key input)	Input the command other than above with the command key.	Input the SP between the device, the source data and the destination.
	Other than above (device key input)	Input the command other than above without the command key.	Input the SP between the command, the device, the source data and the destination.

20.3.2 Operation in Write mode (W)

Details		Purpose	Procedures (key input sequence)
Continuous write in NOP	Set the specified range in the program to NOP.	Program display in the Write mode	
Write/modify (change) of program	Write the new program/modify (change)		

17
 USING THE NET-
 WORK MONITOR
 SCREENS
 18
 ERROR MESSAGES
 FOR NETWORK
 MONITOR
 19
 OPERATING LIST
 EDITOR
 20
 OPERATION OF
 EDITING SCREEN
 FOR EACH LIST
 21
 ERROR MESSAGES
 FOR LIST EDITOR
 22
 OPERATING
 MOTION MONITOR
 23
 OPERATIONS OF
 VARIOUS MOTION
 MONITOR SCREENS
 24
 ERROR MESSAGES
 FOR MOTION MONI-
 TOR

20.3.3 Operation in Read mode (R)

Details	Purpose	Procedures (key input sequence)
Command reading with the specified step number	Read the command of the specified step number in the program.	READ → SET → Step number → GO → GO
Read the command with the specified command.	Read the specified command in the program.	READ → Command → Device → Device number → GO → GO
Read the command with the specified device.	Read the command with the specified device used in the program.	READ → SET → Device → Device number → GO → GO
Automatic scroll	Display the program with automatic scroll.	Read operation above → SET → ↑ ↓ → SET → Step number → ↑ ↓ → SET → SP → ↑ ↓

20.3.4 Operation in Insert mode (I)

Details	Purpose	Procedures (key input sequence)
Insert a command in the program.	Insert a command in the program.	INSERT → SET → Step number → GO → Command → GO
Move the program.	Move the whole program.	Display the program → HELP → 1 → 2 → Specify the movement start step. GO → Specify the movement end step. → GO → Specify the movement destination step. → GO
Copy the program.	Copy the program.	Display the program → HELP → 1 → 3 → Specify the copy start step. GO → Specify the copy end step. → GO → Specify the copy destination step. → GO

20.3.5 Operation in Delete (D) mode

Details	Purpose	Procedures (key input sequence)
Delete a command from the program.	Delete a command from the program.	SHIFT → DELETE → SET → Step number → GO → GO
Delete the specified range of the program.	Specify the range of the program for deletion.	Display the program → HELP → 1 → 1 → Specify the deletion start step. GO → Specify the deletion end step. → GO
Delete the whole NOP.	Delete the whole NOP in the program.	Display the program → HELP → 1 → 2

20.3.6 Operation in Parameter mode (P)

Details	Purpose	Procedures (key input sequence)
Clearing all parameters	Return the parameters to the initial setting status.	PARAM → 1 → ↑ → GO → END → ↑ → GO
Parameter setting (for A0J2HCPU)	Set the parameters for the A0J2HCPU.	PARAM → 2 → 1)
Setting of latch range	Select the latch range from "No latch", "1/2 latch" and "All latch".	1) → 1 →  → GO → 2)
Setting of step relay	Set the availability (S1536 to 2047) of the step relay.	1) → 2 →  → GO → 2)
Completion of setting (write)	When the parameter setting is complete, write the PLC CPU.	2) → CLEAR → END → ↑ → GO (End of writing is displayed.)
Parameter setting (other than A0J2HCPU)	Set the parameters other than A0J2HCPU.	PARAM → 2 → 1)
Setting of memory capacity	Set the main sequence program capacity and the file register capacity.	1) → 1 → Capacity → GO → END → 2) (For main, input unit: 1K step) 1) → 1 → ↓ → Capacity → GO → END → 2) (For sub, input unit: 1K step) 1) → 1 → ↓ → points → GO → END → 2) (For file register, input unit: 1K point)
M, L, S setting (other than AnA, AnUCPU)	Set the top device number used in the latch relay/step relay.	1) → 2 → Top number of L → GO → Top number of S → GO → 2)
M, L, S setting (AnA, AnUCPU only)	Set the top device number used in the latch relay/step relay/internal relay.	1) → 2 → Top number of L → GO → Top number of S → GO → Top number of M → GO → 2)
Timer setting (other than AnACPU)	Set the top device used in the low speed/high speed/retentive timers.	1) → 3 → Top number of timer → GO → 2)
Timer setting (AnACPU)	Set the number of timers used, the top device number that stores the setting value after T256, and the top device used in the low speed/high speed/retentive timers.	1) → 3 → No. of timers → GO → Top device for storage of setting values → GO → Top number of timer → GO → 2)
Counter setting (AnACPU only)	Set the number of counters used, and the top device number that stores the setting value after C255.	1) → 4 → No. of counters → GO → Top device for storage of setting values → GO → 2)
Setting of latch range	Set the range of the device for latch setting.	1) → 5 →  → Top number of latch → GO →  → End number of latch → GO → END → 2)
WDT setting	Set the value of the watchdog timer in the unit of 10 ms.	1) → 6 → WDT value → GO → 2) (input unit: 10 ms)

17 USING THE NET-WORK MONITOR SCREENS
 18 ERROR MESSAGES FOR NETWORK MONITOR
 19 OPERATING LIST EDITOR
 20 OPERATION OF EDITING SCREEN FOR EACH LIST
 21 ERROR MESSAGES FOR LIST EDITOR
 22 OPERATING MOTION MONITOR
 23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24 ERROR MESSAGES FOR MOTION MONITOR

Details	Purpose	Procedures (key input sequence)
Parameter setting (other than A0J2HCPU)	Set the parameters other than A0J2HCPU.	PARAM → 2 → 1)
Setting of I/O control system (only for A3HCPU and A3MCP)	Set the I/O control system.	1) → 7 → ↑ → GO → 2) ↓
Completion of setting (write)	When parameter setting is complete, write the PLC CPU.	2) → CLEAR → END → ↑ → GO (End of writing is displayed.)

20.3.7 Operation in Other modes (O)

Details	Purpose	Procedures (key input sequence)
Error check	Operation that checks the error step number/error code for the current error in the ACPU. (other than AnA and AnUCPU)	SHIFT → OTHER → 2 → 1 → ↑ → ↓ (Except AnA, AnUCPU) (AnA, AnUCPU)
Program check	Check the program (double coil, command code, END command).	SHIFT → OTHER → 2 → 2 → GO → Step number → ↑ → GO
Buffer memory batch monitoring	Monitor the buffer memory details of the special function unit.	SHIFT → OTHER → 3 → 1 → 2 → Y → Top I/O number of unit → SP H → Buffer memory → GO → ↑ → ↓ K → address
Clock monitor	Monitor the clock data of the ACPU.	SHIFT → OTHER → 3 → 1 → 3
Clearing of all PC memories	Clear all memories in the ACPU.	SHIFT → OTHER → 3 → 2 → GO → ↑ → GO
Clearing of all programs	Clear all sequence program, microcomputer program and T/C setting value areas.	SHIFT → OTHER → 3 → 2 → 2 → ↑ → GO
Clearing of all device memories	Clear all details of the bit device and the word device in the ACPU.	SHIFT → OTHER → 3 → 2 → 3 → ↑ → GO
PLC No. setting	Set the PLC No. of other stations for access on the MELSECNET II (/B) or MELSECNET/10.	SHIFT → OTHER → 3 → 3 → 1 → END 1 → PC No. → GO 2 → Network No. → GO → Station No. → GO 3 →
Main/sub-program switching	Select the main/sub-program displayed on the list edit screen.	SHIFT → OTHER → 3 → 3 → 2 → ↓ → ↑ → GO
Remote run/stop	Operate the run/stop status of the ACPU from the GOT.	SHIFT → OTHER → 3 → 4 → 1 → ↓ → ↑ → GO

Details	Purpose	Procedures (key input sequence)
Read/write of machine language	Specify the memory address (absolute address) of the ACPU. Read the memory details and write the machine language to the memory.	<pre> graph LR subgraph Reading_Procedure R1[SHIFT] --> R2[OTHER] R2 --> R3[3] R3 --> R4[4] R4 --> R5[3] R5 --> R6[SET] R6 --> R7[Address (hexadecimal)] R7 --> R8[GO] R8 --> R9[GO] R9 --> R10[Down Arrow] R10 --> R11[Up Arrow] end subgraph Writing_Procedure W1[SET] --> W2[Address (hexadecimal)] W2 --> W3[GO] W3 --> W4[GO] W4 --> W5[Down Arrow] W5 --> W6[Up Arrow] W6 --> W7[Machine language code] W7 --> W8[GO] end </pre>

17	USING THE NET- WORK MONITOR SCREENS
18	ERROR MESSAGES FOR NETWORK MONITOR
19	OPERATING LIST EDITOR
20	OPERATION OF EDITING SCREEN FOR EACH LIST
21	ERROR MESSAGES FOR LIST EDITOR
22	OPERATING MOTION MONITOR
23	OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
24	ERROR MESSAGES FOR MOTION MONI- TOR

21 ERROR MESSAGES FOR LIST EDITOR

21.1 Error detected with the list editor function

If an error is detected with the list editor function during operation of each mode, an error message appears at the 4th line of the display.

Error messages, display conditions and corrective actions are displayed below. If an error message appears, take the following actions to resume operation.

- 1) Check the error message.
- 2) Remove the cause of the error.
- 3) Input the corresponding key.

(The error message disappears. The screen returns to the status before error.)

(Example)

R	0	▶	L D	X 0 0 0 0
▲	1		0 R	Y 0 0 2 0
	2		A N I	M 1 0 0
	3		0 U T	Y 0 0 2 0

→ → →

..... Reading the step with the RST command.

R	0	▶	L D	X 0 0 0 0
▲	1		0 R	Y 0 0 2 0
	2		A N I	M 1 0 0
NOT FOUND				

← Display the error message.

..... Delete the error message.

R	0	▶	L D	X 0 0 0 0
▲	1		0 R	Y 0 0 2 0
	2		A N I	M 1 0 0

← The error message disappears.
The next operation is resumed.

Error message	Display condition	Action
Address error	<ul style="list-style-type: none"> In machine language writing, the address which was tried to be written was at the write-protect area. 	<ul style="list-style-type: none"> Set the correct address.
No corresponding program	<ul style="list-style-type: none"> The specified command was not found. 	<ul style="list-style-type: none"> Check the program.
Memory cassette check	<ul style="list-style-type: none"> In communication with the CPU for clearing the keyword or writing the parameter, the memory cassette is insufficient or not mounted. 	<ul style="list-style-type: none"> Mount the memory cassette properly. Replace the memory cassette with a new one.
Step over error	<ul style="list-style-type: none"> The set step number is larger than the maximum step number. 	<ul style="list-style-type: none"> Set the correct step number.
Setting error	<ul style="list-style-type: none"> Setting value is not correct. 	<ul style="list-style-type: none"> Set the correct value.
Not selectable	<ul style="list-style-type: none"> The function which cannot be executed was selected. 	<ul style="list-style-type: none"> Select other function.
Operation error	<ul style="list-style-type: none"> The set device symbol is incorrect. 	<ul style="list-style-type: none"> Perform the correct key operation.
Device error	<ul style="list-style-type: none"> The specified command was not found. The device number exceeds the range. 	<ul style="list-style-type: none"> Set the correct device symbol. Set the number within the range of CPU device.
Identical coil	<ul style="list-style-type: none"> The identical coil is found in the sequence program. 	<ul style="list-style-type: none"> Proceed to the next operation if it does not affect the control. Correct the program if it affects the control.
Command error	<ul style="list-style-type: none"> When the program is read, it cannot be converted to the proper command. 	<ul style="list-style-type: none"> When the CPU has detected the error, stop running of the operation. After resetting the CPU, check the command around the error. Write the correct command. (For check of the error step, refer to Section 20.3.7.)
Command setting error	<ul style="list-style-type: none"> The command set at the time of read, write or insert is not correct. 	<ul style="list-style-type: none"> Set the correct command.
Memory protect	<ul style="list-style-type: none"> When writing in the Write or the Insert/Delete mode, the memory protect switch in the memory cassette is ON. 	<ul style="list-style-type: none"> Turn OFF the memory protect switch in the memory cassette.
Capacity over	<ul style="list-style-type: none"> Memory assignment set in the parameter exceeded the capacity of the memory cassette. 	<ul style="list-style-type: none"> Set the parameter within the capacity of the memory cassette.
No END command	<ul style="list-style-type: none"> There is no END command. 	<ul style="list-style-type: none"> Write the END command at the last step of the program.
PLC communication error	<ul style="list-style-type: none"> When the list editor function is started, proper communication with the PLC is not made. 	<ul style="list-style-type: none"> Restart the list editor function. If communication is not made properly, check the following: GOT main unit Connection of the cable CPU main unit (if any error has occurred)
PC write error	<ul style="list-style-type: none"> Correct writing was not made in the Write or Insert mode. 	<ul style="list-style-type: none"> Check the setting of RAM/ROM. Check the RAM mounting. Check the setting of the memory protect switch in the CPU.
PLC is running	<ul style="list-style-type: none"> Writing, insertion or deletion was attempted during running of the CPU. 	<ul style="list-style-type: none"> Stop the CPU.
PC No. error	<ul style="list-style-type: none"> The PLC number is set to other station. 	<ul style="list-style-type: none"> Change the PLC number and set the station for access to the host.

Error message	Display condition	Action
**KS over	<ul style="list-style-type: none"> The value exceeding the range of the program capacity by **K steps was attempted to be set. 	<ul style="list-style-type: none"> Reduce the program capacity by **K steps for setting.
**KP over	<ul style="list-style-type: none"> The value exceeding the range of the file register capacity by **K points was attempted to be set. 	<ul style="list-style-type: none"> The value exceeding the range of the file register capacity by **K points was attempted to be set.
Not available for QnACPU. Set the PLC No.	<ul style="list-style-type: none"> The CPU at the list edit destination is QnACPU. 	<ul style="list-style-type: none"> Set the PLC number and change the station for access.
The keyword is not input. Set the PLC No.	<ul style="list-style-type: none"> The GO key was pressed without input of the keyword on the keyword input screen. 	<ul style="list-style-type: none"> Set the PLC number and change the station for list edit. Or select the same station and input the keyword.
The PLC parameter was changed. Restart the GOT system.	<ul style="list-style-type: none"> The PLC parameter exceeding the file (R) register capacity was set. 	<ul style="list-style-type: none"> Restart the GOT system if required.
The PLC parameter was changed. Read the ladder monitor again.	<ul style="list-style-type: none"> The capacity of the file (R) register was set. 	<ul style="list-style-type: none"> Read the ladder monitor on the PLC again if required.
The PLC program was edited. Read the ladder monitor again.	<ul style="list-style-type: none"> Edit the PLC program. 	<ul style="list-style-type: none"> Set the PLC number and change the station for access.

21.2 Error of PLC CPU

When the error step read in other mode is performed, the error message and the error step of the current error in the ACPU are displayed.

Error messages, error details and corrective actions are displayed below. If an error message appears, take the following actions to resume operation.

- 1) Check the error message.
- 2) If the error code is not displayed, check the error code of special register D9008 with the system monitor function (Refer to Section 8.).
- 3) Remove the cause of the error.

(Display)

Example of display for an error in the CPU other than AnA and AnU

0	ERR . STEP =	2 5
	SP . UNIT DOWN	
	ERR . CODE =	4 1

Annotations:

- Mode is displayed (other mode).
- Error step number is displayed (step number of D9010).
- Error message is displayed.
- Error code is displayed (error code of D9008).

Example of display for an error in the AnA or AnUCPU

0	ERR . STEP =	2 5
	SP . UNIT DOWN	
	ERR . CODE =	4 1
	ERR . INFO =	4 1 1

Annotations:

- Mode is displayed (other mode).
- Error step number is displayed (step number of D9010).
- Error message is displayed.
- Error code is displayed (error code of D9008).
- Error detail code is displayed (error code of D9091).
- Error history if available is displayed.

Example of next display for the display of "_" above (error history is available)

0	ERR . STEP =	0
1	AC DOWN	
	ERR . CODE =	9
	9 9 / 0 7 / 1 2 1 1 : 5 5 : 1 0	

Annotations:

- Mode is displayed (other mode).
- Error history number is displayed (history control No. of ACPU).
- Error step number is displayed.
- Error message is displayed.
- Error code is displayed.
- Error detail code is displayed.
- Second, minute, hour, date, month and year of the error are displayed.
- Displayed if other error history is available.

Point

When an error message of the PLC CPU appears, refer to the ACPU programming manual (Common Command) and the user's manual for each CPU for corrective actions.

17 USING THE NET-
WORK MONITOR
SCREENS

18 ERROR MESSAGES
FOR NETWORK
MONITOR

19 OPERATING LIST
EDITOR

20 OPERATION OF
EDITING SCREEN
FOR EACH LIST

21 ERROR MESSAGES
FOR LIST EDITOR

22 OPERATING
MOTION MONITOR

23 OPERATIONS OF
VARIOUS MOTION
MONITOR SCREENS

24 ERROR MESSAGES
FOR MOTION MONI-
TOR

21.3 Error using list editor function on the link system

When the list editor function is used on the link system, the "PLC communication error (**)" may appear. In this case, check the error details and the corrective actions.

Error No.	Error message	Action
2	Time-out error: No response to the request	Check the cable wiring.
4	Process cancel: New process request was given to the list editor function while the CPU is processing.	Perform correct key operations on the GOT.
5	Sum check error: A sum check error from the link communication has occurred.	There may be noise interference. Check the system again.
16	PLC No. error: There is no station corresponding to the PLC number.	Check the PLC number setting. Set the correct number.
19	This error may occur when the ACPU is reset during monitoring.	Perform the monitor setting again.
24	Remote error: Although remote stop/pause is performed from the computer link unit, remote run/stop is additionally performed.	Perform the remote run/stop/pause from either unit.
32	Link error: While the slave station is monitoring the master station, the master station is reset.	Perform the monitor setting again.
34	EEPROM failure: The EEPROM, cannot be written due to EEPROM failure.	Replace the EEPROM with a new one.

If error number "25" appears, the following causes are possible. Check the details and the corrective actions.

(1) When connected to the master station

Device number	Description	Details	
M9210	Link card error (for master station)	OFF: Normal ON : Error	The control depends on whether there is an error at the hardware of the link card. The link card in the CPU link unit is judged at the CPU. Replace the link unit.
M9224	Link status	OFF: Online ON : Offline, station-to-station test, or self-loopback test	The control depends on whether the master station itself is online or offline, or in the station-to-station mode or the self-loopback mode. Check the mode switch.
M9227	Loop test status	OFF: Not executed ON : Normal loop test and sub-loop test are being executed.	The control depends on whether the master station itself is executing the normal loop test or the sub-loop test.

(2) When connected to the local station

Device number	Description	Details	
M9211	Link card error (for local station)	OFF: Normal ON : Error	The control depends on whether there is an error at the hardware of the link card. The link card in the CPU link unit is judged at the CPU. Replace the link unit.
M9240	Link status	OFF: Online ON : Offline, station-to-station test, or self-loopback test	The control depends on whether the local station itself is online or offline, or in the station-to-station mode or the self-loopback mode. Check the mode switch.
M9257	Loop test status	OFF: Not executed ON : Normal loop test and sub-loop test are being executed.	The control depends on whether the local station itself is executing the normal loop test or the sub-loop test.

- (3) When connected to the CPU in MELSECNET/10
An error in the MELSECNET/10 is reported using a four digit (hexadecimal) error number.
For details of the errors and corrective actions, see the MELSECNET/10 Network System Reference Manual.

Point 

If an error code not listed in the previous page is displayed, contact the nearest of our system service centers, agents, and branch offices.

17	USING THE NET- WORK MONITOR SCREENS
18	ERROR MESSAGES FOR NETWORK MONITOR
19	OPERATING LIST EDITOR
20	OPERATION OF EDITING SCREEN FOR EACH LIST
21	ERROR MESSAGES FOR LIST EDITOR
22	OPERATING MOTION MONITOR
23	OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
24	ERROR MESSAGES FOR MOTION MONI- TOR


22 OPERATING MOTION MONITOR

The operation procedure when using the motion monitor function is explained in this chapter.

22.1 Operation procedures before starting motion monitoring


This section contains a summary of the procedure for transmitting the system program (OS) for the motion monitor function and the motion monitor data from the personal computer to the GOT until it is installed in built-in memory.

For details, please refer to the GT Designer2 Version2 Operating Manual. Details of the screen display and key operation are shown in the Help.



22.2 Operation procedures from user-created monitor screen display to start of motion monitor


This section describes the operation procedure for the GOT when starting each operation of the motion monitor function after the system program (OS) of the motion monitor function has been installed in the GOT built-in memory, and downloading the motion monitor data.



... (*1)
 ... When starting, the module format and related data are not displayed. When reading of module data from the PLC CPU is complete, the module format and related data is displayed. When **END** is selected, the motion monitoring ends and the display moves to the original screen where the motion monitor function was begun.


... See Section 23.1

*1 Touch the key where the touch switch (expanded) function was set with the drawing software, and start the system monitor function. When the Utility screen is displayed, touch **MOTION MON.** to start the motion monitor function.



22.2.1 Password entry operation procedure

With the motion parameter changing password written to the GOT using GT Designer2, the password entry screen appears if you attempt to access the parameter setting screen of the motion monitor function.



(1) Features

- If the characters entered match a password, the Parameter Setting screen appears.
- If the characters entered do not match a password, an error message appears on-screen. Touching  will return to the previous monitor screen.
- Numerical numbers and alphabets  to  can be used for a password.
- Use GT Designer2 to set the motion parameter changing password. Refer to the GT Designer2 Version2 Reference Manual for details of password setting.

(2) Procedure

(a) To enter a password, follow these steps:

- Touch  to  and  to  to enter a password.
- Touch  to confirm the password entered.
- To correct the password entered, touch  to delete wrong characters and then enter correct characters again.

(b) To quit entering a password:

- Touch  to return to the previous monitor screen.

23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS

This chapter explains screen operations to be performed when using the motion monitor function. The display screen of the motion monitor function varies slightly with the GOT used. This chapter mainly uses the screen of the A975GOT for explanation.


23.1 Screen layout, common operations and screen changes for monitoring

This section describes the screen layout and common operations for execution of motion monitoring.

23.1.1 System configuration screen layout and key functions

This section explains the layout of the system configuration screen that is displayed after starting the motion monitor function and the key functions that appears on-screen.

(1) Displayed data



1)	The CPU No. is displayed as the CPU and the control CPU No. as the loaded module. (Only the CPU is displayed when the A95*GOT/A956WGOT is used.) To choose the motion controller CPU for servo monitor/servo parameter setting, touch its display position.
2)	The keys used for performing operation on the system configuration screen, shown in (2), are displayed. (Touch input)

(2) Key functions

The following indicates the functions of the keys used for performing operation on the system configuration screen.

Key	Function
	Used to end monitoring and return to the screen where the motion monitor function was started.
	Used to select the motion controller CPU where servo monitor/servo parameter setting will be performed.
	Used to change the system configuration screen to the motion monitor menu screen. (Refer to Section 23.4)
	Used to change the system configuration screen to the parameter setting screen. (Refer to Section 23.5)
	Used to scroll the display data up/down one level to display the currently undisplayed, preceding/succeeding level of the system configuration.  : Scrolls down one level.  : Scrolls up one level.

17 USING THE NET-
WORK MONITOR
SCREENS

18 ERROR MESSAGES
FOR NETWORK
MONITOR

19 OPERATING LIST
EDITOR

20 OPERATION OF
EDITING SCREEN
FOR EACH LIST

21 ERROR MESSAGES
FOR LIST EDITOR


22 OPERATING
MOTION MONITOR

23 OPERATIONS OF
VARIOUS MOTION
MONITOR SCREENS

24 ERROR MESSAGES
FOR MOTION MONI-
TOR

23.2 Changing the screen


This section describes how to change the screen when executing each monitor function of the motion monitor function from the status where the user-created monitor screen is displayed.



23.3 Motion monitor

The motion monitor function allows you to monitor various servo monitor data on multiple monitor screens. To display any of the monitor screens, make selection on the monitor menu screen.

(Monitor menu screen)




- 1) Present Value Mon..... Monitors and displays the feed current values and actual current values of all running axes. (Refer to Section 23.3.1)
- 2) SFC Error History..... Displays the history of errors that occurred in SFC programs from when the motion CPU was powered on or reset. (Refer to Section 23.3.2)
- 3) Error List..... Displays the history of errors (eight latest errors) that occurred on and after the leading edge of PLC ready (M2000). (Refer to Section 23.3.3)
- 4) Error List Axis..... Displays the latest errors that occurred on the specified axis. (Refer to Section 23.3.4)
- 5) Positioning Monitor..... Monitors the details of the positioning data set to any axis. (Refer to Section 23.3.5)
- 6) Servo Monitor..... Monitors the servo motor/servo amplifier. (Refer to Section 23.3.6)
- 7) Present Value Hist..... Displays the history of encoder present values, servo command values and monitor present values of the ABS axis at servo amplifier power-on/off or at home position return. (Refer to Section 23.3.7)
(Not displayed when the A95*GOT is used.)

23.3.1 Display data and key functions of present value monitor screen

This section explains the display data of the present value monitor screen and the key functions displayed on-screen.

(1) Displayed data



No.	Item	Description
1)	Ax	The axis Nos. of the running axes being monitored are displayed.
2)	Actual PV Feed PV	The feed present values or actual present values of the running axes are displayed. Touching the display part of the monitored value switches to the positioning monitor screen of the touched axis No. (Refer to Section 23.3.5)
3)	SV RDY, ERR DT, SV ERR	Whether the servo ready signals, major/minor errors and servo error detection signals are ON (lit) or OFF (extinguished) are displayed. Touching the error indication part "●" switches to the error list designated-axis screen of the touched axis No. (Refer to Section 23.3.4)
4)	Bit device screen *1	The common bit devices are always monitored and displayed. <ul style="list-style-type: none"> • Error detection type bit devices Displayed red • General status type bit devices Displayed green

*1 Not displayed when the A95*GOT/A956WGOT is used.

(2) Key functions

The following indicates the functions of the keys used for operation of the present value monitor screen.

Key	Function
<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Feed PV</div> / <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-top: 5px;">Actual PV</div>	Touching the key alternates the monitor item between the "feed present value" and "actual present value". (Only in the real mode)
<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Mon. Menu</div>	Used to return to the monitor menu screen.
<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">END</div>	Used to end the present value monitoring and return to the screen that was being displayed when the motion monitor function was started.
<div style="display: inline-block; margin-right: 10px; text-align: center;">▲</div> <div style="display: inline-block; text-align: center;">▼</div>	Used to change the displayed axis No. (Displayed only for Q173CPU monitoring.)

23.3.3 Display data and key functions of error list screen

This section explains the display data of the error list screen and the key functions displayed on-screen.

(1) Displayed data

Error List					Mon. Menu	END
M/ D H: M	Ax	SV P. No.	Err Code	Error Definition	Set Data	
7/24 10:50		SV P 103	906	The unused axis was started.	906	
7/24 10:50	5	Ma J. 20	1004	At a start, sv.amp.pu.is OFF, initial processing, the amp. is not yet installed, a sv.err. occurred, or the cable is faulty.		
7/24 10:50		SV P 21	4	Command speed outside the range	4	
7/24 10:50		SV P 22	906	The unused axis was started.	906	
7/24 10:50		SV P 103	906	The unused axis was started.	906	
7/24 10:51	5	Ma J. 20	1004	At a start, sv.amp.pu.is OFF, initial processing, the amp. is not yet installed, a sv.err. occurred, or the cable is faulty.		
7/24 10:51		SV P 21	4	Command speed outside the range	4	
7/24 10:51		SV P 22	906	The unused axis was started.	906	

↑ ↑ ↑ ↑
1) 2) 3) 4)

No.	Item	Description
1)	H/D H: M	The dates and times when errors occurred are displayed.
2)	Ax	The axis Nos. and axis types of the axes where errors occurred are displayed. Virtual axis : Virtual Synchronous encoder axis : Sync
3)	SV P. No.	The servo program Nos. that were being executed at error occurrence are displayed. The execution destination of the servo program in error is not displayed. Using the servo program No., refer to the execution destination.
4)	Err Code	The types and error codes of the errors that occurred are displayed. The error types are displayed as indicated below. <ul style="list-style-type: none"> • Minor errorMinor • Major errorMajor • Servo errorServo • Servo program setting errorServo P • Real/virtual switchingSwitch • Test mode request errorTest • Manual pulse generator setting errorManual • PCPU ERRORP-WDT • SSCNET ERRORCommunication error
5)	Error Definition *1	The definitions of the errors that occurred are displayed.
6)	Set Data *1	The program number in error is displayed if the set data have any errors.

*1 Not displayed when the A95*GOT/A956WGOT is used.

(2) Key functions


The following indicates the functions of the keys used for operation of the error list screen.

Key	Function
	Used to return to the monitor menu screen.
	Used to end the error list and return to the screen that was being displayed when the motion monitor function was started.

23.3.4 Display data and key functions of error list designated-axis screen

This section explains the display data of the error list designated-axis screen and the key functions displayed on-screen.

(1) Displayed data




No.	Item	Description	
1)	1Ax	The axis No. currently monitored is displayed.	
2)	Out Module	The output module axis No. currently monitored is displayed.	
3)	Virt. Axis	The virtual axis No. currently monitored is displayed.	
4)	Syne. Enco.	The synchronous encoder axis No. currently monitored is displayed.	
5)	Program No.	The servo program No. that was being executed at error occurrence is displayed.	
6)	Err Code	The error codes of the minor/major/servo error, servo program setting error, real/virtual switching error information (error code: hexadecimal), personal computer link communication error code and motion CPU WDT error that are currently occurring are displayed.	
7)	Err Definition *1	The definitions of the errors that occurred are displayed.	
8)	MAN-PLS Axis ERR *1	Each 1-Pulse 1M Error	The axes where a 1-pulse input magnification setting error occurred are displayed.
		MAN-PLS AX ERR	The errors of the axis Nos. set to the manual pulse generators P1 to P3 are displayed.
		Each MAN-PLS SM ERR	The errors of the smoothing magnifications set to the manual pulse generators P1 to P3 are displayed.
9)	Test REQ ERR	The axis Nos. that are being started at a test mode request are displayed.	

*1 Not displayed when the A95*GOT/A956WGOT is used.

17 USING THE NETWORK MONITOR SCREENS
 18 ERROR MESSAGES FOR NETWORK MONITOR
 19 OPERATING LIST EDITOR
 20 OPERATION OF EDITING SCREEN FOR EACH LIST
 21 ERROR MESSAGES FOR LIST EDITOR
 22 OPERATING MOTION MONITOR
 23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24 ERROR MESSAGES FOR MOTION MONITOR

(2) Key functions

The following indicates the functions of the keys used for operation of the error list designated-axis screen.

Key	Function
 <p>(In real mode only),</p>  /   <p>(In virtual mode only) (Display example: When axis 1 is monitored)</p>	Used to change the axis to be monitored.
	Used to return to the previous screen.
	Used to return to the monitor menu screen.
	Used to end the error list designated-axis monitoring and return to the screen that was being displayed when the motion monitor function was started.

23.3.5 Display data and key functions of positioning monitor screen

This section explains the display data of the positioning monitor screen and the key functions displayed on-screen.

(1) Displayed data

(In real mode)

Positioning Monitor (Real)				RET	Mon.	END
Data Item	1Ax	MON Val	Status	CMD Signal		
Feed PV	359054	PLS	POS StartCompletion	Stop Command		
Actual PV	350127	PLS	POS Completion	Rapid Stop Command		
Dvt.Counter	927	PLS	In-Position	Forward JOG Start		
EXE Prog No.		4	Command In-Position	Reverse JOG Start		
Min/Major SV ERR	0· 0· 0		In-Position	Completion Sign. OFF		
M Code: T Limit	0· 300		Speed Controlling	Enable Speed/POS CHG		
			Speed/POS CHG Latch	Error Reset		
			Zero Point Passage	Servo Error Reset		
			Error Detection	Inval. STOP in Start		
			Servo Error Detect.	Feed PV Update Cmd.		
			ZERO Request	Servo OFF Command		
			ZERO Completion	FIN Signal		
			External Signal FLS			
			External Signal RLS			
			External Signal STOP			
			External Signal DOG/CHANGE			
			Servo ON/OFF Status			
			Torque Limiting Signal			
			M code Outputting			

(In virtual mode)

Positioning Monitor (Cam)				RET	Mon.	END
Data Item	1Ax	MON Val	Status	CMD Signal		
Feed PV	99999	PLS	In-Position	Error Reset		
Actual PV	53144	PLS	Zero Point Passage	Servo Error Reset		
Dvt.Counter	46855	PLS	Error Detection	Addr. Clutch Ref.		
Min/Major SV ERR	0·1000· 0		Servo Error Detect.	Cam Reference POS		
T Limit	300		ZERO Request	Servo OFF Command		
EXE Cam No.	1		ZERO Completion			
EXE Stroke	100000	PLS	External Signal FLS			
Cam Ax.1 Rev.	1011	PLS	External Signal RLS			
			External Signal STOP			
			External Signal DOG/CHANGE			
			Servo ON/OFF Status			
			Torque Limiting Signal			
			V Mode Cont.Op.Warning			

No.	Item	Description
1)	Data Item	The axis No. of the running axis being monitored is displayed. For the virtual axis, the axis type is displayed. <ul style="list-style-type: none"> • Roller • Ballscrew • Rotary table • Cam
2)	Feed PV	The data during positioning control of the PCPU are displayed. <ul style="list-style-type: none"> • Feed present value : Target address output to the servo amplifier (value of the roller surface speed for the roller axis) • Actual present value : Actually traveled present value (no value is displayed for the roller axis) • Deviation counter : Difference between feed present value and actual present value • Executed program No. : Servo program No. in execution • Minor/major/servo error : Error code of the latest minor/major/servo error
3)	EXE Cam No.	The cam No. currently controlled is displayed.
4)	ExE Stroke	The stroke amount currently controlled is displayed.
5)	Cam Ax.1 Rev.	The present value within one cam axis revolution pulse is displayed.
6)	Status *1	The ON and OFF of the symbols that represent the axis-by-axis control statuses are displayed. <ul style="list-style-type: none"> • In the ON status, the symbol is lit green. • At error or servo error detection, the symbol is lit red.
7)	CMD Signal *1	The ON and OFF of the positioning command signals are displayed. In the ON status, the signal is lit green.

*1 Not displayed when the A95*GOT/A956WGOT is used.

(2) Key functions


The following indicates the functions of the keys used for operation of the positioning monitor screen.

Key	Function
 (Display example: When axis 1 is monitored)	Used to change the axis to be monitored.
	Used to return to the previous screen.
	Used to return to the monitor menu screen.
	Used to end the positioning monitoring and return to the screen that was being displayed when the motion monitor function was started.

23.3.6 Display data and key functions of servo monitor screen

This section explains the display data of the servo monitor screen and the key functions displayed on-screen.

(1) Displayed data



No.	Item	Description
1)	Ax	The axis No. of the running axis currently monitored is displayed.
2)	Motor Speed	The actual speed of the servo motor is displayed.
3)	Motor Current	The motor current value at the rated current of 100% is displayed.
4)	Servo Alarm	The alarm detected by the servo amplifier is displayed.

(2) Key functions

The following indicates the functions of the keys used for operation of the servo monitor screen.

Key	Function
 (Display example: When axis 1 is monitored)	Used to change the axis to be monitored.
	Used to return to the monitor menu screen.
	Used to end the servo monitoring and return to the screen that was being displayed when the motion monitor function was started.

23.3.7 Display data and key functions of present value history monitor screen

This section explains the display data of the present value history monitor screen and the key functions displayed on-screen.

(1) Displayed data

Present Value History Monitor								Mon. Menu	END
Item	M/ D	H: M	Encoder Multi	PV Rev/1Rev	SV CMD Val	Monitor PV	ALM		
1Ax									
HP Data	7/ 9	13:43	0H	0H	1BE9E0H	0	----		
MON Val	7/ 9	17:12	0H	0H	1D7051H	99953.0000	----		
4) {	Nw PWR ON1	7/ 9	13:34	D7FEH	45F3H	0H	0.0000	0	
	PWR OFF1	7/ 9	13:34	0H	0H	20B67DH	490142.0000	----	
	PWR ON2	7/ 9	13:10	D7EDH	19460H	0H	92274.0000	0	
	PWR OFF2	7/ 9	13:10	0H	0H	FFFFFFF0H	92274.0000	----	
	PWR ON3	7/ 9	13:10	D7EDH	19472H	0H	92290.0000	0	
	PWR OFF3	7/ 9	13:10	0H	0H	FFFFFFE0H	92290.0000	----	
	Od PWR ON4	7/ 9	13:10	D7EDH	19495H	0H	92322.0000	0	

No.	Item	Description
1)	Ax	The axis No. of the axis currently monitored is displayed.
2)	HP Data	The following values monitored at home position return are displayed. <ul style="list-style-type: none"> • Home position return completion time • Encoder present value Multi-revolution data of absolute position reference point data Within-one-revolution position of absolute position reference point data • Servo command value • Monitor present value
3)	MON Val	The following present monitor values are displayed. <ul style="list-style-type: none"> • Present time • Encoder present value Present multi-revolution data of encoder present value Present within-one-revolution position of encoder present value • Present servo command value • Present monitor present value
4)	PWR ON/ PWR OFF	The four past present values of the ABS axis at servo amplifier power-on/off are displayed. <p>[At power-on]</p> <ul style="list-style-type: none"> • Power-on time • Encoder present value Multi-revolution data of initial encoder Single-revolution data of initial encoder • Servo command value after recovery • Monitor present value after recovery • Alarm occurrence information at present value recovery (error code of minor/major error) <hr/> <p>[At power-off]</p> <ul style="list-style-type: none"> • Servo amplifier power-off time • Encoder present value Multi-revolution data of encoder present value before servo amplifier power-off Single-revolution data of encoder present value before servo amplifier power-off • Servo command at servo amplifier power-off • Monitor present value at servo amplifier power-off

(2) Key functions

The following indicates the functions of the keys used for operation of the present value history monitor screen.

Key	Function
 (Display example: When axis 1 is monitored)	Used to change the axis to be monitored.
	Used to return to the monitor menu screen.
	Used to end the present value history monitoring and return to the screen that was being displayed when the motion monitor function was started.


23.4 Parameter setting

With the parameter setting function, you can set the servo parameters (basic parameters/adjustment parameters) of the connected motion controller CPU (Q172CPU, Q173CPU).

23.4.1 Display data and key functions of parameter setting screen

This section explains the display data of the parameter setting screen and the key functions displayed on-screen.

(1) Display screen










(2) Key functions

The following indicates the functions of the keys used for operation of the parameter setting screen.

Key	Function
	Used to change the servo parameter setting of the selected item.
	Used to choose the servo parameter setting item.
	Used to change the axis whose parameter setting will be made.
	Used to return to the system configuration screen.
	Used to end the parameter setting and return to the screen that was being displayed when the motion monitor function was started.

23.4.2 Parameter setting operation

The following describes the procedure of changing the setting of the "Auto Tuning" item as an example of parameter setting operation.



1) Choose the item whose parameter will be set with the ▲, ▼ key, and touch the **CHG** key.


2) As the parameter setting window appears, enter the parameter setting data with **Alphanumeric**, and touch **Enter** to confirm the setting. If you do not confirm it, touch **Close** to close the parameter setting window.

3) As the confirmation window appears, touch the **OK** key to write the parameter setting to the motion controller CPU. When you do not write the parameter setting, touch the **CANCEL** key.

4) After completion of write, the parameter setting screen whose display has been updated to the new parameter setting appears.

23.5 About Hardcopy Output

This section describes the way to print the motion monitor screen with the printer or to save it in the memory card in the BMP/JPEG file format during motion monitor.



The printout method varies with the used GOT as described below.

- (1) When A985GOT or A97*GOT is used

To start printout, touch the **Print Screen** / **Cancel Print** key displayed on the motion monitor screen.

- (2) When A95*GOT or A956WGOT is used

To start printout, set the hardcopy function start/stop triggering device using GT Designer2, and turn that set device on/off.

Point

- Before printing out the motion monitor screen, always install the option driver into the GOT.
- Set the output destination (Memory card/printer) of the hardcopy in the hardcopy setting of GT Designer2.
Refer to GT Designer2 Version2 Reference Manual for details of the hardcopy setting.

24 ERROR MESSAGES FOR MOTION MONITOR

This section gives the errors that may be displayed during motion monitoring operation and their corrective actions.

Error message	Error Definition	Corrective Action
No. PLC Communications	Communication with the monitor destination PLC CPU cannot be made.	<ul style="list-style-type: none"> • Check the connection status of the PLC CPU and GOT (for unplugged connector, open cable). • Check the PLC CPU for error occurrence.
This PLC type is not supported	The CPU selected on the system configuration screen is other than the Q172CPU or Q173CPU.	Choose the Q172CPU or Q173CPU on the system configuration screen.
Controllers' OS type is different	The motion controller OS installed into the monitor destination motion controller CPU (Q172CPU, Q173CPU) is other than SV13 or SV22.	Install SV13 or SV22 into the monitor destination motion controller CPU (Q172CPU, Q173CPU) as the motion controller OS.
It is not a version for GOT	The version of the motion controller OS installed into the monitor destination motion controller CPU is not compatible with the motion monitor function.	Install the motion controller OS whose version is "00E" or later into the motion controller CPU.
Monitor data not found	Monitor data was not installed or was deleted.	Download the monitor data of the motion monitoring.
Unused axis selected	The axis No. selected has not been set.	<ul style="list-style-type: none"> • Choose the axis No. that has been set. • Set the axis using the peripheral software.
It is not possible to select	During servo parameter setting, the item that cannot be set has been selected.	Choose the item that can be set.
Incorrect setting range	The value that is outside the setting range has been set.	Set the value within the setting range.
Unmatched password	The password entered as the motion parameter changing password is illegal.	Enter the correct password.

17 USING THE NETWORK MONITOR SCREENS
 18 ERROR MESSAGES FOR NETWORK MONITOR
 19 OPERATING LIST EDITOR
 20 OPERATION OF EDITING SCREEN FOR EACH LIST
 21 ERROR MESSAGES FOR LIST EDITOR
 22 OPERATING MOTION MONITOR
 23 OPERATIONS OF VARIOUS MOTION MONITOR SCREENS
 24 ERROR MESSAGES FOR MOTION MONITOR


25 OPERATING SERVO AMPLIFIER MONITOR

The operation procedure when using the servo amplifier monitor function is explained in this chapter.

25.1 Operation procedures before starting motion monitoring


This section contains a summary of the procedure for transmitting the system program (OS) for the servo amplifier monitor function and the motion monitor data from the personal computer to the GOT until it is installed in built-in memory.

For details, please refer to the GT Designer2 Version2 Operating Manual. Details of the screen display and key operation are shown in the Help.



25.2 Operation procedures from user-created monitor screen display to start of motion monitor

This section provides the GOT operating procedure for starting the operation of any servo amplifier monitor function after completion of the installation of the "servo amplifier monitor function OS".




26 OPERATIONS OF SERVO AMPLIFIER MONITOR SCREENS

This chapter describes the screen operations to be performed when using the servo amplifier monitor functions.
The display screens of the servo amplifier monitor functions change slightly depending on the used GOT.
This chapter mainly uses the screens of the A975GOT for explanation.

26.1 Screen Transition

This section gives the screen transition from the user-created monitor screen display status to the servo amplifier monitor function screen operations.




- *1 Start the servo amplifier monitor functions by touching the key for which the touch key (extended) function has been set on GT Designer2.
- *2 Touch **AMP. MON.** to start the servo amplifier monitor functions.
- *3 When **End** was touched to terminate the servo amplifier monitor functions, the screen on which the functions were terminated appears when the servo amplifier monitor functions are started next time.

26.2 About the Servo Amplifier Monitor Functions

The servo amplifier monitor functions allow various monitor functions, parameter setting changes, test operations and others to be performed for the servo amplifier connected to the GOT. Select and display the required function from the function selection menu screen.

(Function selection menu screen)



- 1) Setup Selects the model of the servo amplifier to be monitored by the servo amplifier function, the communication baudrate, station number setting (station number presence/absence, station number selection), and IFU station number.
(Refer to Section 26.2)
- 2) Monitor Displays all monitor data of the servo amplifier in real time.
(Refer to Section 26.3)
- 3) Alarm Displays the currently occurring alarm and displays the history. Also resets the alarm or clears the history.
(Refer to Section 26.4)
- 4) Diagnostics Runs the following various diagnostics on the connected servo amplifier.
(Refer to Section 26.5)
 - DI/DO display
Displays the ON/OFF states of the external I/O signals.
 - Function device display
Displays the ON/OFF states of the I/O function devices.
 - Amplifier information display
Displays the model, ID and encoder resolution of the servo motor connected to the servo amplifier.
 - ABS data display
Displays the absolute position data of the absolute position detection system.
 - Unit composition list display
Displays the servo amplifier unit composition list.
- 5) Parameters Displays the parameter data and changes the parameter setting.
(Refer to Section 26.6)
- 6) Test Performs various test operations (JOG operation, positioning operation, motorless operation, DO forced output).
(Refer to Section 26.7)

26.3 Setup


Set communication with the servo amplifier.

Point

- (1) Before making the settings on the setup screen, also make the same settings on the servo amplifier side.
If the settings on this screen differ from the settings on the servo amplifier side, normal communication may not be performed.
- (2) The settings on the setup screen return to the initial states when the GOT is powered off or reset.
After powering on the GOT, make settings on the setup screen again.

26.3.1 Setup screen

This section explains the display data of the setup screen and the key functions displayed on the screen.



*You cannot set "Axis number" and "Capacity setting".

(1) About the display data

No.	Item	Description
1)	Model	Displays the servo amplifier model to be connected.
2)	Baudrate	Displays the communication baudrate (38400/19200/9600) with the servo amplifier.
3)	Station supp.	Displays the station number presence/absence.
4)	Station	Displays the station number (00 to 31) of the servo amplifier to communicate with.
5)	IFU Station	Displays the serial communication station number of the IFU (interface unit).

(2) About the key functions

The following table indicates the functions of the keys used for the operations of the alarm display screen.

Key	Function
<input type="text" value="Model"/>	Sets the servo amplifier model to be connected.
<input type="text" value="Baudrate"/>	Sets the communication baudrate (38400/19200/9600) with the servo amplifier. • Set the communication baudrate parameter on the servo amplifier side to 38400 or less.
<input type="text" value="Station Support"/> *	Sets the station number presence/absence.
<input type="text" value="Station"/>	Sets the station number (00 to 31) of the servo amplifier to communicate with.

Key	Function
<input type="text" value="IFU Station"/> *2	Sets the serial communication station number of the IFU (interface unit).
<input type="button" value="Fix"/>	Confirms the settings and returns to the function selection menu screen.
<input type="button" value="End"/>	Terminates the servo amplifier monitor functions.

*1: Valid only when the MR-J2S-□A is connected.

*2: Valid only when the MR-J2M A series is connected.


26.4 Monitor Functions

All monitor data of the servo amplifier are displayed in real time.

26.4.1 Monitor screen

This section explains the display data of the monitor screen and the key functions displayed on the screen.

(1) About the display data



No.	Item	Description
1)	Cumulative feedback pulses	Counts and displays the feedback pulses from the servo motor encoder. <ul style="list-style-type: none"> When the setting exceeds 9999999, it starts from 0. The - sign appears for reverse rotation.
2)	Servo motor speed	Displays the servo motor speed. <ul style="list-style-type: none"> The value is displayed with the 0.1r/min unit rounded off. The - sign appears for reverse rotation.
3)	Droop pulses	Displays the droop pulses of the deviation counter. <ul style="list-style-type: none"> The - sign appears for reverse rotation.
4)	Cumulative command pulses	Counts and displays the position command input pulses. <ul style="list-style-type: none"> Since the value before multiplication of the electronic gear (CMX/CDV) is displayed, this value may not match the indication of the cumulative feedback pulses. The - sign appears for the reverse rotation command.
5)	Command pulse frequency	Displays the position command input pulse frequency. <ul style="list-style-type: none"> The value before multiplication of the electronic gear (CMX/CDV) is displayed. The - sign appears for the reverse rotation command.
6)	Analog speed command voltage (In speed control mode) *1	Displays the input voltage of the analog speed command (VC).
	Analog speed limit voltage (In torque control mode) *1	Displays the input voltage of the analog speed limit (VLA).
7)	Analog torque command voltage (In position/speed control mode) *1	Displays the voltage of the analog torque limit (TLA).
	Analog torque limit voltage (In torque control mode) *1	Displays the voltage of the analog torque command (TC).

*1 Displayed only when the MR-J2S-□A is connected.

No.	Item	Description
8)	Regenerative load ratio	Displays the ratio of the regenerative power to the permissible regenerative power in %. <ul style="list-style-type: none"> ▪ The permissible regenerative power changes depending on the presence/absence of the regenerative brake option. Set the parameter No. 0 value correctly according to the regenerative option. (Set 80% or less as a guideline.)
9)	Effective load ratio	Displays the continuous effective load torque. <ul style="list-style-type: none"> ▪ The effective value is displayed on the assumption that the rated torque is 100%.
10)	Peak load ratio	Displays the maximum torque generated. <ul style="list-style-type: none"> ▪ The maximum value for the past 15 seconds is displayed on the assumption that the rated torque is 100%.
11)	Instantaneous torque	Displays the instantaneously generated torque. <ul style="list-style-type: none"> ▪ The value of the generated torque is displayed in real time on the assumption that the rated torque is 100%.
12)	Within one-revolution position	Displays the within one-revolution position in the servo motor in pulse units of the encoder. <ul style="list-style-type: none"> ▪ When the value exceeds the maximum pulse count, it returns to 0.
13)	ABS counter	Displays the distance from the home position (0) in the absolute position detection system as the multi-revolution counter value of the absolute position encoder.
14)	Load inertia moment ratio	Displays the estimated ratio of the servo motor shaft-equivalent load inertia moment to the servo motor's inertia moment.
15)	Bus voltage	Displays the voltage (across P - N) of the main circuit converter.

(2) About the key functions

The following table indicates the functions of the keys used for the operations of the monitor screen.


Key	Function
	Clears the "cumulative feedback pulses" or "cumulative command pulses" to 0.
	Returns to the function selection menu screen.
	Terminates the servo amplifier monitor functions.
	Scrolls the monitor items in units of six items. (Displayed only when the A95*GOT/A956WGOT is used.)

26.5 Alarm Function


The following alarm definitions are displayed.

- Alarm display: Displays the currently occurring alarm.
(Refer to Section 26.5.1.)
- Alarm history: Displays the history of alarms that occurred.
(Refer to Section 26.5.2.)


The following shows the screen transition after selection of Alarm on the function selection menu screen.



Function selection menu screen (refer to Section 26.2)



Alarm display screen



Alarm history screen




If the alarm display screen data has not been downloaded to the GOT, "Monitor data not found" appears and the subsequent screen is not displayed.

26.5.1 Alarm display screen

This section describes the display data of the alarm display screen and the key functions displayed on the screen.

(1) About the display data



No.	Item	Description
1)	Alarm Number	Displays the number of the alarm that occurred.
2)	Alarm Name	Displays the name of the alarm that occurred.
3)	Time of Alarm	Displays the date and time when the alarm occurred. <ul style="list-style-type: none"> The alarm occurrence time is displayed on the basis of the clock data of the PLC CPU connected to the GOT. If a fault occurred in the servo amplifier before it is connected to the GOT, an alarm is displayed when the servo amplifier is connected to the GOT. In that case, the time when the GOT and servo amplifier was connected is displayed as the alarm occurrence time.
4)	Cause of Alarm	Displays the cause of the currently occurring alarm.

(2) About the key functions

The following table indicates the functions of the keys used for the operations of the alarm display screen.

Key	Function
	Resets the alarm. <ul style="list-style-type: none"> Sets the servo amplifier model to be connected.
	Displays the cause of the alarm on the window screen. (Displayed only when the A95*GOT/A956WGOT is used.)
	Changes to the alarm history screen (refer to Section 26.5.2).
	Confirms the settings and returns to the function selection menu screen.
	Terminates the servo amplifier monitor functions.

26.5.2 Alarm history screen

This section describes the display data of the alarm history screen and the key functions displayed on the screen.

(1) About the display data

Seq No.	Alarm No.	Alarm Name	Time(hour)	Detail(hex)
0	AL8E	Serial com. error	270	10
1	AL8E	Serial com. error	270	10
2	AL8E	Serial com. error	268	10
3	AL8E	Serial com. error	268	10
4	AL8E	Serial com. error	268	10
5	AL52	Error excessive	215	01

1) 2) 3) 4) 5)

No.	Item	Description
1)	Sequence No.	Displays the alarm history, starting from the newest alarm, in order. <ul style="list-style-type: none"> The newer alarms have smaller history numbers. (0 is the newest.) Six alarms are displayed.
2)	Alarm No.	Displays the number of the alarm that occurred
3)	Alarm Name	Displays the name of the alarm that occurred. (Displayed only when the A95*GOT/A956WGOT is used.)
4)	Time (hour)	Displays the energization time of the servo amplifier until alarm occurrence on the assumption that the time at shipment from the factory is "0".
5)	Detail (hex)	Displays the code of the alarm detail information.

(2) About the key functions

The following table indicates the functions of the keys used for the operations of the alarm history screen.

Key	Function
	Clears the alarm history stored in the servo amplifier.
	Changes to the alarm display screen (refer to Section 26.5.1).
	Confirms the settings and returns to the function selection menu screen.
	Terminates the servo amplifier monitor functions.

26.6 Diagnostics Function


Run the following various diagnostics on the connected servo amplifier.

- DI/DO display : Displays the ON/OFF states of the external I/O signals.
(Refer to Section 26.6.1)
- Function device display : Displays the ON/OFF states of the I/O function devices.
(Refer to Section 26.6.2)
- Amplifier information display : Displays the model, ID and encoder resolution of the servo motor
(Refer to Section 26.6.3) connected to the servo amplifier.
- ABS data display : Displays the absolute position data of the absolute position detection
(Refer to Section 26.6.4) system.
- Unit composition list display : Displays the servo amplifier unit composition list.
(Refer to Section 26.6.5)

(1) Screen transition

The following shows the screen transition after selection of **Diagnostics** on the function selection menu screen.

Some screens may not be displayed depending on the model of the connected servo amplifier. For the screens that cannot be displayed, refer to (2).





If the DI/DO display screen data or function device display screen (for MR-J2M□DU monitor only) data has not been downloaded to the GOT, "Monitor data not found" appears and the subsequent screens are not displayed.

(2) Display screens

The screens that can be displayed are indicated on a servo amplifier model basis.


Item	MR-J2S-□A	MR-J2S-□CP	MR-J2M A Series	
			MR-J2M-P8A	MR-J2M-□DU
DI/DO display screen	○	○	○	---
Function device display screen	---	○	○	○
Amplifier information display screen	○	○	---	○
ABS data display screen	○	○	---	○
Unit composition list display screen	---	---	○	○

○: Screen present ---: Screen absent

26.6.1 DI/DO display screen

This section describes the display data of the DI/DO display screen and the key functions displayed on the screen.

(1) About the display data



No.	Item	Description
1)	Input/Output Signal	Indicates the ON (lit)/OFF (extinguished) of the DI/DO signal.

(2) About the key functions

The following table indicates the functions of the keys used for the operations of the DI/DO display screen.



Key	Function
*1	Displays the DI/DO signals of the extension IO unit.
	Changes to the function device screen (refer to Section 26.6.2).
	Changes to the amplifier information screen (refer to Section 26.6.3).
	Changes to the unit composition list screen (refer to Section 26.6.5).
	Changes to the ABS data screen (refer to Section 26.6.4).
	Confirms the settings and returns to the function selection menu screen.
	Terminates the servo amplifier monitor functions.

*1: Displayed only when the MR-J2M A series is connected.

26.6.2 Function device display screen

This section describes the display data of the function device display screen and the key functions displayed on the screen.

(1) About the display data



[When MR-J2S-□CP is monitored]

No.	Item	Description
1)	Input/Output Function	Indicates the ON (■)/OFF (□) state of each I/O signal.

(2) About the key functions


The following table indicates the functions of the keys used for the operations of the function device display screen.

Key	Function
	Changes the indication of the I/O signal. (Displayed only when the A95*GOT/A956WGOT is used.)
	Changes to the DI/DO display screen (refer to Section 26.6.1).
	Changes to the ABS data screen (refer to Section 26.6.4).
	Changes to the amplifier information screen (refer to Section 26.6.3).
	Changes to the unit composition list screen (refer to Section 26.6.5).
	Confirms the settings and returns to the function selection menu screen
	Terminates the servo amplifier monitor functions
	Scrolls the I/O signal items in units of 10 items. (Displayed only when the A95*GOT/A956WGOT is used.)

26.6.3 Amplifier information display screen

This section describes the display data of the amplifier information display screen and the key functions displayed on the screen.

(1) About the display data



No.	Item	Description
1)	Amplifier Firmware Version*1	Displays the software number of the servo amplifier connected to the GOT.
2)	Motor model*1	Displays the model of the servo motor connected to the servo amplifier.
3)	Motor ID*1	Displays the ID of the servo motor connected to the servo amplifier.
4)	Encoder resolution*1	Displays the encoder resolution of the servo motor connected to the servo amplifier.

*1 Not displayed for MR-J2M-P8A monitor.

(2) About the key functions

The following table indicates the functions of the keys used for the operations of the amplifier information display screen.

Key	Function
	Changes to the DI/DO display screen (refer to Section 26.6.1).
	Changes to the function device screen (refer to Section 26.6.2).
	Changes to the ABS data screen (refer to Section 26.6.4).
	Changes to the unit composition list screen (refer to Section 26.6.5).
	Confirms the settings and returns to the function selection menu screen.
	Terminates the servo amplifier monitor functions.

26.6.4 ABS data display screen

This section describes the display data of the ABS data display screen and the key functions displayed on the screen.

(1) About the display data

The screenshot shows a terminal window with the following content:

```

MR-J2S-A 9600 bps Servo amp.Monitor [ 0St] Menu End
-----
1) Absolute position data
   Value of each motor edge pulse  Command pulse value
   -1529942003                    -1529942003
Encoder data
  <Current position>                <Position at power loss>
Absolute encoder data(pulse)      Absolute encoder data
CYC(Motor edge pulse value)      CYC0(Motor edge pulse value)
   61453                          0
CYC(Command pulse value)         CYC0(Command pulse value)
-----
Number of motor rotations(rev)    Number of motor rotations
ABS                               ABS0
  21095                          0
-----
DI/DO  Amp. Inf
  
```

Brackets on the left indicate that items 1) and 2) correspond to the 'Absolute position data' and 'Encoder data' sections respectively.

No.	Item	Description
1)	Absolute position data	Displays the following items of the absolute position data in the absolute position detection system. <ul style="list-style-type: none"> ▪ Motor edge pulse value ▪ Command pulse value
2)	Encoder data	Displays the following items of the encoder data. <p><Current position></p> <ul style="list-style-type: none"> ▪ Absolute encoder data ▪ CYC (Motor edge pulse value) ▪ CYC (Command pulse value) <p><Position at power loss></p> <ul style="list-style-type: none"> ▪ Absolute encoder data ▪ CYC0 (Motor edge pulse value) ▪ CYC0 (Command pulse value) <p>▪ Number of motor rotations ABS</p> <p>▪ Number of motor rotations ABS0</p>

(2) About the key functions

The following table indicates the functions of the keys used for the operations of the ABS data display screen.

Key	Function
	Changes the indication between the current value and home position information of the encoder data. (Displayed only when the A95*GOT/A956WGOT is used.)
	Changes to the DI/DO display screen (refer to Section 26.6.1).
	Changes to the function device screen (refer to Section 26.6.2).
	Changes to the unit composition list screen (refer to Section 26.6.5).
	Changes to the amplifier information screen (refer to Section 26.6.3).
	Confirms the settings and returns to the function selection menu screen.
	Terminates the servo amplifier monitor functions.

26.6.5 Unit composition list display screen

This section describes the display data of the unit composition list display screen and the key functions displayed on the screen.

(1) About the display data

Slot	Type name	AxNo.	State	Motor model	S/W version
IFU	MR-J2M-P8A	10	AB	----	BCD-B30W100 A0
Slot:1	MR-J2M-10DU	1	C1	HC-PQ053/MF(S)053	BCD-B29W000 B0
Slot:2	MR-J2M-10DU	2	C2	HC-PQ053/MF(S)053	BCD-B29W000 B0
Slot:3					
Slot:4					
Slot:5					
Slot:6					
Slot:7					
Slot:8					
Option					

No.	Item	Description
1)	Type name	Displays the types of the drive unit (DRU), interface unit (IFU) and option unit installed to the slots.
2)	Axis No.	Displays the axis numbers of the drive unit (DRU) and interface unit (IFU).
3)	State	Displays the states and alarm/warning numbers of the drive unit (DRU) and interface unit (IFU).
4)	Motor model	Displays the motor model connected to the drive unit (DRU).
5)	S/W version	Displays the software numbers of the drive unit (DRU) and interface unit (IFU).

(2) About the key functions

The following table indicates the functions of the keys used for the operations of the unit composition list display screen.


Key	Function
	Changes to the DI/DO display screen (refer to Section 26.6.1).
	Changes to the ABS data screen (refer to Section 26.6.4).
	Changes to the amplifier information screen (refer to Section 26.6.3).
	Changes to the function device screen (refer to Section 26.6.2).
	Confirms the settings and returns to the function selection menu screen.
	Terminates the servo amplifier monitor functions.
	Scrolls the list display in units of three items. (Displayed only when the A95*GOT/A956WGOT is used.)

26.7 Parameter Setting

Using the parameter setting function, you can set the servo parameters (basic parameters/extension parameters 1, 2) for the connected servo amplifier.



After the password has been set on GT Designer2, an attempt to access the parameter setting screen of the servo amplifier monitor displays the password input screen.

After selection of **Parameters** on the function selection menu screen, the screen transition is as shown below.




Function selection menu screen (refer to Section 26.2)

*1 Set the servo parameter changing password on GT Designer2. For details of the parameter setting, refer to the GT Designer2 Version2 Reference Manual.



Password input screen


Enter the parameter changing password. ... Refer to Section 26.7.1



Parameter setting screen

26.7.1 Password entry operation procedure

The following gives the servo parameter changing password input operation procedure.



(1) Features

- If the characters entered match a password, the Parameter Setting screen appears.
- If the password does not match, the error message appears.

Touching  returns to the function selection menu screen.

- Numerical numbers and alphabets  to  can be used for a password.

(2) Procedure

(a) To enter a password, follow these steps:

- Touch  to  and  to  to enter a password.
- Touch  to confirm the password entered.
- To correct the password entered, touch  to delete wrong characters and then enter correct characters again.

(b) To quit entering a password:

- Touch  to return to the previous monitor screen.


26.7.2 Parameter setting screen

This section describes the display data of the parameter setting screen and the key functions displayed on the screen.



The * mark preceding the parameter name indicates that the parameter is made valid when power is switched off once and then on again after the parameter value has been set.

(1) Display screen



No.	Item	Description
1)	Pr.*1	Displays the parameter number.
2)	Name	Displays the parameter name.
3)	Value*1	Displays the current setting of the parameter.
4)	Unit*1	Displays the setting unit of each parameter.

*1: When the A956W/A95*GOT is used, the information of only the selected parameter is displayed at the bottom of the screen.

(2) About the key functions




The following table indicates the functions of the keys used for the operations of the parameter setting screen.

Key	Function
	Selects the servo parameter setting item.
	Scrolls the parameter items in units of one screen.
	Changes the servo parameter setting read to the GOT internal memory.
	Writes the servo parameter setting of the selected item to the servo amplifier.
	Verifies all parameter values currently displayed on the GOT and the parameter values of the servo amplifier.
	Writes all parameter values currently displayed on the GOT to the parameters of the servo amplifier.
	Reads all parameter values from the servo amplifier to the GOT and displays them there.
	Returns all parameter values to the initial values.

Key	Function
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Param. IFU</div> <div style="border: 1px solid black; padding: 2px; display: inline-block;">Param. DRU</div> *1	Every time touched, changes the parameter display between the drive unit (DRU) and interface unit (IFU).
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Slot:1</div> *1	Selects the slot number of the drive unit (DRU).
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Pr. 0</div> *1	Displays the specified parameter number on the parameter list screen. (Displayed only when the A95*GOT/A956WGOT is used.)
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Menu</div>	Confirms the settings and returns to the function selection menu screen.
<div style="border: 1px solid black; padding: 2px; display: inline-block;">End</div>	Terminates the servo amplifier monitor functions.

*1: Displayed only when the MR-J2M A series is connected.

(From previous page)



- 5) As the parameter setting window appears, enter the parameter setting data with **Alphanumeric**, and touch **↵** to confirm the setting. If you do not confirm it, touch **⏏** to close the parameter setting window.

- 6) The parameter value changes on the parameter setting screen.

Choose the changed parameter item and touch the **Write** key.

When you have changed the settings of two or more parameter items, touch the **Write All** key to write all the parameter items whose settings have been changed.

- 7) The confirmation window appears. Touch the **OK** key to write the parameter setting to the servo amplifier. When you do not write the parameter setting, touch the **CANCEL** key.

This completes the parameter setting write operation.

Point


- (1) The changes made to the parameter settings are written to the E²PROM of the servo amplifier. Hence, if the amplifier is powered off, the written parameter values are retained.
- (2) When you have changed any parameter setting on the servo amplifier side, also change that setting to the same value on the setup screen of the GOT (Section 26.2). If the setup screen settings and servo amplifier side settings do not match, normal communication cannot be made with the servo amplifier.
 - Serial communication baudrate selection
 - Protocol station number selection
 - Station number setting

26.8 Test Operations

The following test operations are performed for the connected servo amplifier.

- JOG operation (Refer to Section 26.8.3.) : The servo motor runs while you are touching the Forward or Reverse key.
- Positioning operation (Refer to Section 26.8.4.) : When you touch the Forward or Reverse key, this operation starts and runs the servo motor by the preset distance.
- Motorless operation (Refer to Section 26.8.5.) : Simulates the operation of the servo motor in the servo amplifier if the servo motor is not connected.
- DO forced output (Refer to Section 26.8.6.) : Forcibly turns ON/OFF the output signals independently of the output conditions of the servo amplifier output signals.

- (1) The following shows the screen transition after selection of **Test** on the function selection menu screen.
- Some screens may not be displayed depending on the model of the connected servo amplifier. For the screens that cannot be displayed, refer to (2).



If the JOG operation screen data has not been downloaded to the GOT, "Monitor data not found" appears and the subsequent screens are not displayed.

(2) Display screens

The screens that can be displayed are indicated on a servo amplifier model basis.

Item	MR-J2S-□ A	MR-J2S-□ CP	MR-J2M A Series	
			MR-J2M-P8A	MR-J2M-□DU
JOG operation	○	○	---	○
Motorless operation	○	○	---	○
Positioning operation screen	○	○	---	○
DO forced output screen	○	○	○	---

○: Screen present ---: Screen absent

26.8.1 Precautions for test operations

This section gives the precautions for using the test operations of the servo amplifier monitor functions.



WARNING

- Do not operate the servo amplifier switches with wet hands. Doing so can cause an electric shock.
- Do not perform operations with the front cover of the servo amplifier removed. Doing so can cause an electric shock since the high-voltage terminals and charging section are exposed.
- Do not open the front cover of the servo amplifier while power is on and during operation. Doing so can cause an electric shock.



CAUTION

- Before starting test operations, always read the precautions for test operations in the manual of the corresponding servo amplifier.
- Before starting operation, check the servo amplifier parameters. Depending on the machine, unexpected operation may be performed.
- While power is on or for some time after power-off, the servo amplifier's heat sink and regenerative brake resistor, the servo motor, and others may be hot. Do not touch them and bring the parts (cables, etc.) close to them. Doing so can cause a burn and damage to the parts.

(1) Servo on

In the JOG operation and positioning operation among the test operations, the SON digital input signal of the servo amplifier is turned ON automatically in the servo amplifier to start operation, independently of whether the SON signal is ON or OFF.

The servo amplifier does not accept any external command pulses and input signals (except the emergency stop) until the test operation screen is closed.

SON turns ON automatically by touching the **Forward** or **Reverse** key on the JOG operation screen or positioning operation screen.

(2) Stop



To make an emergency stop, turn OFF the emergency stop signal of the servo amplifier or switch off the input power.

- (a) The operation for stopping the test operation on the servo amplifier monitor screen is as described below.
- JOG operation: Release the **Forward** or **Reverse** key.
 - Positioning operation: Touch the **Pause** key.
- (b) The servo motor stops if any of the following states occurs during test operation.
- The communication cable is disconnected.
 - The servo amplifier monitor screen is switched to that of the other servo amplifier, or the servo amplifier monitor function is terminated.
- However, during motorless operation, the test mode is not canceled until the servo amplifier is powered off.


26.8.2 Preparations for test operations

To start test operations, you need to make settings for test operations on the connected servo amplifier. For details of the servo amplifier side settings for performing test operations, refer to the manual of the connected servo amplifier.

26.8.3 JOG operation screen

This section describes the display data of the JOG operation screen and the key functions displayed on the screen.

(1) About the display data



No.	Item	Description
1)	Motor speed	Displays the set speed of the servo motor.
2)	Acc/dec time	Displays the set acceleration/deceleration time constant of the servo motor.

(2) Operation

- Operation start
Touch the **Forward** or **Reverse** key.
- Operation stop
Release the **Forward** or **Reverse** key.

(3) About the key functions


The following table indicates the functions of the keys used for the operations of the JOG operation screen.

Key	Function
Forward	Runs the servo motor in the forward rotation (CCW) direction while being touched.
Reverse	Runs the servo motor in the reverse rotation (CW) direction while being touched.
Motor speed	Changes the servo motor speed.
Acc/dec time	Changes the acceleration/deceleration time constant.
Positioning	Changes to the positioning operation screen (refer to Section 26.8.4).
Without Motor	Changes to the motorless operation screen (refer to Section 26.8.5).
DO ForcedOutput	Changes to the DO forced output screen (refer to Section 26.8.6).
Menu	Confirms the settings and returns to the function selection menu screen.
End	Terminates the servo amplifier monitor functions.

26.8.4 Positioning operation screen

This section describes the display data of the positioning operation screen and the key functions displayed on the screen.

(1) About the display data



No.	Item	Description
1)	Motor speed	Displays the set speed of the servo motor.
2)	Acc/dec time	Displays the set acceleration/deceleration time constant.
3)	Move distance	Displays the set distance.

(2) Operation

• Operation start

Touch the **Forward** or **Reverse** key.

To resume the operation stopped temporarily, retouch the **Forward** button for forward rotation or the or **Reverse** button for reverse rotation.

• Operation stop

Operation stops when the axis has moved the preset distance.

Alternatively, touch the **Pause** key to stop the operation temporarily.

After a temporary stop, retouch the **Pause** key to erase the remaining distance.

(3) About the key functions

The following table indicates the functions of the keys used for the operations of the positioning operation screen.

Key	Function
Forward	Runs the servo motor in the forward rotation (CCW) direction.
Reverse	Runs the servo motor in the reverse rotation (CW) direction.
Pause	Stops the running servo motor temporarily.
Motor speed	Changes the servo motor speed.
Acc/dec time	Changes the acceleration/deceleration time constant.
Move distance	Changes the distance.
JOG	Changes to the JOG operation screen (refer to Section 26.8.3).


Key	Function
	Changes to the motorless operation screen (refer to Section 26.8.5).
	Changes to the DO forced output screen (refer to Section 26.8.6).
	Confirms the settings and returns to the function selection menu screen.
	Terminates the servo amplifier monitor functions.

25	OPERATING SERVO AMPLIFIER MONITOR
26	OPERATIONS OF SERVO AMPLIFIER MONITOR SCREENS
27	ERROR MESSAGES FOR SERVO AMPLIFIER MONITOR
28	OPERATING CNC MONITOR
29	OPERATING THE CNC MONITOR FUNCTION SCREEN
30	ERROR MESSAGES FOR CNC MONITOR
31	FONT CHANGE FUNCTION
32	SYSTEM DIALOG LANGUAGE SWITCHING

26.8.5 Motorless operation screen

This section describes the display data of the motorless operation screen and the key functions displayed on the screen.

(1) About the display data



(2) Operation

- Operation start
Touch the **Start** key.
- Operation stop
Power off the servo amplifier to cancel the motorless operation.

(3) About the key functions


The following table indicates the functions of the keys used for the operations of the motorless operation screen.

Key	Function
Start	Starts motorless operation.
JOG	Changes to the JOG operation screen (refer to Section 26.8.3).
Positioning	Changes to the positioning operation screen (refer to Section 26.8.4).
DO ForcedOutput	Changes to the DO forced output screen (refer to Section 26.8.6).
Menu	Confirms the settings and returns to the function selection menu screen.
End	Terminates the servo amplifier monitor functions.

26.8.6 DO forced output screen

This section describes the display data of the DO forced output screen and the key functions displayed on the screen.

(1) About the display data



No.	Item	Description
1)	Output signal ON/OFF state	Displays the ON (●)/OFF (○) of each output signal of the servo amplifier. • After this screen has been switched to another screen, all external I/O signals are turned OFF.

(2) Operation

Touch the required output signal name to invert the ON/OFF status of the corresponding signal and write it to the servo amplifier.

(3) About the key functions


The following table indicates the functions of the keys used for the operations of the DO forced output screen.

Key	Function
<div style="border: 1px solid black; padding: 2px; display: inline-block;">CN1A-3</div> (Signal names of output signals)	By touching the signal name of the required output signal, SET/RESET the corresponding signal status (● : ON, ○ : OFF). • If the current output signal is ON, it is turned OFF (reset). If it is OFF, it is turned ON (set).
<div style="border: 1px solid black; padding: 2px; display: inline-block;">D01</div> ^{*1}	Displays the external output signals of the extension I/O unit.
<div style="border: 1px solid black; padding: 2px; display: inline-block;">JOG</div>	Changes to the JOG operation screen (refer to Section 26.8.3)
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Positioning</div>	Changes to the positioning operation screen (refer to Section 26.8.4).
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Without Motor</div>	Changes to the motorless operation screen (refer to Section 26.8.5).
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Menu</div>	Confirms the settings and returns to the function selection menu screen.
<div style="border: 1px solid black; padding: 2px; display: inline-block;">End</div>	Terminates the servo amplifier monitor functions.

*1 Displayed only when the MR-J2M-P8A is connected.

26.9 About Hardcopy Output

This section describes the way to print the ladder monitor screen with the printer or to save it in the memory card in the BMP/JPEG file format during ladder monitor.



Depending on the used GOT, output the hardcopy in the following corresponding method.

- (1) When A985GOT or A97*GOT is used

Touch the **Start hardcopy** or **Stop hardcopy** key displayed on the ladder monitor screen to output the hardcopy.

- (2) When A95*GOT or A956WGOT is used

Set the start/stop triggering device of the hardcopy function on GT Designer2 and turn that device ON/OFF to output the hardcopy.

Point

- When printing out the ladder monitor screen, always install the option driver into the GOT.
- Set the output destination (Memory card/printer) of the hardcopy in the hardcopy setting of GT Designer2.
Refer to GT Designer2 Version2 Reference Manual for details of the hardcopy setting.

27 ERROR MESSAGES FOR SERVO AMPLIFIER MONITOR

This chapter provides the error indications given during servo amplifier monitor operation and their corrective actions.

Error Message	Error Definition	Corrective Action
Monitor data not found	Monitor data have not been installed, or monitor data have been deleted.	Download the monitor data of the servo amplifier monitor.
No AMP Communications	Communication cannot be made with the servo amplifier set as the monitor destination.	<ul style="list-style-type: none"> • Check the connection state (connector disconnection, cable wire break) of the servo amplifier and GOT. • Check the servo amplifier for error occurrence. • Set the same values to the servo amplifier monitor function setup screen and servo amplifier side parameters.
This test mode cannot be selected. Operation without Motor rotation	The other test operation function has started.	End the other test operation function.
SON Make sure that operation is at a stop.	The SON signal of the servo amplifier is ON.	Turn OFF the SON signal of the servo amplifier.
Servo alarm has occurred. Alarm: **	A value outside the setting range was set in the servo parameter setting.	Set the servo amplifier parameter values inside the setting ranges.
Emergency is stopping	An alarm occurred in the connected servo amplifier.	Reset the alarm of the servo amplifier.
Unit not found	The selected slot is not loaded with the drive unit.	Select the slot where the drive unit is loaded.
Unmatched password	The password entered as the servo amplifier changing password is illegal.	Enter the correct password.
Please confirm forward or reversal stroke end (LSP or LSN)	The LSP/LSN signal of the servo amplifier is OFF.	Turn ON the LSP/LSN signal of the servo amplifier.

28 OPERATING CNC MONITOR




Before using CNC monitor function, please read the manual of the MELDAS C6/C64 to be connected thoroughly to fully understand it.

The operation procedure when using the CNC monitor function is explained in this chapter.

28.1 Operation procedures before starting CNC monitoring

This section provides an outline of the procedures; from the step of transferring CNC monitor function operating system (OS) and communication driver from a personal computer to GOT, up to the step of installing them into the built-in memory.

For details, please refer to the GT Designer2 Version2 Operating Manual.




29 OPERATING THE CNC MONITOR FUNCTION SCREEN

This chapter describes the screen operations to be performed when using the CNC monitor function.

29.1 Changing screens

This section shows screen transition from the user-created monitor screen to the CNC monitor screen.





Function selection menu screen (refer to Section 29.2)

- *1 Start the CNC monitor functions by touching the key for which the touch key (extended) function has been set on GT Designer2.
- *2 Touch **MOTION/CNC MON.** to start the CNC monitor functions.
- *3 When **RET** was touched to terminate the CNC monitor functions, the screen on which the functions were terminated appears when the CNC monitor functions are started next time.

29.2 About the CNC Monitor Functions

This section explains the display data of the CNC monitor screen and the key functions displayed on the screen.



No.	Item	Display Data
1)	Function switching area	Selects the function to be displayed and CNC monitor termination.
		Switches the monitor area to position display monitor.
		Switches the monitor area to alarm diagnostics monitor.
		Switches the monitor area to tool compensation parameter.
		Switches the monitor area to program monitor.
		Switches the monitor area to the APLC screen. If the monitored MELDAS C6/C64 unit does not include the APLC function, the screen turns blank. (In this case, use a function switching key to switch the monitor to other function.)
		<ul style="list-style-type: none"> For Ethernet connection Switches the monitor between the MELDAS C6/C64 units when connected with multiple MELDAS C6/C64 units. The MELDAS C6/C64 units are switched in the order set in the Ethernet setting of GT Designer2. For MELSENET/10 connection Unusable as only control station can be monitored (switching not required).
	Terminates the CNC monitor function and returns to the monitor screen or utility screen of the GOT.	
2)	Monitor area	Functions equivalent to the MELDAS dedicated display are available, such as Position Display Monitor, Alarm Diagnosis Monitor, Tool Offset/Param, Program Monitor and F0 function. The graphic and ladder editor functions are unavailable.

No.	Item	Display Data
3)	 to 	<p>Switches to the monitor that corresponds to each item in the menu area. In the case of the above screen, the menu items are as follows.</p> <p>Menu1 : Relative value Menu2 : PLC switch Menu3 : Common editing Menu4 : Local variable Menu5 : Menu switching</p> <p>When the MELDAS dedicated display is valid, the "Other display operating" message and "Key operation right" menu are displayed. When performing key operation on the GOT, select the "Key operation right" menu.</p>
		Switches to the previous page when there are multiple pages displayed on the screen.
		Switches to the next page when there are multiple pages displayed on the screen.
4)	Keyboard	Sets data to the monitor area.
	Alphanumeric/symbol key	<p>Enters alphabets (upper case only), numerals, spaces or symbols. The grayed symbol can be entered after the SHIFT key is touched.</p>
		Moves the cursor up or down or to the left or right. (Repeat function available)
		Moves the cursor to the previous or subsequent block. (Repeat function available)
		Deletes one character in the cursor position.
		Switches the insert mode.
		<p>Erases one block while editing machining program. After touching the SHIFT key, touch the CAN C-B key to erase all blocks being displayed on the screen.</p>
		Enters EOB(;) into the machining program.
		Determines the entry.
	Switches the key function.	

25 OPERATING SERVO AMPLIFIER MONITOR
26 OPERATIONS OF SERVO AMPLIFIER MONITOR SCREENS
27 ERROR MESSAGES FOR SERVO AMPLIFIER MONITOR
28 OPERATING CNC MONITOR
29 OPERATING THE CNC MONITOR FUNCTION SCREEN
30 ERROR MESSAGES FOR CNC MONITOR
31 FONT CHANGE FUNCTION
32 SYSTEM DIALOG LANGUAGE SWITCHING

30 ERROR MESSAGES FOR CNC MONITOR

This chapter provides the error indications given during CNC monitor operation and their corrective actions. If two or more of the following errors have occurred, the error with the higher priority is displayed.

Priority	Error Message	Error Definition	Corrective Action
Higher  Lower	The GOT which can operate is only A985GOT.(CNC MONITOR)	CNC monitor was started on the GOT other than the A985GOT.	Start monitor on the A985GOT.
	Support communication driver is not installed.(CNC MONITOR)	The compatible communication driver is not installed in the GOT.	Install the compatible communication driver into the GOT. Ethernet connection: QJ71E71/AJ71(Q)E71 MELSECNET/10 connection: MNET/10(A/QnA/Q)
	The E71 communication driver being used doesn't cope with a CNC monitor. E71 communication driver [Ver9.2.0 or more] is to install a rest again.	The communication driver for Ethernet connection (QJ71E71/ (Q) E71) installed in the GOT is not compatible with CNC monitor.	Install into the GOT the communication driver for Ethernet connection (QJ71E71/ AJ71 (Q) E71) compatible with CNC monitor.
	The MNET10 communication driver being used doesn't cope with a CNC monitor. MNET10 communication driver is to install a rest again.	The communication driver for MELSEC-NET/10 connection (MNET/10) installed in the GOT is not compatible with CNC monitor.	Install into the GOT the communication driver for MELSECNET/10 connection (MNET/10) compatible with CNC monitor.
	The IP address of CNC to monitor is not set up.(CNC MONITOR)	The IP address of the CNC has not been set.	After setting the IP address of the CNC to be monitored in the Ethernet setting of GT Designer2, download the monitor data to the GOT.
	The Standard monitor OS being used doesn't cope with a CNC monitor. Standard monitor OS [Ver9.2.0 or more] is to install a rest again.	The standard monitor OS installed in the GOT does not support CNC monitor.	Install into the GOT the standard monitor OS that supports CNC monitor (Ver. 9.2.0 or later).

31 FONT CHANGE FUNCTION

31.1 Preparation to use the font change function

Before using the font change function, check the required devices, ROM_BIOS/OS version and GOT settings.

31.1.1 Checking the required devices

For devices required to use the font change function, refer to Section 2.2.

31.1.2 Checking the ROM_BIOS version

The following ROM_BIOS must be installed into the GOT to use the font change function.

Function	Compatible ROM_BIOS version
Font change function	Version X or later.

If the ROM_BIOS version older than above is installed in the GOT, install the compatible version. For installing ROM_BIOS, refer to GT Designer2 Version2 Operating Manual.


- (1) How to check the ROM_BIOS version.

The ROM_BIOS version installed in the GOT can be checked from the GOT memory information or rating plate.


However, if the ROM_BIOS version has been upgraded since purchase, check it from the memory information.

The ROM_BIOS version installed in the GOT at purchase, can be checked from the rating plate

Memory information




Rating plate



Remark

The GOT memory information is with in the Utility.

<Example of displaying the memory information>



Simultaneously touch the upper right/upper left corners of the screen.

Select the utility memory information.

Start and operate the utility with reference to Chapter 4.

31.1.3 Checking the OS

The following OS must be installed into the GOT to use the font change function.

OS	Description
Standard monitor OS	Version 9.4.0 or later

(1) Checking the OS

The information of the standard monitor OS and extended function OS information installed the GOT is obtainable from the GT Designer2 memory information.

If the extended function OS version older than above is installed in the GOT, install the compatible version.

For installing/checking the OS, refer to GT Designer2 Version2 Operating Manual.

(2) Precautions for installing the extended function OS

Install the extended function OS while paying attention to Section 2.2, as some OSs should not be combined with others.

31.2 Operation of the font change function

31.2.1 Setting the font change device

Font change is performed by writing the value corresponding to each font into the GOT internal device (font change device: GS453(b7 to b0)).

Value in GS453		Corresponding font
b15 to b8	b7 to b0	
System dialog language switching device	Font change device	
(Refer to Section 32.2.1)	00H	Standard font
	01H	Chinese (simplified characters) font
	02H or later	Used prohibited (The previous font is held.)

The following example shows how to make the settings so that the status observation function will work to automatically store "1" (Chinese (simplified characters) font) into the font change device after the GOT is powered ON.

<Example of setting the status observation function>

Make the following settings in the "Status Observation" screen.

- The GOT internal device (device that is always ON: GS0.b4) functions as a trigger.
- "1" is stored into the font change device when the trigger turns ON.

With this settings, the status observation function works and "1" is stored into the font change device after the GOT is powered ON.

For details of the observation status function, refer to GT Designer2 Version2 Reference Manual.



- Make the settings in the "Project" tab within the "Status Observation" screen.
- Put the settings in the first line. ("1" is stored into the font change device right after the GOT is powered ON.)*1
- Set "Observe Cycle" to "Ordinary".

*1: The font may not be switched to the Chinese (simplified characters) font, when the GOT is started. (The Chinese (simplified characters) font will appear by switching the screen to another one.)


Design screens while paying attention to the above.

31.2.2 Displaying Chinese (simplified characters) fonts with Preview of GT Designer2



To preview in Chinese (simplified characters), the font environment of GT Designer2 is required to be changed to Chinese (simplified characters).

The following describes how to change the font environment of GT Designer2.


- (1) When preview the standard characters (other than HQ fonts) in Chinese (simplified characters) fonts
 - (a) Change the font environment of GT Designer2 to Chinese (simplified characters)
 - 1) Delete the [unicode. fnt] in the GT Designer2 installation folder.





- 2) Copy the [unicode_gb. fnt] in the same folder and change the file name to [unicode. fnt].




- (b) Change the font environment of GT Designer2 back to using Japanese
- 1) Delete the [unicode. fnt] created by "(a) Change the font environment of GT Designer2 to Chinese (simplified characters)".





- 2) Copy the [unicode_jp. fnt] in the same folder and change the file name to [unicode. fnt].



- (2) When preview the HQ fonts characters in Chinese (simplified characters) fonts
- (a) Change the font environment of GT Designer2 to use Chinese (simplified characters)
- 1) Delete the [hqfont. dat] in the GT Designer2 installation folder.




- 2) Copy the [hqfont_gb. dat] in the same folder and change the file name to [hqfont. dat].





25 OPERATING SERVO AMPLIFIER MONITOR
 26 OPERATIONS OF SERVO AMPLIFIER MONITOR SCREENS
 27 ERROR MESSAGES FOR SERVO AMPLIFIER MONITOR
 28 OPERATING CNC MONITOR
 29 OPERATING THE CNC MONITOR FUNCTION SCREEN
 30 ERROR MESSAGES FOR CNC MONITOR
 31 FONT CHANGE FUNCTION
 32 SYSTEM DIALOG LANGUAGE SWITCHING

- (b) Change the font environment of GT Designer2 back to using Japanese
- 1) Delete the [hqfont. dat] created by "(a) Change the font environment of GT Designer2 to Chinese (simplified characters)".



- 2) Copy the [hqfont_jp. dat] in the same folder and change the file name to [hqfont. dat].



31.2.3 Installing font data


- (1) Displaying standard characters (other than HQ fonts) of Chinese (simplified characters) on the GOT

Install the font data of standard characters (other than HQ fonts) with the following procedure from (a) to (c) to display standard characters (other than HQ fonts) of Chinese (simplified characters) on the GOT.

 - (a) Writing OS (standard monitor OS, communication driver, extended function OS) into memory card.


Use GT Designer2 to write the required OSs into a memory card.

For details of writing into a memory card, refer to GT Designer2 Version2 Operating Manual.



- (b) Copying font data

Use the Windows® Explorer or similar to copy the font data (font_gb.bin) from "C:\MELSEC\GTD2\OS\font" into "OS" folder within the memory card.



(c) Transferring font data to GOT

Set a memory card to the GOT, and install the OS.

(Before data transfer, mount a memory board to the GOT.)

The font data will be transferred together with the OS into the GOT.

For details of installing into GOT, refer to GT Designer2 Version2 Operating Manual.

If the installation is completed, the following message appears on the GOT.

セットアップが完了しました。
本体の電源をリセットして下さい。
Setup completed
Cycle power on unit.

Point 

- Data transfer through the RS-232C communication is not available.
- The font data and OS are copied into a memory card by executing "DATA & OS CPY" within the utility.
By using the same memory card, the font data can be installed into another GOT.

(2) How to display HQ fonts with Chinese (simplified characters) on the GOT

To use HQ fonts for characters and comments, change the font environment of GT Designer2 to Chinese (simplified characters) and download the monitor data to the GOT from the changed GT Designer2.


For how to change the font environment of the GT Designer2, refer to Section 31.2.2 (2).

Point 

For downloading method of monitor data, refer to GT Designer2 Version2 Operating Manual.

31.3 Troubleshooting when font cannot be changed.

The following shows the corrective actions when font cannot be changed.



32 SYSTEM DIALOG LANGUAGE SWITCHING

32.1 Preparation to use the system dialog language switching function

Before using the system dialog language switching function, check the required devices, ROM_BIOS/OS version and GOT settings.

32.1.1 Checking the required devices

For devices required to use the system dialog language switching function, refer to Section 2.2.

32.1.2 Checking the ROM_BIOS version

The ROM_BIOS version has no restrictions when using the system dialog language switching function.



When using the system dialog language switching function with the font change function, check the required devices, ROM_BIOS/OS version, and GOT settings referring to "Chapter 31 FONT CHANGE FUNCTION".

32.1.3 Checking the OS

The following OS must be installed into the GOT to use the system dialog language switching function.

OS	Description
Standard monitor OS	Version 9.7.6 or later

(1) Checking the OS

The information of the standard monitor OS and extended function OS information installed the GOT is obtainable from the GT Designer2 memory information.

If the extended function OS version older than above is installed in the GOT, install the compatible version.

For installing/checking the OS, refer to GT Designer2 Version2 Operating Manual.

32.2 Operation of the system dialog language switching function

32.2.1 Setting the system dialog language switching device

System dialog language switching is performed by writing the value corresponding to each language into the GOT internal device (system dialog language switching device: GS453(b15 to b8)).

Value in GS453		Corresponding language
b15 to b8	b7 to b0	
System dialog language switching device	Font change device	
00H	(Refer to Section 31.2.1)	Japanese/English (The language can be switched by the utility.*1)
01H		Chinese (simplified characters)
02H		Chinese (traditional characters)
03H or later		Used prohibited

*1 Switching of the language to be displayed (Japanese/English) is set with the followings.

- Setting the language with the language selection key on the Utility Menu screen (Refer to Section 4.3.)
- Setting the language with [Language] in Setup of the utility function (Refer to Section 4.5.)

32.3 Example of system dialog language display

The following shows system dialogs for which language switching (system dialog language switching function) is available.

Occurrence factor	Displayed message	
	Set language: Japanese (Set font: Standard font)	Set language: English (Set font: Standard font)
The touch panel is pressed when an event as base screen switching has occurred.	画面変更(切換え、移動など) または、アラーム流れが発生しました。 画面から手をはなしてください。	The screen change (switching screen and moving screen,etc.) or alarm flow was detected. Remove your finger from the display.
The execution condition was not satisfied when starting an extended function (such as ladder monitor function) from the utility menu or monitor screen. For example, the required extended function OS was not installed.	[When using A985GOT(-V)/A97*GOT/ A960GOT] 現在この機能は使えません	[When using A985GOT(-V)/A97*GOT/ A960GOT] This function cannot be used now.
	[When using A956WGOT/A95*GOT] この機能は使えません	[When using A956WGOT/A95*GOT] The func.cannot be used
Objects are overlapped.	オブジェクトが 重なっています	Coordinates error
The input numerical or ascii data exceeded the max. input digits.	最大入力桁を オーバーしました	Input data error, number too large/small
The integer part of the input numerical data exceeded the max. input digits.	整数部が最大入力桁を オーバーしました	Input data error, too many integer places
The decimal part of the input numerical data exceeded the max. input digits.	小数部が最大入力桁を オーバーしました	Input data error, too many decimal places
The numerical data out of range was input.	範囲外のデータが 入力されました	Input data error, out of range
The condition was not satisfied when pressing the RET key, while the condition was satisfied when selecting the object and displaying the cursor in numerical/ascii input.	入力条件が 成立していません	Interlock not set
The RET key of numerical/ascii input was pressed while the GOT internal device GS450.b0 was "1" (ON).	下記値に変更しますか	Do you want to change?

Occurrence factor	Displayed message	
	Set language: Chinese (simplified characters) (Set font: Chinese (simplified characters) font)	Set language: Chinese (traditional characters) (Set font: Standard font)
The touch panel is pressed when an event as base screen switching has occurred.	画面变更了(切换, 移动等), 或是发生了浮动报警。 请不要触摸画面。	畫面變更了(切換, 移動等), 或是發生了浮動報警。 請不要觸摸畫面。
The execution condition was not satisfied when starting an extended function (such as ladder monitor function) from the utility menu or monitor screen. For example, the required extended function OS was not installed.	不能使用此功能	不能使用此功能
Objects are overlapped.	对象有重叠	對象有重疊
The input numerical or ascii data exceeded the max. input digits.	超过了最大输入位数	超過了最大輸入位數
The integer part of the input numerical data exceeded the max. input digits.	整数部分 超过了最大输入位数	整數部分 超過了最大輸入位數
The decimal part of the input numerical data exceeded the max. input digits.	小数部分 超过了最大输入位数	小數部分 超過了最大輸入位數
The numerical data out of range was input.	输入了范围外的数据	輸入了範圍外的數據
The condition was not satisfied when pressing the RET key, while the condition was satisfied when selecting the object and displaying the cursor in numerical/ascii input.	输入条件不成立	輸入條件不成立
The RET key of numerical/ascii input was pressed while the GOT internal device GS450.b0 was "1" (ON).	更改成下列数值吗	更改成下列數值嗎

25 OPERATING SERVO AMPLIFIER MONITOR
26 OPERATIONS OF SERVO AMPLIFIER MONITOR SCREENS
27 ERROR MESSAGES FOR SERVO AMPLIFIER MONITOR
28 OPERATING CNC MONITOR
29 OPERATING THE CNC MONITOR FUNCTION SCREEN
30 ERROR MESSAGES FOR CNC MONITOR
31 FONT CHANGE FUNCTION
32 SYSTEM DIALOG LANGUAGE SWITCHING

INDEX

[A]	Adapter address 4-9	[H]	Host (FF) address 4-9
[B]	Batch monitor 9-10		How to display the utility menu 4-2
	Baud rate 4-9		Human sensor detection sensitivity 4-12
	BM Monitor 9-14		Human sensor function 4-13
	Brightness/contrast adjustment of 4-4		Human sensor OFF delay 4-12
	Brightness/contrast adjustment screen 4-21	[L]	Ladder monitor function 1-3
	Buzzer sound 4-8		Ladder read operation 6-9
[C]	C.C.U monitor registration 4-10		List editor function 1-11
	Capacity of special module monitor data 3-5	[M]	Memory information 4-16
	Clock setting 4-17		Message display 1-2
	CNC monitor functions 1-16		Microcomputer connection protocol 4-9
	Connection transmission speed 4-9		Microcomputer connection transmission speed 4-9
[D]	Deleting a registered device 9-9	[N]	Network monitor function 1-9
	Detailed own station monitor 17-4	[O]	Operation for defect search 6-12
[E]	Entry monitor 9-7		Operation procedures
	Error display and handling		CNC monitor function 28-1
	Ladder monitor function 7-1		Font change function 31-1
	List editor function 21-1		Ladder monitor function 5-1
	Network monitor function 18-1		List editor function 19-1
	Servo amplifier monitor 27-1		Network monitor function 15-1
	Special module monitor function 14-1		Servo amplifier monitor 25-1
	System monitor function 10-1		Special module monitor function 11-1
	Error List 23-7		System dialog language switching function 32-1
	Error List Axis 23-8		System monitor function 8-1
[F]	Features		Other station monitor 17-12
	CNC monitor functions 1-16		Outside speaker sound 4-8
	Font change function 1-17		Own station monitor 17-1
	Ladder monitor function 1-3	[P]	Password 4-20
	List editor function 1-11		Positioning Monitor 23-10
	Network monitor function 1-9		Present Value Hist 23-13
	Servo amplifier monitor 1-14		Present Value Mon 23-5
	Special module monitor function 1-7	[Q]	QBUS extension number 4-9
	System dialog language switching function 1-17		QBUS slot number 4-9
	System monitor function 1-5		QC24 connection transmission speed 4-9
	Utility function 1-1		Quick test function 9-20
	Font change function 1-17	[R]	Reading data from the PLC 6-3
	Functions require a memory board 2-1		Required equipment 2-1
[G]	GOT IP address 4-11		Reverse display 4-12
	GOT NET No. 4-11		Router Address 4-11
	GOT PC No. 4-11		
	GOT port No. 4-11		
	Grip switch 4-12		

[S]

Screen & OS copy	4-5
Screen cleanup	4-18
Screen display and key functions	
Batch monitor	9-11
BM monitor	9-15
Detailed own station monitor	17-4
Entry monitor	9-8
Ladder monitor function	6-19
Other station monitor	17-12
Special module monitor function	12-1
System monitor function	9-1
TC monitor	9-13
Screen save light	4-8
Screen save time	4-8
Screen saver function	4-8
Screen saver Human sensor	4-12
Security password	4-19
Self test	4-15
Send Message Delay	4-9
Send Message Time	4-11
Send Message Wait	4-11
Servo amplifier monitor function	25-1
Servo Monitor SFC Error History	23-6
Setup	4-7
Special module monitor function	1-7
Specifications	
CNC monitor function	3-26
Font change function	3-27
Ladder monitor function	3-1
List editor function	3-11
Network monitor function	3-9
Servo amplifier monitor functions	3-21
Special module monitor function	3-3
System dialog language switching function	3-29
System monitor function	3-2
Specifying the monitor station and device	9-4
Startup time	4-10,4-11
Sub-net Mask	4-11
System dialog language switching function	1-17
System monitor function	1-5

[T]

TC monitor	9-12
Test for special function module	12-9
Test function	9-20

[U]

Utility function	1-1
Utility function list	4-1

Warranty

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place.

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

(1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued.

Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.

(2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation of damages caused by any cause found not to be the responsibility of Mitsubishi, loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products, special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products, replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

6. Product application

- (1) In using the Mitsubishi MELSEC programmable logic controller, the usage conditions shall be that the application will not lead to a major accident even if any problem or fault should occur in the programmable logic controller device, and that backup and fail-safe functions are systematically provided outside of the device for any problem or fault.
- (2) The Mitsubishi programmable logic controller has been designed and manufactured for applications in general industries, etc. Thus, applications in which the public could be affected such as in nuclear power plants and other power plants operated by respective power companies, and applications in which a special quality assurance system is required, such as for Railway companies or Public service purposes shall be excluded from the programmable logic controller applications.

In addition, applications in which human life or property that could be greatly affected, such as in aircraft, medical applications, incineration and fuel devices, manned transportation, equipment for recreation and amusement, and safety devices, shall also be excluded from the programmable logic controller range of applications.

However, in certain cases, some applications may be possible, providing the user consults their local Mitsubishi representative outlining the special requirements of the project, and providing that all parties concerned agree to the special circumstances, solely at the users discretion.

GOT-A900 Series Operating Manual

(GT Works2 Version2/GT Designer2 Version2 Compatible
Extended·Option Functions Manual)

MODEL	SW2-GT900-O(SYS)-E
MODEL CODE	1DM218
SH(NA)-080523ENG-F(0611)MEE	

 **MITSUBISHI ELECTRIC CORPORATION**

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.